

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
AIWA	TV-1402	2	1		
AIWA	TV-2002	2	1		
AIWA	TV-207	2	23		
AIWA	TV-2102	2	1		
AIWA	TV-2112SH	1	15		
AIWA	TV-A145	7	13		
AIWA	TV-A205	7	13		
AIWA	TV-A215	3	15		
AIWA	TV-C141	2	19		
AIWA	TV-C142	7	15		
AIWA	TV-C201	2	19		
AIWA	TV-C202	2	13		
AKAI	CT-1407DTY1	3	3		
AKAI	CT-1407DY1	3	3		
AKAI	CT-1417D(Y1)	12	15		
AKAI	CT-1419DD (U2E)	2	29		
AKAI	CT-1419PD (Y2/Y2E)	2	29		
AKAI	CT-1419PDT (U2E)	2	29		
AKAI	CT-1419PDT (Y2E)	2	29		
AKAI	CT-14WKD	2	29		
AKAI	CT-14WKD/T	2	29		
AKAI	CT-2005EA	57	19		
AKAI	CT-2007D[Yi]	4	23		
AKAI	CT-2007DT[Yi]	4	23		
AKAI	CT-205M	15	15		
AKAI	CT-2107D[Yi]/E1	11	23		
AKAI	CT-2119PD(U2E)	6	21		
AKAI	CT-2119PD(Y2/Y2E)	8	21		
AKAI	CT-2119PDT(U2E)	4	21		
AKAI	CT-2119PDT(Y2E)	2	21		
AKAI	CT-217D	15	15		
AKAI	CT-21W30A(S3)	2	27		
AKAI	CT-21W30AT(S3)	2	27		
AKAI	CT-21W30DM(Y3)	2	27		
AKAI	CT-21W30M(U1/U7)	2	27		
AKAI	CT-21W30M(U50)	2	27		
AKAI	CT-21W30MT(U50)	2	27		
AKAI	CT-21W30PA(Y9)	2	27		
AKAI	CT-21W30PD(Y2)	2	27		
AKAI	CT-21W30PDB(Y6)	2	27		
AKAI	CT-21WKD	2	27		
AKAI	CT-G140	2	28		
AKAI	CT-G215	2	28		
AKIRA	ST-14MS9	2	29		
AMCOL	C2101	2	3		
AMTEL	CTV-1403R	2	18		
ATEC	TV-1402 MK9	2	4		
ATLANTA	AT-2020	11	23		
AVANTI	T1200	87	14		
AVANTI		88	14		
BEIJING	8303	2	22		
BEKO	14"/20"/21"/25"/28"	1	12		
BLACK and WHITE	T8	92	8		
BRANDT		84	22	TX 91G	
BRANDT		90	22	TX 92	
BRANDT		97	22	TX 92	
BRANDT		92	23	ICC6	
CASIO	EV-1800B (KX-523)	16	21		
CASIO	EV-510B (KX-619B)	8	19		
CASIO	EV-510C/D//N	2	20		

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
CASIO	EV-600 (KX-613)	14	21		
CASIO	EV-770C/D/G/N	5	20		
CASIO	JY-10C/D/I/N (KX-513)	11	21		
CHANCCHENG	C539	84	29		
COLORLUX	4110A	2	8	110°	
COLORMAT	4506A/4510A/4610A/	5	26	H9	
COLORTRON	4100A	2	8	110°	
CONTEC	FS-2140SK	1	14		
CONTEC	MFP-5398	21	15		
CONTEC	MFP-5398	30	4		
CONTEC	MV-5198/A/	21	15		
CONTEC	MV-5198A	30	4		
CROWN	CTV-B5055	10	26		
DAEWOO	14/20/21A5/T	10	20	CP-375	
DAEWOO	14/20/21Q1/T	10	20	CP-375	
DAEWOO	14/20/21Q2/T	10	20	CP-375	
DAEWOO	14/20/21T1/T	10	20	CP-375	
DAEWOO	14/20/21T2/T	10	20	CP-375	
DAEWOO	14/20/Q3/T	10	20	CP-375	
DAEWOO	21Q4/T	10	20	CP-375	
DAEWOO	CTV-2595	7	9	CP-760	
DAEWOO	CTV-2895	7	9	CP-760	
DAEWOO	DTC-25XXVM/TM	2	17	CM-805	
DAEWOO	DTC-29XXVM/VMO/TM	2	17	CM-805	
DAEWOO	DTD-1427/1447/1451/1457/1458	20	13	CP-315(F,P)	
DAEWOO	DTD-2027/2046/2047/2051/2057	20	13	CP-315(F,P)	
DAEWOO	DTD-2058/2147/2148/2157	20	13	CP-315(F,P)	
DAEWOO	DTD-2158/2159/2169	20	13	CP-315(F,P)	
DAEWOO	DTG-2593/2596/2597/2997TK	8	4		
DAEWOO	DTK-1417/1649/2057/2157VMS	2	7	C-50N	
DAEWOO	DTK-1432/1435/1436	16	13	CP-52	
DAEWOO	DTK-2035/2036/2053	16	13	CP-52	
DAEWOO	DTK-2135/2136	16	13	CP-52	
DAEWOO	DTT-1427/1442/1444/1446/1451	2	5	C-50	
DAEWOO	DTT-1457/1458/1649/2027/2044	2	5	C-50	
DAEWOO	DTT-2046/2047/2049/2051/2057	2	5	C-50	
DAEWOO	DTT-2058/2147/2157	2	5	C-50	
DAEWOO	DTX-14/20/21A1	11	13	CP-330	
DAEWOO	DTX-14B1	11	13	CP-330	
DAEWOO	DTX-21C1	11	13	CP-330	
DAEWOO	T140/T142/T200/T202/T512	11	13	CP-330	
DAEWOO	T594/T694	7	9	CP-760	
DAEWOO	TDK-1413/1418/2013/2018VM	2	9	C-50NA	
DAEWOO	TDY-2510T	4	9	CP-765	
DAEWOO	TDY-2570/2590/2595/2599	7	9	CP-760	
DAEWOO	TDY-2870/2890/2895/2899	7	9	CP-760	
DISTAR	SCM-101 AMS	19	15	D-101A	
ELEKTA	CTR-1020	2	25		
ELEKTA	CTR-1498EMK	1	2		
ELEKTA	CTR-2005	22	26		
ELEKTA	CTR-2036E MK2	2	5	C-50	
ELEKTA	CTR-2036E MK3	2	26		
ELEKTA	CTR-20T39E MK3	4	7		
ELEKTA	E-1411 MK2	112	25		
ELEKTA	E-1414	113	25		
ELEKTA		93	8		
ELEKTRA		94	21		
ELEKTRA		40	25		
FERGUSON		84	22	TX 91G	
FERGUSON		90	22	TX 92	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
FERGUSON		97	22	TX 92	
FERGUSON		92	23	ICC6	
FISHER	FTM-536	5	1	057	
FISHER	FTM-542	5	1	057	
FISHER	FTM-551	5	1	057	
FISHER	FTM-954DK/TXT	6	7	097	
FISHER		4	5		
FUNAI	MS-14A	2	11		
FUNAI	MS-14A MK2	6	11		
FUNAI	MS-14A MK3	8	11		
FUNAI	MS-14VN	8	11		
FUNAI	MS-14VN2	8	11		
FUNAI	MS-20	12	11		
FUNAI	MS-20 HYPER	14	11		
FUNAI	MS-20A	14	11		
FUNAI	MS-20A MK2	14	11		
FUNAI	MS-20A MK3	17	11		
FUNAI	MS-20VN MK2	17	11		
FUNAI	TV-1400A MK6	2	6		
FUNAI	TV-1400A MK8	26	13		
FUNAI	TV-1400A MK8	15	9		
FUNAI	TV-2000A MK7	2	2		
FUNAI	TV-2000A MK8	11	3		
FUNAI	TV-2000T MK7	6	3		
FUNAI	TV-2003	3	1		
FUNAI	TV-2008GL	8	3		
FUNAI	TV-20MS	3	1		
FUNAI	TV-2100 MK10 HYPER	4	14		
FUNAI	TV-2100A MK6	3	6		
FUNAI	TV-2100A MK7	6	12		
FUNAI	TV-2100A MK8	21	11		
FUNAI	TV-2100T MK8	21	11		
FUNAI	TV-2500A MK8	26	11		
FUNAI	TV-2500T MK8	26	11		
FUTIC	FC-9220	111	25		
FUTIC	FC-9230	111	25		
GOLDSTAR(LG)	CF-14/16/20/21S10E/X/12E	23	19	MC-84A	
GOLDSTAR(LG)	CF-14/20/21A80B	18	7	MC-41B	
GOLDSTAR(LG)	CF-14/20/21A80V	16	19	MC-34A	
GOLDSTAR(LG)	CF-14/20/21A80Y	39	2	MC-41A	
GOLDSTAR(LG)	CF-14/20/21D60	19	19	MC-64A	
GOLDSTAR(LG)	CF-14/20/21D60B	30	11	MC-41B	
GOLDSTAR(LG)	CF-14/20/21D70R	19	19	MC-64A	
GOLDSTAR(LG)	CF-14/20/21E20B	30	11	MC-41B	
GOLDSTAR(LG)	CF-14/20/21E20R	19	19	MC-64A	
GOLDSTAR(LG)	CF-14/20/21E40B	13	19	MC-41B	
GOLDSTAR(LG)	CF-14/20/21E40R	19	19	MC-64A	
GOLDSTAR(LG)	CF-14/20/21F60	23	19	MC-84A	
GOLDSTAR(LG)	CF-14/20/21F80	23	19	MC-84A	
GOLDSTAR(LG)	CF-14/20/21G20R	19	19	MC-64A	
GOLDSTAR(LG)	CF-14/20/21K50E/X	23	19	MC-84A	
GOLDSTAR(LG)	CF-14/20/21K52E/X	23	19	MC-84A	
GOLDSTAR(LG)	CF-14A90B	18	7	MC-41B	
GOLDSTAR(LG)	CF-14B10B	30	11	MC-41B	
GOLDSTAR(LG)	CF-14B80	16	19	MC-34A	
GOLDSTAR(LG)	CF-14D10	16	19	MC-34A	
GOLDSTAR(LG)	CF-20/21B70V	16	19	MC-34A	
GOLDSTAR(LG)	CF-20/21B80	19	19	MC-64A	
GOLDSTAR(LG)	CF-20/21C22X	47	11	MC-46A	
GOLDSTAR(LG)	CF-20/21D10B	13	19	MC-41B	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
GOLDSTAR(LG)	CF-20/21D16	19	19	MC-64A	
GOLDSTAR(LG)	CF-20/21D70B	13	19	MC-41B	
GOLDSTAR(LG)	CF-20/21D70X	19	19	MC-64A	
GOLDSTAR(LG)	CF-20/21E60	19	19	MC-64A	
GOLDSTAR(LG)	CF-20/21E60B	13	19	MC-41B	
GOLDSTAR(LG)	CF-20/21E60X	19	19	MC-64A	
GOLDSTAR(LG)	CF-20/21F30	19	19	MC-64A	
GOLDSTAR(LG)	CF-20/21G20X	19	19	MC-64A	
GOLDSTAR(LG)	CF-20/21K40E	23	19	MC-84A	
GOLDSTAR(LG)	CF-20A80	93	9	MC-34A	
GOLDSTAR(LG)	CF-20D29	10	19	MC-64B	
GOLDSTAR(LG)	CF-20E50X	30	13	MC-46A	
GOLDSTAR(LG)	CF-21A90V	16	19	MC-34A	
GOLDSTAR(LG)	CF-21D20B	13	19	MC-41B	
GOLDSTAR(LG)	CF-21D30RX	10	19	MC-64B	
GOLDSTAR(LG)	CF-21D70M	15	20	MC-83A	
GOLDSTAR(LG)	CF-25/29C32J	41	11	PC-33J	
GOLDSTAR(LG)	CF-25/29C36	51	11	MC-51B	
GOLDSTAR(LG)	CF-25/29C42P	61	19	MC-15A	
GOLDSTAR(LG)	CF-25C44	3	10	MC-51A	
GOLDSTAR(LG)	CF-25C60	3	10	MC-51A	
GOLDSTAR(LG)	CF-25C70	3	10	MC-51A	
GOLDSTAR(LG)	CF-25C80	3	10	MC-51A	
GOLDSTAR(LG)	CF-29C10	33	11	MC-15A	
GOLDSTAR(LG)	CF-29C10	61	19	MC-15A	
GOLDSTAR(LG)	CF-29C20J	41	11	PC-33J	
GOLDSTAR(LG)	CF-29C20P	33	11	MC-15A	
GOLDSTAR(LG)	CF-29C20P	61	19	MC-15A	
GOLDSTAR(LG)	CF-29C44/80	3	10	MC-51A	
GOLDSTAR(LG)	CF-29C60/70	3	10	MC-51A	
GOLDSTAR(LG)	CF-29H20TM	10	17	MC-71A	
GOLDSTAR(LG)	CF-29H20TM/NM	18	20	MC-71A	
GOLDSTAR(LG)	CF-29H30/T/N	26	19	MC-74A	
GOLDSTAR(LG)	CF-29H90TM/XM/NM	23	20	MC-71B	
GOLDSTAR(LG)	CF-29V10KT/N	28	20	MD-66A	
GOLDSTAR(LG)	CF-34C60/NM/XM/TM	18	20	MC-71A	
GOLDSTAR(LG)	CFT-2505/P	33	11	MC-15A	
GOLDSTAR(LG)	CFT-2590/P	33	11	MC-15A	
GOLDSTAR(LG)	CFT-2875	61	19	MC-15A	
GOLDSTAR(LG)	CFT-2875/P	33	11	MC-15A	
GOLDSTAR(LG)	CKT-2180/X	61	18	PC-04A	
GOLDSTAR(LG)	CKT-2190	35	2	PC-04A	
GOLDSTAR(LG)	CKT-2570	65	18	PC-12A	
GOLDSTAR(LG)	CKT-2571X	65	18	PC-12A	
GOLDSTAR(LG)	CKT-2870/1	42	2	PC-12A	
GOLDSTAR(LG)	CKT-2876X	65	18	PC-12A	
GOLDSTAR(LG)	CKT-4442B	31	2	PC-05X2	
GOLDSTAR(LG)	CKT-9322B	31	2	PC-05X2	
GOLDSTAR(LG)	CKZ-4822X	61	18	PC-04A	
GOLDSTAR(LG)		28	1	PCO8X8	
GOLDSTAR(LG)		1	10	MC-0AA	
GRUNDIG	14V1R/T	17	31	CUC7303 GB	
GRUNDIG	20V1R/T	17	31	CUC7303 GB	
GRUNDIG	B8400/4/7/KT/VT/GB	7	1	CUC 720	
GRUNDIG	B8410/2/3/4KT	7	1	CUC 720	
GRUNDIG	GR-1450	2	28		
GRUNDIG	GR-1455	2	28		
GRUNDIG	GR-2150	2	28		
GRUNDIG	M61-1690 DPL	16	12	CUC 6460	
GRUNDIG	M61-1690 DPL	16	12	CUC 6465/6480	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
GRUNDIG	M63-281/8/IDTV/LOG	18	27	CUC 1826	
GRUNDIG	M63-370 CTi/text/GB	2	31	CUC3600/3800	
GRUNDIG	M63-375/9/CTi/GB/9text	2	31	CUC3600/3800	
GRUNDIG	M63-670/TOP	22	8	CUC 5361	
GRUNDIG	M70-169/9 IDTV	2	16	CUC 1951	
GRUNDIG	M70-1690 DPL	16	12	CUC 6460	
GRUNDIG	M70-1690 DPL	16	12	CUC 6465/6480	
GRUNDIG	M70-269/9	6	25	CUC 1952	
GRUNDIG	M70-281/8/IDTV/LOG	18	27	CUC 1826	
GRUNDIG	M70-390/9/GB/9text	2	31	CUC3600/3800	
GRUNDIG	M70-395 CTi	2	31	CUC3600/3800	
GRUNDIG	M70-395 CTi/GB/text	2	31	CUC3600/3800	
GRUNDIG	M70-396 CTi-PC	2	31	CUC3600/3800	
GRUNDIG	M72-270 IDTV/LOG	18	27	CUC 1826	
GRUNDIG	M72-410/9/PIP	6	25	CUC 1842	
GRUNDIG	M82-169/9 IDTV	2	16	CUC 1982	
GRUNDIG	M82-269/9/ PAL PLUS	6	25	CUC 1984	
GRUNDIG	M82-269/9/ PAL PLUS/LOS	6	25	CUC 1983	
GRUNDIG	M84-210/8 IDTV/LOG	18	27	CUC 1827	
GRUNDIG	M95-410/9/PIP	6	25	CUC 1894	
GRUNDIG	MW70-269 PAL PLUS	6	25	CUC 1952	
GRUNDIG	MW82-100/9	6	25	CUC 1984	
GRUNDIG	P27-649/12	8	12	CUC 5200	
GRUNDIG	P37-040	6	8	CUC 5330	
GRUNDIG	P37-050	6	8	CUC 5330	
GRUNDIG	P37-060	56	11	CUC 6300	
GRUNDIG	P37-342/CTI	15	1	CUC 3400	
GRUNDIG	P3747	6	8	CUC 5330	
GRUNDIG	P37-640text	56	11	CUC 6300	
GRUNDIG	P37-731/12text	37	12	CUC 7305	
GRUNDIG	P37-733/5text	17	31	CUC7303	
GRUNDIG	P40-050	6	8	CUC 5330	
GRUNDIG	P40-060	56	11	CUC 6300	
GRUNDIG	P40-345CTI/GB	15	1	CUC 3400	
GRUNDIG	P4047	6	8	CUC 5330	
GRUNDIG	P40-640text	56	11	CUC 6300	
GRUNDIG	P42-050	6	8	CUC 5330	
GRUNDIG	P42-060	56	11	CUC 6300	
GRUNDIG	P42-342CTI	15	1	CUC 3400	
GRUNDIG	P45-345CTI	15	1	CUC 3400	
GRUNDIG	P45-640text	56	11	CUC 6300	
GRUNDIG	SE 2670text/TOP/8TOP	22	8	CUC 5361	
GRUNDIG	SE 4264	6	8	CUC 5330	
GRUNDIG	SE 6367text	22	8	CUC 5360	
GRUNDIG	SE 7016/9	6	25	CUC 1952	
GRUNDIG	SE 7026 PAL PLUS	6	25	CUC 1952	
GRUNDIG	SE 7065text	22	8	CUC 5360	
GRUNDIG	SE 7066/8TOP	22	8	CUC 5361	
GRUNDIG	SE 7075text	22	8	CUC 5361	
GRUNDIG	SE 7086/TOP	22	8	CUC 5361	
GRUNDIG	SE 70-869 IDTV	18	27	CUC 1826	
GRUNDIG	SE 7090/8 IDTV/LOG	18	27	CUC 1826	
GRUNDIG	SE 8216/9/ PAL PLUS/PIP	6	25	CUC 1984	
GRUNDIG	ST 1663text/8	22	8	CUC 5360	
GRUNDIG	ST 1670text	22	8	CUC 5360	
GRUNDIG	ST 2663/8TOP	22	8	CUC 5361	
GRUNDIG	ST 63-650text/8text	22	8	CUC 5360	
GRUNDIG	ST 63-655/8text/8TOP/FT/GB	22	8	CUC 5360	
GRUNDIG	ST 63-660 8FT/GB	22	8	CUC 5360	
GRUNDIG	ST 63-671text	22	8	CUC 5361	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
GRUNDIG	ST 6367text	22	8	CUC 5360	
GRUNDIG	ST 6368text	22	8	CUC 5360	
GRUNDIG	ST 70-650text/8	22	8	CUC 5360	
GRUNDIG	ST 70-655text/8	22	8	CUC 5360	
GRUNDIG	ST 70-657/TOP	22	8	CUC 5360	
GRUNDIG	ST 70-660/8FT/GB	22	8	CUC 5361	
GRUNDIG	ST 70-670/TOP/8TOP	22	8	CUC 5361	
GRUNDIG	ST 7068text	22	8	CUC 5360	
GRUNDIG	ST 70-755/9 DPL/LOG	16	12	CUC 6460	
GRUNDIG	ST 70-755/9 DPL/LOG	16	12	CUC 6465/6480	
GRUNDIG	ST 70-93text	22	8	CUC 5360	
GRUNDIG	ST 72-261 IDTV/LOG	18	27	CUC 1826	
GRUNDIG	ST 72-761/8 IDTV/LOG	18	27	CUC 1826	
GRUNDIG	T1655text	56	11	CUC 6300	
GRUNDIG	T50-640text	56	11	CUC 6300	
GRUNDIG	T51-040	6	8	CUC 5330	
GRUNDIG	T51-050	6	8	CUC 5330	
GRUNDIG	T51-060	56	11	CUC 6300	
GRUNDIG	T51-066/5	17	31	CUC7303	
GRUNDIG	T51-070	17	17	CUC 7301	
GRUNDIG	T51-340	15	1	CUC 3400	
GRUNDIG	T51-640text	56	11	CUC 6300	
GRUNDIG	T51-720/text	20	17	CUC 7301	
GRUNDIG	T51-730/5text/text	17	17	CUC 7301	
GRUNDIG	T51-730/textASIS/5textASIS	20	17	CUC 7301	
GRUNDIG	T51-731/5text/text	17	17	CUC 7301	
GRUNDIG	T51-733/5text	17	31	CUC7303	
GRUNDIG	T55-050	6	8	CUC 5330	
GRUNDIG	T55-060	56	11	CUC 6300	
GRUNDIG	T55-066/5	17	31	CUC7303	
GRUNDIG	T55-340CTI/VT/GB	15	1	CUC 3400	
GRUNDIG	T55-640text	56	11	CUC 6300	
GRUNDIG	T55-730/text/5text	17	17	CUC 7301	
GRUNDIG	T55-730/text/5text/textASIS/5textASIS	20	17	CUC 7301	
GRUNDIG	T55-731/5text	17	17	CUC 7301	
GRUNDIG	T55-731/5text	20	17	CUC 7301	
GRUNDIG	T6346	15	8	CUC 5310	
GRUNDIG	T63-640text/DS/FT/GB	15	8	CUC 5310	
GRUNDIG	T70-640text/DS/FT/GB	15	8	CUC 5310	
GRUNDIG	XS 63 8/FT/GB	22	8	CUC 5360	
GRUNDIG	XS 70 8/8FT/GB	22	8	CUC 5360	
GRUNDIG		24	1	CUC 4400	
GRUNDIG		32	12	CUC 7300/7302	
GRUNDIG		14	3	CUC 4510	
GRUNDIG		5	6	CUC 1835	
GRUNDIG		5	6	CUC 1860	
GRUNDIG		5	6	CUC 1880	
GRUNDIG		5	6	CUC 1890	
GRUNDIG		10	7	CUC 5511	
HAPPI	EC 2067AR	13	4		
HITACHI	C21-S250	22	4		
HITACHI	C2578FS/081S/981/PX-981	33	17	V1	
HITACHI	C2589FS/041/051/751	33	17	V1	
HITACHI	C25-S250	22	4		
HITACHI	C2978FS/191/192/433	33	17	V1	
HITACHI	C2989FS/081S/981/PX-981	33	17	V1	
HITACHI	CMT 1450	6	2	G7PN-26	
HITACHI	CMT 1471-191/192/431/051	28	17	S3	
HITACHI	CMT 1472	37	15	CTV 1401	
HITACHI	CMT 1473-981	28	17	S3	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
HITACHI	CMT 2077	37	15	CTV 1401	
HITACHI	CMT 2117-191/192	19	2	SO	
HITACHI	CMT 2130	62	11	NP84C22	
HITACHI	CMT 2141	4	2	G7PN-24	
HITACHI	CMT 2145-191/192	19	2	SO	
HITACHI	CMT 2157-191/192	19	2	SO	
HITACHI	CMT 2191-191/192/192S/981/981S	25	15	S2-M3	
HITACHI	CMT 2192-192/981	9	18		
HITACHI	CMT 2192T-441	9	18		
HITACHI	CMT 2193-171/192/441	28	15	A1PS	
HITACHI	CMT 2198-041R/981	31	15	S2-M3	
HITACHI	CMT 2518	23	2	G9PL	
HITACHI	CMT 2528-051/081/981	8	2	A1PL	
HITACHI	CMT 2578-191/192/433	33	17	V1	
HITACHI	CMT 2579-191/192/192S/081S	7	5		
HITACHI	CMT 2718	23	2	G9PL	
HITACHI	CMT 2918	23	2	G9PL	
HITACHI	CMT 2928-051/081/981	8	2	A1PL	
HITACHI	CMT 2978-041/051/751	33	17	V1	
HITACHI	CMT 2979-051/981/081S/751	10	10	S4	
HITACHI	CMT 2979-191/192/192S/041	10	10	S4	
HITACHI	CMT 2979PX-981	10	10	S4	
HITACHI	CS-1406R/T	16	4		
HITACHI	CS-2106R/T	18	4		
HITACHI	CS-2506R/T	20	4		
HITACHI	CST 1435P/S	26	4		
HITACHI	CST 1570	26	4		
HITACHI	CST 2148	7	14		
HITACHI	CST 2548	7	14		
HITACHI	HFS 1425	14	4	F90PT	
HITACHI	HFS 1925	14	4	F90PT	
HITACHI	HFS 2014R	6	18	HFS-1	
HITACHI	HFS 2111	6	18	HFS-1	
HITACHI	HFS 2125	14	4	F90PT	
HITACHI	CP1415R/T	14	29		
HITACHI	CP1714/RE/TE	14	29		
HITACHI	CP1715R/T	14	29		
HITACHI	CP2114RE/TE	14	29		
HITACHI	CP2115R/RE/TE	14	29		
HITACHI	CP2514RE/TE	14	29		
HITACHI	CP2514RE/TE	14	29		
HITACHI	CP2515R/RE/T/TE	14	29		
HITACHI	CS1415R/T	12	29		
HITACHI	CS2114RE/TE	14	29		
HITACHI	CS2115R/T	14	29		
HITACHI	CS2515R/T	14	29		
HUANYU	54C-3RA	31	8		
ITT	IDEAL COLOR 3436	73	6	Compact 80 90°	
ITT		69	6	S4-SQ-110°	
JVC	7755EE	12	5		
JVC	7808EE	14	5		
JVC	AV-1410EE	21	31	CL	
JVC	AV-14TE/-A/	27	16	MZ2	
JVC	AV-20ME	65	11		
JVC	AV-21F1EG	12	18	JX	
JVC	AV-21TE/-A/	21	6	MZ2	
JVC	AV-25F1EG	12	18	JX	
JVC	AV-25MEX/-A/	33	13	MZ2	
JVC	AV-28F1EG	12	18	JX	
JVC	AV-29TH3ENS/ENB/ER	2	30	MC	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
JVC	AV-G14T	31	19	CA2	
JVC	AV-G210T	38	16	CA2	
JVC	AV-G21T	12	14	CA2	
JVC	AV-G21TR	30	16	KA	
JVC	AV-G21TT	30	16	KA	
JVC	AV-G250MX	76	11		
JVC	AV-G29MX/-A/	45	12	KA	
JVC	AV-J210T	72	11		
JVC	AV-S25 EE	15	14		
JVC	AV-S250ET	52	12	BY-2	
JVC	AV-S250M	35	19	BY-1	
JVC	AV-S290M	35	19	BY-1	
JVC	C-140MU	35	8		
JVC	C-1480EE/M/EG	62	12	BY-2	
JVC	C-14M1	19	21	KY	
JVC	C-14T1	19	14	KY	
JVC	C-14T1	22	16	KY	
JVC	C-14W/-A/	4	22	CZ	
JVC	C-14Z/-A/	4	22	CZ	
JVC	C-210MU	30	1		
JVC	C-211EE	59	12	BY-2	
JVC	C-2155EM	33	8		
JVC	C-2180M	27	14	BX-2	
JVC	C-21M1(SJ)	24	6		
JVC	C-21T1	29	6		
JVC	C-21Z/-A/	34	6		
JVC	C-21ZE/-A/	24	14	MZ2	
JVC	C-S2181ET/ET(B)	68	12	BY-X	
JVC	CX-60ME	43	12		
KANSAI	14/20	37	15	CTV 1401	
KIM	CK-534Z/PALMX	74	2	P-58SH	RM-101
KIT	37SYCE-5	29	1		
KITT		40	25		
LATAN	LT-1298	93	21		
LATAN	LT-1499	93	21		
LICO	HC53FS-1	38	8		
LOEWE	110Q21	5	28	Q2100	
LUXOR	7128	25	31		
LUXOR	8228	25	31		
LUXOR	9128	25	31		
MINOKA	1493M/2183M	37	8		
MITSUBISHI	CT-21M5E/ET/RT	37	14		
MITSUBISHI	CT-25M5E/EN/ET/ETN/RT/RTN	37	14		
MITSUBISHI	CT-29B3EE	13	26		
NEC	FS-1502K	37	4		
NEC	FS-1530SK/SU	41	4		
NOKIA	6332 VTEE	32	4	EUROMONO	
NOKIA	6364 VTEE	26	27	2B-F	
NOKIA	7164 VTEE	40	8	2B-F	
NOKIA	7291	25	31		
NOKIA	8291	25	31		
NOKIA	9291	25	31		
NOKIA	IDEAL COLOR 3436	73	6	Compact 80 90°	
NOKIA		96	12	STEREO PLUS	
NOKIA		69	6	S4-SQ-110°	
NORDMENDE	6405 IMC/VT SPECTRA STEREO	38	6		
NORDMENDE	6408 IMC/VT SPECTRA STEREO	38	6		
NORDMENDE	GALAXY 55XP	92	23		
NORDMENDE	M 10 KV/VS SPECTRA	92	23		
NORDMENDE	M 63 KV/VS SPECTRA	92	23		



Фирма	Модель	Стр.	Альб.	Шасси	Пульт
NORDMENDE	M 63 VE	97	22	TX 92	
NORDMENDE	M 70 VE	97	22	TX 92	
NORDMENDE	S 63 VT SPECTRA	38	6		
NORDMENDE	S 72 VT SPECTRA	38	6		
NORDMENDE	ST 63 VE	97	22	TX 92	
NORDMENDE	ST 70 VE	97	22	TX 92	
NORDMENDE		84	22	TX 91G	
NORDMENDE		90	22	TX 92	
NOVA	NTV-1020	2	25		
NOVA	NTV-1434MK	40	25		
NOVA	NTV-2005	22	26		
NOVA	NTV-2007	18	28	SW-5500R	
ONWA	K-9515BF	24	7		
ONWA	K-9620BT	26	7		
ONWA	K-9621BF	28	7		
ONYX	2088C/2188C	15	15		
ORCHID		96	21		
ORION	14J	14	23		
ORION	14J	27	26		
ORION	20AR	36	1		
ORION	20AR TXT	50	4		
ORION	20J	32	1		
ORION	4800	43	1		
ORION	COLOR 363	41	1		
ORION	COLOR 3650PC	38	13		
ORION	COLOR 513	20	5		
ORION	COLOR 5130-2RC	18	3		
ORION	COLOR 5150RC	20	5		
ORION	COLOR 520VTP	40	13		
ORION	COLOR 553	20	3		
ORION	COLOR 683DK	24	3		
ORION	COLOR S19DK	46	4		
ORION	T20MS	38	1		
ORION	T20MS	21	7		
ORION	T2190MJ	35	15		
ORION	TV-2050MK5	18	9		
ORION		18	23		
ORION		18	5		
ORSON	1486CK	40	25		
ORTA	CTV-2102	43	13		
OTAKE	5522VT	28	3		
OTAKE	VT-2002 MK9	10	10		
PANASONIC	TC-14B3EE	36	27	M15M	
PANASONIC	TC-14D2	22	30	MX-5	
PANASONIC	TC-14K1R	23	23	Z-7	
PANASONIC	TC-14L1R	46	2	M16S	
PANASONIC	TC-14L3RTE	56	4		
PANASONIC	TC-14S1RCP	118	6	Z-5	
PANASONIC	TC-2125RT	24	9	MX-3	
PANASONIC	TC-2150R/RS	102	6	MX-3C	
PANASONIC	TC-2155R	102	6	MX-3C	
PANASONIC	TC-2160EE	50	1	M14EC	
PANASONIC	TC-2170R	23	10	MX-3	
PANASONIC	TC-2171	24	5		
PANASONIC	TC-2187R	25	18	MX-3S	
PANASONIC	TC-21B4R	59	2	M15M	
PANASONIC	TC-21E1R	37	20	MX-1A	
PANASONIC	TC-21F1	24	9	MX-3	
PANASONIC	TC-21K1R	23	23	Z-7	
PANASONIC	TC-21L100R	22	28	MX-5	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
PANASONIC	TC-21L10R	24	9	MX-3	
PANASONIC	TC-21L1EE	49	8	M16S	
PANASONIC	TC-21L3RTE	56	4		
PANASONIC	TC-21M1RD	109	6	Z-4	
PANASONIC	TC-21S1RCP	116	6	Z-5	
PANASONIC	TC-21S2	43	14	MX-3C	
PANASONIC	TC-21W2	22	28	MX-5	
PANASONIC	TC-21Z2A	33	23	MX-5A	
PANASONIC	TC-25V50R	104	6	MX-2A	
PANASONIC	TC-25V70R	27	10	MX-4	
PANASONIC	TC-25V80R	37	26	MX-4S	
PANASONIC	TC-2990EE	53	27	M15M	
PANASONIC	TC-29GV10R	58	4	M17V	
PANASONIC	TC-29V80R	37	26	MX-4S	
PANASONIC	TC-33A4R	54	1	M15M	
PANASONIC	TC-M21	63	2	M16S	
PANASONIC	TC-M29	30	7	M16MV3	
PANASONIC	TX-14K1T	23	23	Z-7	
PANASONIC	TX-14K2T	31	26	Z-7	
PANASONIC	TX-14S1TCC	39	27	Z-5	
PANASONIC	TX-2170T	23	10	MX-3	
PANASONIC	TX-21F1T	28	9	MX-3	
PANASONIC	TX-21GF10P	70	2	MX-2	
PANASONIC	TX-21K1T	23	23	Z-7	
PANASONIC	TX-21K2T	31	26	Z-7	
PANASONIC	TX-21M1TD	109	6	Z-4	
PANASONIC	TX-21S1TCC	39	27	Z-5	
PANASONIC	TX-21S1TCP	116	6	Z-5	
PANASONIC	TX-21T1EE	33	9	M16S	
PANASONIC	TX-21W2T	22	28	MX-5	
PANASONIC	TX-24W1D	46	1	ALPHA-2W	
PANASONIC	TX-25A3C	29	18	EURO-1	
PANASONIC	TX-25C1CP	37	9	ALPHA-4	
PANASONIC	TX-25S1DR	45	27	EURO-2	
PANASONIC	TX-25S1S	50	27	EURO-2	
PANASONIC	TX-25V70T	27	10	MX-4	
PANASONIC	TX-25V80T	37	26	MX-4S	
PANASONIC	TX-25X1CP	98	3	ALPHA-4	
PANASONIC	TX-25X1CP/BC	106	3	ALPHA-4	
PANASONIC	TX-28C1CP	37	9	ALPHA-4	
PANASONIC	TX-28S1DR	45	27	EURO-2	
PANASONIC	TX-28S1S	50	27	EURO-2	
PANASONIC	TX-28W1D	46	1	ALPHA-2W	
PANASONIC	TX-28X1CP	98	3	ALPHA-4	
PANASONIC	TX-28X1CP/BC	106	3	ALPHA-4	
PANASONIC	TX-29A3C	29	18	EURO-1	
PANASONIC	TX-29GF35T	58	16	M18	
PANASONIC	TX-29GF85T	72	16	M18M	
PANASONIC	TX-29V80T	37	26	MX-4S	
PANASONIC	TX-33GF15P	41	16	M17	
PANASONIC	TX-33GF85T	72	16	M18M	
PANASONIC	TX-33V1EE	53	2	M16M	
PEDCOCK	/экзотика/ made in China	31	14		
PHILIPS	14GR1236/50/52/57/58/59	26	21	GR1-AX	
PHILIPS	14GR1236/65/68/70/75/79R	26	21	GR1-AX	
PHILIPS	14GR1239/50R/59H/65R	26	21	GR1-AX	
PHILIPS	14GX1011	52	6	ANUBIS-S	
PHILIPS	14GX1315	52	6	ANUBIS-S	
PHILIPS	14GX1515	52	6	ANUBIS-S	
PHILIPS	14GX1516	52	6	ANUBIS-S	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
PHILIPS	14GX1517	52	6	ANUBIS-S	
PHILIPS	14GX1715	52	6	ANUBIS-S	
PHILIPS	14GX37A	37	15	CTV 1401	
PHILIPS	14GX8310/50B/67R/75R/94R	53	13	ANUBIS-S	
PHILIPS	14GX8325/67R/94R	53	13	ANUBIS-S	
PHILIPS	14GX8510/52R/54R/58R/54R	53	13	ANUBIS-S	
PHILIPS	14GX8510/59H/71R/77B/87R	53	13	ANUBIS-S	
PHILIPS	14GX8512/50B/50R/57R/59B	53	13	ANUBIS-S	
PHILIPS	14GX8512/59R/59T/62R/67R/74R	53	13	ANUBIS-S	
PHILIPS	14GX8525/71R	53	13	ANUBIS-S	
PHILIPS	14GX8527/50B/74R/87R	53	13	ANUBIS-S	
PHILIPS	14PT118A/50B/67R/94R	39	15	L7.1A	
PHILIPS	14PT121A/05/05W/10	26	21	GR1-AX	
PHILIPS	14PT132A/50B/50R/75R	39	15	L7.1A	
PHILIPS	14PT133A/162R	39	15	L7.1A	
PHILIPS	14PT1342/43	88	16	L6.1	
PHILIPS	14PT134A/58	14	22	ANUBIS A	
PHILIPS	14PT1352/00/01/D5/07/11/39	88	16	L6.1	
PHILIPS	14PT136A/58	14	22	ANUBIS A	
PHILIPS	14PT137A/162R	39	15	L7.1A	
PHILIPS	14PT138A/54R/58M/59T/67R	39	15	L7.1A	
PHILIPS	14PT138A/71R/74R/75R/93S	39	15	L7.1A	
PHILIPS	14PT1542/01/43	88	16	L6.1	
PHILIPS	14PT1552/00/01/05/11	88	16	L6.1	
PHILIPS	20CT6350	75	1		
PHILIPS	20CT6360	90	4		
PHILIPS	20CT6451	75	1		
PHILIPS	20GR1250/07B/08B/15B/30B	26	21	GR1-AX	
PHILIPS	20GR1359/50R/59H/65R/79R	26	21	GR1-AX	
PHILIPS	20GX1355	52	6	ANUBIS-S	
PHILIPS	20GX1555	52	6	ANUBIS-S	
PHILIPS	20GX1556	52	6	ANUBIS-S	
PHILIPS	20GX1557	52	6	ANUBIS-S	
PHILIPS	20GX1558	52	6	ANUBIS-S	
PHILIPS	20GX1755	52	6	ANUBIS-S	
PHILIPS	20GX51A	37	15	CTV 1401	
PHILIPS	20GX8350/50B/67R/75R/94R	53	13	ANUBIS-S	
PHILIPS	20GX8550/52R/54R/58H	53	13	ANUBIS-S	
PHILIPS	20GX8550/58R/59H/59R/71R	53	13	ANUBIS-S	
PHILIPS	20GX8550/73R/77B/87R/97R	53	13	ANUBIS-S	
PHILIPS	20GX8552/50R/57R/59B	53	13	ANUBIS-S	
PHILIPS	20GX8552/59R/59T/67R/74R	53	13	ANUBIS-S	
PHILIPS	20PT120A/78R	39	15	L7.1A	
PHILIPS	20PT132A/75R	39	15	L7.1A	
PHILIPS	20PT133A/62R	39	15	L7.1A	
PHILIPS	20PT1342/43	88	16	L6.1	
PHILIPS	20PT137A/62R	39	15	L7.1A	
PHILIPS	20PT138A/50B/54R/58H/58R/67R	39	15	L7.1A	
PHILIPS	20PT138A/71R/73R/74R/75R/94R/97R	39	15	L7.1A	
PHILIPS	20PT1542/43	88	16	L6.1	
PHILIPS	20PT188A/50B/67R/73R	39	15	L7.1A	
PHILIPS	21CN4462	70	1		
PHILIPS	21CN4672	70	1		
PHILIPS	21GR6761	39	31		
PHILIPS	21GX1556	52	6	ANUBIS-S	
PHILIPS	21GX1765	52	6	ANUBIS-S	
PHILIPS	21GX1875/79R	57	29	Anubis Sbb	
PHILIPS	21GX1972	57	29	Anubis Sbb	
PHILIPS	21GX1975/68R/69Z	57	29	Anubis Sbb	
PHILIPS	21MMTV/57V/69V/75V	31	28	PV4.0.AA	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
PHILIPS	21PT135B	45	13	AA-5	
PHILIPS	21PT136A/58	14	22	ANUBIS A	
PHILIPS	21PT136B	45	13	AA-5	
PHILIPS	21PT1532/58	88	16	L6.1	
PHILIPS	21PT1542/43	88	16	L6.1	
PHILIPS	21PT165	76	12	AA-5	
PHILIPS	21PT166A/58	14	22	ANUBIS A	
PHILIPS	21PT166B	45	13	AA-5	
PHILIPS	21PT231A/67R	31	28	PV4.0.AA	
PHILIPS	21PT233A/71R	31	28	PV4.0.AA	
PHILIPS	21PT238A/50B/56R/57R/58R/59H/59R	31	28	PV4.0.AA	
PHILIPS	21PT23ZA/50B/58R	31	28	PV4.0.AA	
PHILIPS	21PT240A/65R/ 93R/94R	31	28	PV4.0.AA	
PHILIPS	21PT241A/A67R/70R/77R	31	28	PV4.0.AA	
PHILIPS	21PT260A/57R/97V/67R/75R/75V	31	28	PV4.0.AA	
PHILIPS	21PT262/68R/69R/69V/79R/79V	31	28	PV4.0.AA	
PHILIPS	21PT263A/97R	31	28	PV4.0.AA	
PHILIPS	21PT4303/02	41	20	MD1.2E	
PHILIPS	21PT440B/00B/58B	41	20	MD1.2E	
PHILIPS	21PT441B/02B	41	20	MD1.2E	
PHILIPS	21PT4422/01	41	20	MD1.2E	
PHILIPS	21PT442B/01/01B/05B/07B/BB/16B	41	20	MD1.2E	
PHILIPS	24PW6302/00	41	20	MD1.2E	
PHILIPS	24PW6322/01/16	41	20	MD1.2E	
PHILIPS	25GR6771	39	31		
PHILIPS	25GX1885/73R	57	29	Anubis Sbb	
PHILIPS	25GX1886/73/75Z/94R	57	29	Anubis Sbb	
PHILIPS	25PT233A/71R	31	28	PV4.0.AA	
PHILIPS	25PT400/42	40	21	GR 2.2	
PHILIPS	25PT4103/00/01/05/07/11/39/58/58H	68	21	L6.2	
PHILIPS	25PT4323/11	68	21	L6.2	
PHILIPS	25PT4403/43	68	21	L6.2	
PHILIPS	25PT4423/11	68	21	L6.2	
PHILIPS	25PT448A/56R/59B/59H/68R/75R/79R	31	28	PV4.0.AA	
PHILIPS	25PT462A/68R/69R/79R	31	28	PV4.0.AA	
PHILIPS	25PT463A/61R/71R/77R/97R	31	28	PV4.0.AA	
PHILIPS	25PT468A/57R/67R/73R/75R	31	28	PV4.0.AA	
PHILIPS	25PT8302/58	42	23	MD2.11/12/13	
PHILIPS	25PT8303/58	42	23	MD2.11/12/13	
PHILIPS	25PT9001/58R	42	25	GFL2.20E	
PHILIPS	25SX8661/58H/58R/57R/75R/93R	57	27	G8	
PHILIPS	25SX8662/97R	57	27	G8	
PHILIPS	25SX8663/61R	57	27	G8	
PHILIPS	25SX8671/56H/56R/75R/93R	57	27	G8	
PHILIPS	25SX8761/56H/56R/57R/67R	57	27	G8	
PHILIPS	25SX8761/69R/73R/75R/79R	57	27	G8	
PHILIPS	25PT410A/42	40	21	GR 2.2	
PHILIPS	25PT4503/00/15/58/58P	41	20	MD1.2E	
PHILIPS	25PT4513/02	41	20	MD1.2E	
PHILIPS	25PT4523/01/05/07/13/16/58	41	20	MD1.2E	
PHILIPS	25PT5302/58	41	20	MD1.2E	
PHILIPS	25PT5322/58	41	20	MD1.2E	
PHILIPS	25PT5403/00	41	20	MD1.2E	
PHILIPS	25PT5423/16	41	20	MD1.2E	
PHILIPS	25PT6322/05	41	20	MD1.2E	
PHILIPS	27CE4290/02	44	6	2B	
PHILIPS	28GR6781	39	31		
PHILIPS	28PT400A/42	40	21	GR 2.2	
PHILIPS	28PT4102/00	68	21	L6.2	
PHILIPS	28PT4103/00/01/11/39/58/60	68	21	L6.2	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
PHILIPS	28PT4323/11	68	21	L6.2	
PHILIPS	28PT4403/00	68	21	L6.2	
PHILIPS	28PT4423/01/11	68	21	L6.2	
PHILIPS	28PT450A/42	40	21	GR 2.2	
PHILIPS	28PW9521/05	42	25	GFL2.20E	
PHILIPS	28PW9531/25	42	25	GFL2.30E	
PHILIPS	28PW9611/58	42	25	GFL2.30E	
PHILIPS	28PW9631/25	42	25	GFL2.30E	
PHILIPS	28PT4503/43/58/58P	41	20	MD1.2E	
PHILIPS	28PT4513/02	41	20	MD1.2E	
PHILIPS	28PT4523/01/05/13/16/58	41	20	MD1.2E	
PHILIPS	28PT5001/02B	41	20	MD1.2E	
PHILIPS	29GX1893/73R	57	29	Anubis Sbb	
PHILIPS	29GX1896/73R/94K	57	29	Anubis Sbb	
PHILIPS	29PT233A/71R	31	28	PV4.0.AA	
PHILIPS	29PT826C/25	42	25	GFL2.20E	
PHILIPS	29PT828C/25	42	25	GFL2.20E	
PHILIPS	29PT8302/58	42	23	MD2.11/12/13	
PHILIPS	29PT8402/58	42	23	MD2.11/12/13	
PHILIPS	29PT9101/58/58R	42	25	GFL2.20E	
PHILIPS	29PT9111/58/58R	42	25	GFL2.20E	
PHILIPS	29PT9113	41	20	MD1.2E	
PHILIPS	29PT9113/05/12	31	28	PV4.0.AA	
PHILIPS	29PT9113/05/12/19//58/58R	42	25	GFL2.20E	
PHILIPS	29SX8664/78R	57	27	G8	
PHILIPS	29SX8671/56H/56R/57R/67R	57	27	G8	
PHILIPS	29SX8671/69R/73R/75R/79R	57	27	G8	
PHILIPS	29SX8672/97R	57	27	G8	
PHILIPS	29SX8673/61R	57	27	G8	
PHILIPS	29SX8674/54R/78R/85R	57	27	G8	
PHILIPS	29SX8770/90R	57	27	G8	
PHILIPS	29SX8771/56H/56R/57R/67R	57	27	G8	
PHILIPS	29SX8771/69R/73R/75R/79R	57	27	G8	
PHILIPS	32PW6302/00	41	20	MD1.2E	
PHILIPS	32PW6312/00	41	20	MD1.2E	
PHILIPS	32PW6322/01/13/16	41	20	MD1.2E	
PHILIPS	32PW6332/01/16	41	20	MD1.2E	
PHILIPS	32PW9611/58/58R	42	25	GFL2.30E	
PHILIPS	32PW9631/25	42	25	GFL2.30E	
PHILIPS	37TA1232/03	88	16	L6.1	
PHILIPS	37TA1432/03	88	16	L6.1	
PHILIPS	37TA1462/18	88	16	L6.1	
PHILIPS	37TA1473/18	88	16	L6.1	
PHILIPS	52TA4311/03B	41	20	MD1.2E	
PHILIPS	52TB2452/19	88	16	L6.1	
PHILIPS	63TA3913/11/18	68	21	L6.2	
PHILIPS	63TA4013/16	68	21	L6.2	
PHILIPS	63TA4413/08/11/16/18	68	21	L6.2	
PHILIPS	63TB3893/19	68	21	L6.2	
PHILIPS	63TB4394/19	68	21	L6.2	
PHILIPS	70WA9410/03	42	25	GFL2.20E	
PHILIPS	70TA3913/11/18	68	21	L6.2	
PHILIPS	70TA4013/16	68	21	L6.2	
PHILIPS	70TA4413/03/08/11/16/18	68	21	L6.2	
PHILIPS	70TB3893/19	68	21	L6.2	
PHILIPS	70TB4394/19	68	21	L6.2	
PHILIPS	8148	37	15	CTV 1401	
PHILIPS	CTV-2101	75	12		
PHILIPS	CTV-2102	43	13		
PHILIPS	CTV-8202	38	23		

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
PHILIPS	CTV-8212	38	23		
PHILIPS	CTV-8213BR	40	23		
PHILIPS	CTV-8218BK	40	23		
PHILIPS	CTV-8219	43	13		
PHILIPS	K-35	64	1		
PHILIPS	K-9K-11	58	1		
PHILIPS	M2052/00/01	88	16	L6.1	
PHILIPS	M2152/00/07/15	88	16	L6.1	
PHILIPS	M2182/00	88	16	L6.1	
PHILIPS	M2192/05	88	16	L6.1	
PHILIPS	PD5029M	42	25	GFL2.20E	
PHILIPS	PD5029S	42	25	GFL2.20E	
PHILIPS	RC-4020/4021	28	5		
PHILIPS	RC-4029PSH/I/NICAM	42	9		
PHILIPS		82	1		
PHILIPS		31	29	FL1.14/16/17	
PHILIPS		84	29		
PHILIPS		50	31	MD1.1E/AA	
PHILIPS		75	31	GR2.4 AA	
PHILIPS		64	6		
RECOR	RC-4029PSH/I/NICAM	42	9		
ROYAL	510	96	4		
ROYAL	555	125	4		
SABA	IDEAL COLOR 3436	73	6	Compact 80 90°	
SABA	M3709	60	26	FF547	
SABA	M4007	60	26	FF546	
SABA	M4209	60	26	FF521	
SABA	M5107	92	23	ICC6	
SABA	M5109VT	60	26	FF548	
SABA	T6301/FF345	80	6		
SABA	T6308/T6317/T7008/T7017	92	23	ICC6	
SABA		84	22	TX 91G	
SABA		90	22	TX 92	
SABA		97	22	TX 92	
SABA		69	6	S4-SQ-110°	
SAIKO		89	10	C41/C41M	
SALORA	21/24/28K70	56	8		
SALORA	21/24/28K77	56	8		
SALORA	28F8	25	31		
SALORA	32F8	25	31		
SALORA	36F8	25	31		
SALORA		96	12	STEREO PLUS	
SAMSUNG	CK-1438VR5X/VWT	17	30	S15A	
SAMSUNG	CK-1448VR5X/BWT	17	30	S15A	
SAMSUNG	CK-14C8VR5S	17	30	S15A	
SAMSUNG	CK-14E1VR5S	17	30	S15A	
SAMSUNG	CK-14E3VR5X	17	30	S15A	
SAMSUNG	CK-14F1VR5S	17	30	S15A	
SAMSUNG	CK-14F1XR5	17	30	S15A	
SAMSUNG	CK-14H1VR5S/NWT	17	30	S15A	
SAMSUNG	CK-14R1VR5X/BWT	17	30	S15A	
SAMSUNG	CK-2039VR5S	17	30	S15A	
SAMSUNG	CK-2073XR5X/VWT	17	30	S15A	
SAMSUNG	CK-2085VR5S	17	30	S15A	
SAMSUNG	CK-2085VR5X/BWT	17	30	S15A	
SAMSUNG	CK-20C8VR5C	17	30	S15A	
SAMSUNG	CK-20E1VR5C	17	30	S15A	
SAMSUNG	CK-20E3VR5X/NWT	17	30	S15A	
SAMSUNG	CK-20F1R5C	17	30	S15A	
SAMSUNG	CK-2166VR5S/AWT	17	30	S15A	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
SAMSUNG	CK-2173VR5X/BWT	17	30	S15A	
SAMSUNG	CK-2185VR5S/AWT	17	30	S15A	
SAMSUNG	CK-3312Z	79	2	P-58SC(H)	RM-109
SAMSUNG	CK-331EVR5X/NWT	17	30	S15A	
SAMSUNG	CK-331FVR5X/BWT	17	30	S15A	
SAMSUNG	CK-331FVR5X/NWT	17	30	S15A	
SAMSUNG	CK-331FVR5X/VWT	17	30	S15A	
SAMSUNG	CK-3338ZR/BWX	86	12	SCT-11B	
SAMSUNG	CK-3339ZR1/TR1BWX	46	19	SCT-11D	
SAMSUNG	CK-333EXR5X/VWT	17	30	S15A	
SAMSUNG	CK-333EZR4X/BWT	63	20	SCT-13B	
SAMSUNG	CK-3351A	40	7		RM-109
SAMSUNG	CK-3366ZR4X/BWT	63	20	SCT-13B	
SAMSUNG	CK-3373T/ANASX	92	12	P1B	
SAMSUNG	CK-3373ZR/BWX	92	12	P1B	
SAMSUNG	CK-3373ZR4X/BWT	63	20	SCT-13B	
SAMSUNG	CK-3383ZR1BWX	43	10	P69SA-1	RM-135-1
SAMSUNG	CK-3385TR1/ZR1BWX	46	19	SCT-11D	
SAMSUNG	CK-338CVR5X/BWT	17	30	S15A	
SAMSUNG	CK-346ZSE	76	2	P-54S	RM-101
SAMSUNG	CK-5012Z	79	2	P-58SC(H)	RM-109
SAMSUNG	CK-501ETR1X/BWT	46	19	SCT-11D	
SAMSUNG	CK-501EVR5S/NWT	17	30	S15A	
SAMSUNG	CK-501EVR5X/CAL	17	30	S15A	
SAMSUNG	CK-501FVR5S/NWT	17	30	S15A	
SAMSUNG	CK-5020T1HPLCX	46	19	SCT-11D	
SAMSUNG	CK-5020Z1HPLCX	46	19	SCT-11D	
SAMSUNG	CK-5035TR1BWX	43	10	P69SA-1	RM-135-1
SAMSUNG	CK-5035Z/UEISX	40	10	P69SA	RM-135
SAMSUNG	CK-5038T/ANASX	71	8	SCT-11B	
SAMSUNG	CK-5038ZR/BWX	71	8	SCT-11B	
SAMSUNG	CK-5039VR5S/AWT	17	30	S15A	
SAMSUNG	CK-5039ZR1/TBR1/TR1BWX	46	19	SCT-11D	
SAMSUNG	CK-503EZR4X/BWT	63	20	SCT-13B	
SAMSUNG	CK-5051X(T)	83	2	P68SC	RM-109
SAMSUNG	CK-5061ATR/AWX/BWX	40	7	P68SA(AT)	RM-109
SAMSUNG	CK-5062A	40	7		RM-109
SAMSUNG	CK-5066ZR4X/BWT	63	20	SCT-13B	
SAMSUNG	CK-5073T/BOLIX/ANASX	92	12	P1B	
SAMSUNG	CK-5073Z/BOLIX	92	12	P1B	
SAMSUNG	CK-5073ZR/BWX	92	12	P1B	
SAMSUNG	CK-5073ZR1	46	19	SCT-11D	
SAMSUNG	CK-5079ZR1UKCX	46	19	SCT-11D	
SAMSUNG	CK-5083ZR1BWX	43	10	P69SA-1	RM-135-1
SAMSUNG	CK-5085TBR/BWX	92	12	P1B	
SAMSUNG	CK-5085VR5S/AWT	17	30	S15A	
SAMSUNG	CK-5085ZB/BOLIX	92	12	P1B	
SAMSUNG	CK-5085ZR/BWX	92	12	P1B	
SAMSUNG	CK-5085ZR1/ZBR1/TBR1BWX	46	19	SCT-11D	
SAMSUNG	CK-508CVR5S/NWT	17	30	S15A	
SAMSUNG	CK-5314M	38	7	P64SM(H)	RM-107
SAMSUNG	CK-5322X/METX	83	2	P68SC	RM-109
SAMSUNG	CK-5322ZV/NEX	79	2	P-58SC(H)	RM-109
SAMSUNG	CK-5339VR5S/AWT	17	30	S15A	
SAMSUNG	CK-5339ZR/BWX	92	12	P1B	
SAMSUNG	CK-5339ZR1/TBR1/TR1BWX	46	19	SCT-11D	
SAMSUNG	CK-5342AT	40	7		RM-109
SAMSUNG	CK-5361A/TTASX	42	7	P68SA1	RM-109
SAMSUNG	CK-5366ZR4X/BWT	63	20	SCT-13B	
SAMSUNG	CK-5370WB/BWX	71	13	US-60A	RM-119

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
SAMSUNG	CK-5370WTBR/BWX	71	13	US-60A	RM-119
SAMSUNG	CK-5373ZR/BWX	92	12	P1B	
SAMSUNG	CK-5373ZR1	46	19	SCT-11D	
SAMSUNG	CK-5379TR1/ZR1UKCX	46	19	SCT-11D	
SAMSUNG	CK-5385TBR1/ZR1/ZBR1BWX	46	19	SCT-11D	
SAMSUNG	CK-6202WB/WTR	50	14	SCT-12B	
SAMSUNG	CK-6229Z/AMRX	100	2	P72	RM-109B
SAMSUNG	CK-6271	44	7	Z68	RM-131
SAMSUNG	CK-6271WP	65	26	Z70	
SAMSUNG	CK-6330Z (CB, CK, CW)	100	28	P72-1	
SAMSUNG	CK-6813Z/STTX	87	2	S60MT	RM-113
SAMSUNG	CK-7202WB/N/WTR	50	14	SCT-12B	
SAMSUNG	CK-7230Z	92	2	S60MT	RM-113
SAMSUNG	CK-7271	44	7	Z68	RM-131
SAMSUNG	CK-7271WP	65	26	Z70	
SAMSUNG	CS-5062Z	48	9	P68SM(H)	RM-133
SAMSUNG	CS-5342Z	48	9	P68SM(H)	RM-133
SAMSUNG	CS-721APFR/BWX	59	13	SCT-52A	
SAMSUNG	CS-721APTR/BWX	59	13	SCT-52A	
SAMSUNG	CS-7272PTR/BWX	60	8	SCT-51A	
SAMSUNG	CS-7277PF/PT	46	10	SCT-51A	RM-124
SAMSUNG	CS-7830ZP	50	9	Z66P	RM-111
SAMSUNG	CW-3382Z1PN6MCX	55	9	P69SA1	RM-135-1
SAMSUNG	CW-3383Z1M16MX	55	9	P69SA1	RM-135-1
SAMSUNG	CW-5012X	47	14	P64(SMH,SH1)	
SAMSUNG	CW-5082Z1NW6HX	55	9	P69SA1	RM-135-1
SAMSUNG	CW-5082Z1SR6HX	55	9	P69SA1	RM-135-1
SAMSUNG	CW-5082Z1WX	55	9	P69SA1	RM-135-1
SAMSUNG	CW-5082ZB1T06HX	55	9	P69SA1	RM-135-1
SAMSUNG	CW-5083Z1HALCCX	55	9	P69SA1	RM-135-1
SAMSUNG	CW-5322X/K06HX	98	2	P64SA(H)	RM-107
SAMSUNG	CW-6833WT	65	26	Z70	
SAMSUNG	CX-5330AN	71	13	US-60A	RM-119
SAMSUNG	CX-558WT/AMF	24	30	P-88MT(MTTS2)	
SAMSUNG		28	30	P-54HA	
SAMSUNG		95	8		
SANYO	C14EA13EX-00/01	48	7	A7-A	
SANYO	C14EA23-00	57	10	A7-A	
SANYO	C14EL83-00	32	30	A7-A	
SANYO	C14MA14-00	50	7	A7-A	
SANYO	C14MA14A-00	50	7	A7-A	
SANYO	C21EM47-00	79	13	A7-A	
SANYO	C25EG57-00	53	15	AA1-A	
SANYO	C25EG57-00	58	9	AA1-A	
SANYO	CAX 3021A-00	60	9	A3-B	
SANYO	CEM 1454-00	62	14	A3-CA	
SANYO	CEM 1454-00	47	7	A3-CA	
SANYO	CEM 1459SU-00	30	5	A3	
SANYO	CEM 2054-00	77	13	A3-CA	
SANYO	CEM 2130PV-20	86	1		
SANYO	CEM 2140C-00	52	3	A3-C	
SANYO	CEM 2141PTX-10	52	7	A3-B	
SANYO	CEM 2511SU-00	88	1	A2	
SANYO	CEM 2511VSU-00	80	26	A2	
SANYO	CEM 2511VSU-00	32	5	A2	
SANYO	CEM 2515C-05	78	26	A2-C	
SANYO	CEM 2515C-06	54	7	A2-C	
SANYO	CEM 2515VSU-00	80	26	A2	
SANYO	CEM 2515VSU-00	32	5	A2	
SANYO	CEM 3022SU-00	90	1	A3-A	



Фирма	Модель	Стр.	Альб.	Шасси	Пульт
SANYO	CEM 6011VSV-20	59	10	A1	
SANYO	CEP 2147/TX,PS,PSTX/-00	34	5	E2	
SANYO	CEP 3011VPS-40	46	3	A1	
SANYO	CMM 3024/A-00	50	3	A3-A	
SANYO	CMX 2510A-50	48	15	A4-A	
SANYO	CMX 2940CK-00	62	9	A8-A	
SANYO	CMX 3310C-05	54	3	A4-A	
SANYO	CTP 7375-00	59	14	83S-D22	
SCHAUB LORENZ	7128	25	31		
SCHAUB LORENZ	8228	25	31		
SCHAUB LORENZ	9128	25	31		
SCHNEIDER		84	13	TV 5.1	
SELECO	BS 990.0-110°	86	6		
SELECO	PC 010-020-90°	83	6		
SELECO		96	12	STEREO PLUS	
SHARP	14/20/21H-SC	62	10		
SHARP	14B-E	100	4		
SHARP	14BN1/A	89	6	14BM	
SHARP	14BN14	89	6	14BM	
SHARP	14B-SC	116	2		
SHARP	14L-SC	57	15		
SHARP	14N51-E1	86	27		
SHARP	14R2/B/	21	22	SP-70	
SHARP	14R-SC/M8/M10	41	18	SP-70	
SHARP	14R-W	41	18	SP-70	
SHARP	20B-SC	98	1		
SHARP	21BN21	93	6	21B	
SHARP	21B-SC	96	6		
SHARP	21D-CK1	54	8		
SHARP	21FN1	52	8		
SHARP	21JN1	67	10	SP-51	
SHARP	21N52-E1	99	12		
SHARP	21R2/B/	41	18	SP-70	
SHARP	21R-SC	41	18	SP-70	
SHARP	25FN1	47	18	SP-42M	
SHARP	29FN1	47	18	SP-42M	
SHARP	29N21D1	68	14		
SHARP	29N42-E3	40	3		
SHARP	37AM-12SC	30	22	5BS	
SHARP	37AM-23S	48	28	5BS	
SHARP	37AM-24S	48	28	5BS	
SHARP	37DM-23SC	92	27	CA-1	
SHARP	54AM-12SC	86	26	5BS-A	
SHARP	54AT-15SC	84	26	5BS-A	
SHARP	54AT-16SC	84	26	5BS-A	
SHARP	63CS-03SC	89	26		
SHARP	70CS-03SC	89	26		
SHARP	C-2002SC	100	1		
SHARP	C-2091	34	3		
SHARP	C-262SC	95	1		
SHARP	CS54-S2	103	1		
SHARP	CV-1496RU	25	22	L	
SHARP	CV-14RU	41	18	SP-70	
SHARP	CV-2021S/G	82	26		
SHARP	CV-2121S/G	64	14		
SHARP	CV-2131CK1	118	2		
SHARP	CV-2132CK1	36	3		
SHARP	CV-2132CK1	38	3		
SHARP	CV-2152SCN	120	2		
SHARP	CV-2195RU	32	22	H	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
SHARP	CV-3730SC	44	3		
SHARP	DV-1410SPN	89	27		
SHARP	DV-3760S	86	29	4BSA	
SHARP	DV-3765S	86	29	4BSA	
SHARP	DV-3770S	86	29	4BSA	
SHARP	DV-5405G	66	14		
SHARP	DV-5450SC	98	6	S3B	
SHARP	DV-5460SC	34	30	4BSA	
SHARP	DV-5461SC	34	30	4BSA	
SHARP	DV-5462SC	34	30	4BSA	
SHARP	OZ47-2S /CHINA/	88	23		
SHARP	SV-2142S	93	1		
SHARP	SV-2152CK1	102	4		
SHARP	SV-2152U	104	4		
SHARP	TC-271EE	92	1		
SHERION	RC-4020/4021	28	5		
SHIVAKI	STV-101M4	58	18		
SHIVAKI	STV-1414	57	28	DY-300/321/350	
SHIVAKI	STV-1415	59	15	11AK20	
SHIVAKI	STV-142M4	61	18	PC-04A	
SHIVAKI	STV-143M4	53	19		
SHIVAKI	STV-2016	54	28	H-203	
SHIVAKI	STV-2017M4	70	19		
SHIVAKI	STV-202 MK2	100	6		
SHIVAKI	STV-2023	57	28	DY-300/321/350	
SHIVAKI	STV-2024 MULTI	38	23		
SHIVAKI	STV-2026	62	15	11AK19	
SHIVAKI	STV-208 MK2/143/140	100	6		
SHIVAKI	STV-208M4	53	19		
SHIVAKI	STV-2110	57	28	DY-300/321/350	
SHIVAKI	STV-2113	62	15	11AK19	
SHIVAKI	STV-2119	77	21	H-501V	
SHIVAKI	STV-212M4	61	18	PC-04A	
SHIVAKI	STV-213M4	61	18	PC-04A	
SHIVAKI	STV-214M4	57	19		
SHIVAKI	STV-2160	40	23		
SHIVAKI	STV-217MA	37	22		
SHIVAKI	STV-251M4	65	18	PC-12A	
SHIVAKI	STV-280M4 MULTI	61	19	MC-15A	
SHIVAKI	STV-281M4	65	18	PC-12A	
SHIVAKI	STV-2901 MULTI	61	19	MC-15A	
SHIVAKI	STV-2905	81	19		
SHIVAKI	STV-503	68	19		
SHIVAKI		107	4	PC-04X	
SIEMENS	CS 9203	80	5		
SIEMENS	CS 9204	80	5		
SIEMENS	FS 245M6/V6	80	5		
SIEMENS	FS 248M6	80	5		
SIESTA	SB-23-2U/Y	96	21		
SIESTA	SB-31-2U/N	95	21		
SIESTA	TV55-141	90	9		
SIESTA	TV55-252SAT	72	5	ECK-chassis-90	
SIESTA	TV63-142	90	9		
SIESTA	TV67-130	90	9		
SIESTA	TV70-100	88	9		
SIESTA	TV70-111	88	9		
SIESTA	TV70-143	90	9		
SIESTA		94	21		
SIESTA		97	21		
SIGNUM	67-5201/02/03 COLOR 40	76	5		

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
SONY	FD-240BE	96	8		
SONY	KV-1435M3	106	1		RM-827B
SONY	KV-1440ME2A	60	3		
SONY	KV-1442ME2	62	3		
SONY	KV-1484MT	56	7	GP-1A	RM-687C
SONY	KV-1485MT	77	8		RM-827S
SONY	KV-1487	110	2		RM-849S
SONY	KV-14DK1	79	8		RM-849S
SONY	KV-14DK2	110	2		RM-849S
SONY	KV-14GM2	46	22	BG-2S	RM-869
SONY	KV-14M1A/B/E/K/L/U	71	9		RM-836
SONY	KV-14T1A/B/C/D/K/L/R/U	71	9		RM-836
SONY	KV-16WS1A/B/ D/E/U	62	28	BE-5	RM-836
SONY	KV-16WT1/A/K/R/U	130	17	BE-4	RM-836
SONY	KV-16WT1/A/K/R/U	135	17	BE-4	RM-836
SONY	KV-1984MT	40	22	GP-1A	RM-687C
SONY	KV-1984MT	56	7	GP-1A	RM-687C
SONY	KV-1985MT/MTJ	43	22	G-3E	RM-827S
SONY	KV-2102M2	86	19	GP-1S	RM-677C
SONY	KV-2103M3	86	19	GP-1S	RM-677C
SONY	KV-2151	77	3		
SONY	KV-2162M9	44	17	GP-1S	RM-677C
SONY	KV-2162M9	86	19	GP-1S	RM-677C
SONY	KV-2162U	85	11	AE-2	RM-830
SONY	KV-2163E	85	11	AE-2	RM-830
SONY	KV-2167MT	110	2		RM-849S
SONY	KV-2182M9	84	3		RM-677A
SONY	KV-2182MR	82	13	GP-1	RM-656A
SONY	KV-2184MT	92	19	GP-1A	RM-687C
SONY	KV-2184MT	56	7	GP-1A	RM-687C
SONY	KV-2184MT	67	9	GP-1A	RM-687C
SONY	KV-2185MTJ	89	3		RM-827S
SONY	KV-2187MT	110	2		RM-849S
SONY	KV-2192M3	108	1		RM-687B
SONY	KV-2194MT	56	7	GP-1A	RM-687C
SONY	KV-21C4/D/E/K/R	51	22	BE-5	RM-836
SONY	KV-21DK	79	8		RM-849S
SONY	KV-21DK2	110	2		RM-849S
SONY	KV-21M1/A/B/D/K/L/U	56	22	BE-4A	RM-836
SONY	KV-21M3/A/B/D/E/K/U	61	22	BE-4A	RM-836
SONY	KV-21R1/A/D/E	67	15	BE-5	RM-836
SONY	KV-21T1/A/B/D/E/K/L/R/U	56	22	BE-4A	RM-836
SONY	KV-21T3/A/B/D/K/L/R/U	61	22	BE-4A	RM-836
SONY	KV-21VX1MT	78	21	VX/SS-X4	RM-664
SONY	KV-21X1/A/B/D/E/K/L/R/U	71	15	BE-5	RM-836
SONY	KV-21X4/A/B/D/E/K/L/R/U	51	22	BE-5	RM-836
SONY	KV-2264MR	94	25	RX	RM-611
SONY	KV-2552M9	44	17	GP-1S	RM-677C
SONY	KV-2552M9	48	17	GP-1S	RM-677C
SONY	KV-2553MT	80	22	GP-1A	RM-867C
SONY	KV-2565MT/MTY	91	29	GP-1A	RM827S
SONY	KV-2584MT	86	3		RM-687C
SONY	KV-25C5A/B/D/E/K/R	96	19	FE-1	RM-883
SONY	KV-25E1A/B/D/E/K/R	69	18	AE-3	RM-831
SONY	KV-25K1/A/B/D/E/K/R/U	65	22	AE-4A	RM-862
SONY	KV-25M1A/B/D/E/K	76	9	BE-3B	RM-837
SONY	KV-25R1A/D/E/K/R	105	18	BE-5	RM-836
SONY	KV-25T1A/B/D/E/K/L/R/U	76	9	BE-3B	RM-837
SONY	KV-25X1/A/B/D/E/K/L/R/U	120	17	BE-3D	RM-839
SONY	KV-2764MR	95	27	RX	RM-611

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
SONY	KV-27XSTD	84	21	RX-2	RM-635
SONY	KV-28WS3/A/B/D/E/K/U	64	24	AE-3	RM-838
SONY	KV-2900	110	1		RM-679MTP
SONY	KV-2964MT	98	4		RM-687C
SONY	KV-2965MT	91	29	GP-1A	RM827S
SONY	KV-2965MT	80	3		RM-827S
SONY	KV-29C3A/B/D/E/K/R	77	28	AE-4	RM-689
SONY	KV-29C5A/B/D/E/K/R	96	19	FE-1	RM-883
SONY	KV-29E1A/B/D/E/K/R	2	24	AE-3	RM-831
SONY	KV-29F1A/B/D/E/K/R/U	77	15	BE-3D	RM-862
SONY	KV-29F3A/B/D/E/K/R/U	42	30	BE-3D	RM-862
SONY	KV-29FX11A/B/D/E/K/R	28	24	BE-3D	RM-886
SONY	KV-29X1A/B/D/E/K/L/R/U	42	24	BE-3D	RM-839
SONY	KV-29X5A/B/D/E/K/L/R/U	54	24	FE-1	RM-883
SONY	KV-29X5A/B/D/E/K/L/R/U	94	18	FE-1	RM-883
SONY	KV-3400D	110	1		RM-679MTP
SONY	KV-A2531D	104	2	AE-2A	RM-831
SONY	KV-C2171D/K/KR	79	14	BE-3B	RM-833
SONY	KV-C2173E/B	79	14	BE-3B	RM-833
SONY	KV-C2501A/D/K	61	17	BE-3C	RM-833
SONY	KV-C2503B/E	61	17	BE-3C	RM-833
SONY	KV-C2508D/E	61	17	BE-3C	RM-833
SONY	KV-C2509D/E/K	61	17	BE-3C	RM-833
SONY	KV-C2521K	70	20	AE-1B	RM-689
SONY	KV-C27M	50	17	AE-1	RM-673
SONY	KV-C2921K	70	20	AE-1B	RM-689
SONY	KV-E2511D	67	28	AE-1A	RM-689
SONY	KV-E2541D	70	3		RM-831
SONY	KV-E2941D	70	3		RM-831
SONY	KV-E2961A/B/D/K	160	24	AE-2F	RM-831
SONY	KV-E2963E	160	24	AE-2F	RM-831
SONY	KV-G14M1	58	7	BG-1S	RM-870
SONY	KV-G14MD1	58	7	BG-1S	RM-870
SONY	KV-G14P1	58	7	BG-1S	RM-870
SONY	KV-G14P11	58	7	BG-1S	RM-870
SONY	KV-G14Q1	58	7	BG-1S	RM-870
SONY	KV-G14S1	58	7	BG-1S	RM-870
SONY	KV-G21M1	64	7	BG-1S	RM-870
SONY	KV-G21P1	64	7	BG-1S	RM-870
SONY	KV-G21S1	64	7	BG-1S	RM-870
SONY	KV-G21S11	64	7	BG-1S	RM-870
SONY	KV-G25M1	85	9	BG-1S	RM-870
SONY	KV-G25M11	85	9	BG-1S	RM-870
SONY	KV-K21MF1	48	5		RM-845T
SONY	KV-K25MF1	48	5		RM-845P
SONY	KV-K25MF1J	48	5		RM-845P
SONY	KV-K29MF1J	48	5		RM-845P
SONY	KV-M1400K	122	1	BE-2A	RM-841
SONY	KV-M1401KR	122	1	BE-2A	RM-841
SONY	KV-M1431K	81	8	BE-2A	RM-694
SONY	KV-M1440A/B/D/E/K/L/U	68	7	BE-4	RM-836
SONY	KV-M1441A/B/D/E/K/KR/U	68	7	BE-4	RM-836
SONY	KV-M1450A/B/D/E/K/U	81	11	BE-4	RM-836
SONY	KV-M1451A/B/D/E/K/U	81	11	BE-4	RM-836
SONY	KV-M14D	120	1	BE-1	RM-658
SONY	KV-M16D	120	1	BE-1	RM-658
SONY	KV-M19D/TD	120	1	BE-1	RM-658
SONY	KV-M2100K	64	3		RM-841
SONY	KV-M2101K	64	3		RM-841
SONY	KV-M2141	67	3		

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
SONY	KV-M2151KR	74	10	BE-2A	RM-841
SONY	KV-M2155K	71	10	BE-2A	RM-834
SONY	KV-M2170A/B/D/E/K/L/U	72	7	BE-4A	RM-836
SONY	KV-M2171A/B/D/E/K/KR/U	72	7	BE-4A	RM-836
SONY	KV-M2181KR	77	10	BE-4	RM-836
SONY	KV-M2520K	92	24	AE-1C	RM-816
SONY	KV-M2521K	92	24	AE-1C	RM-816
SONY	KV-M2530K	81	10	AE-1C	RM-816
SONY	KV-M2531K	81	10	AE-1C	RM-816
SONY	KV-M2540B/D/E/K	38	5	BE-3B	RM-833
SONY	KV-M2541A/E/K/L/U	38	5	BE-3B	RM-833
SONY	KV-S2921A/B/D/E/U	104	24	AE-2A	RM-842
SONY	KV-S2951KR	70	17	AE-3	RM-831
SONY	KV-S29MH1/JH1	56	5		
SONY	KV-S34MH1/JH1	56	5		
SONY	KV-T21MF1	76	7	BG-1S	RM-870
SONY	KV-T21MN1	76	7	BG-1S	RM-870
SONY	KV-T21MN11	76	7	BG-1S	RM-870
SONY	KV-T25MF1	81	7	BG-1S	RM-870
SONY	KV-X2131K	70	20	AE-1B	RM-689
SONY	KV-X2151K	77	20	AE-1C	RM-816
SONY	KV-X2160B	85	11	AE-2	RM-830
SONY	KV-X2161A/B/D/K	85	11	AE-2	RM-830
SONY	KV-X2161K	92	26	AE-2	RM-830
SONY	KV-X2520M	71	14	AE-1	RM-673
SONY	KV-X2521K	70	20	AE-1B	RM-689
SONY	KV-X2531K	124	1	AE-1C	RM-816
SONY	KV-X2531K	125	24	AE-1B	RM-689
SONY	KV-X2561K	92	26	AE-2	RM-830
SONY	KV-X2581/KR	111	17	BE-3B	RM-833
SONY	KV-X25M	50	17	AE-1	RM-673
SONY	KV-X2900B	135	24	BE-3B	RM-833
SONY	KV-X2901A/D/B/K	135	24	BE-3B	RM-833
SONY	KV-X2902/L/U	135	24	BE-3B	RM-833
SONY	KV-X2903E	135	24	BE-3B	RM-833
SONY	KV-X2931K	124	1	AE-1C	RM-816
SONY	KV-X2960/B	143	24	AE-2	RM-830
SONY	KV-X2961A/B/D/K	143	24	AE-2	RM-830
SONY	KV-X2961K	92	26	AE-2	RM-830
SONY	KV-X2962U	143	24	AE-2	RM-830
SONY	KV-X2963E	143	24	AE-2	RM-830
SONY	KV-X2971A/B/D/K	95	17	AE-2B	RM-831
SONY	KV-X2972/U	95	17	AE-2B	RM-831
SONY	KV-X2973/E	95	17	AE-2B	RM-831
SONY	KV-X2981/KR	111	17	BE-3B	RM-833
STANDART		98	8		
STASSFURT	67 5202/03	84	23		
SUPERSTAR		88	21		
SUPRA	STV-1452FS	89	20	C-500	
SUPRA	STV-1454	89	10	C41/C41M	
SUPRA	STV-1454DK	2	5		
SUPRA	STV-1495W	93	9	MC-34A	
SUPRA	STV-2026W	94	28	C-51 (daewoo)	
SUPRA	STV-2052FS	89	20	C-500	
SUPRA	STV-2054	89	10	C41/C41M	
SUPRA	STV-2054DK	2	5		
SUPRA	STV-2064	92	20	P54SA	
SUPRA	STV-2072	92	20	P54SA	
SUPRA	STV-2074	84	7	P54SC	
SUPRA	STV-2084DK	83	8	PC-04A	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
SUPRA	STV-2085	18	7	MC-41B	
SUPRA	STV-2094	102	12	P64SA	
SUPRA	STV-2095W	93	9	MC-34A	
SUPRA	STV-2110MS	92	7	Z66	
SUPRA	STV-2152FS	89	20	C-500	
SUPRA	STV-2500MX	86	7	Z56	
SUPRA	STV-2620MS	100	28	P72-1	
SUPRA	STV-2900X	88	7	S60MT	
SUPRA	STV-2924MS	92	3	MC-15A	
TAMASHI	CTV 14"/20"/21"	106	23		
TEC	5173VR-M	89	10	C41/C41M	
TELEFUNKEN	36431T	88	15	ICC4"14"	
TELEFUNKEN	36M807	88	15	ICC4"14"	
TELEFUNKEN	36MK18/MT19/MK10X	84	8	TX 91	
TELEFUNKEN	36MPS41	88	15	ICC4"14"	
TELEFUNKEN	51MT11/X	84	8	TX 91	
TELEFUNKEN	7137 MULTI OSD	88	15	ICC4"14"	
TELEFUNKEN	F 430	90	22	TX 92	
TELEFUNKEN	F 522 T	97	22	TX 92	
TELEFUNKEN	F 530	90	22	TX 92	
TELEFUNKEN	FS 433 NIC/RXNIC	97	22	TX 92	
TELEFUNKEN	GALAXY 36K/KV	84	8	TX 91	
TELEFUNKEN	GALAXY 40KV	84	8	TX 91	
TELEFUNKEN	MP 204C	92	23	ICC6	
TELEFUNKEN	MP 254C	92	23	ICC6	
TELEFUNKEN	MP 284C	92	23	ICC6	
TELEFUNKEN	MS 254T/TR	97	22	TX 92	
TELEFUNKEN	MS 284T/TR	97	22	TX 92	
TELEFUNKEN	PAL COLOR A125M/MT	84	8	TX 91	
TELEFUNKEN	PAL COLOR A135M/MT	84	8	TX 91	
TELEFUNKEN	SERVICE	131	1	318A	
TELEFUNKEN		96	16	ICC9	
TELEFUNKEN		95	29	418A-BG,L,D,K	
TELEFUNKEN		110	4	418A	
TELEFUNKEN		96	7	318B	
TEMP		89	14		
TENSAI	model 524	89	10	C41/C41M	
THAKRAL	T2190MJ	35	15		
THOMSON	14 MG 77C	84	22	TX 91G	
THOMSON	20 MG 77C	84	22	TX 91G	
THOMSON	21 MG 77C/CX	84	22	TX 91G	
THOMSON	21MT21E	98	25	ICC17	
THOMSON	25DG16E	98	25	ICC17	
THOMSON	25DG21E	98	25	ICC17	
THOMSON	28DG21E	98	25	ICC17	
THOMSON	29DU21E	98	25	ICC17	
THOMSON	51 ML 14	92	23	ICC6	
THOMSON	51 ML 15	92	23	ICC6	
THOMSON	63 DC 68	104	16	ICC9	
THOMSON	63 DE 48N	97	22	TX 92	
THOMSON	63 DE 48X	90	22	TX 92	
THOMSON	63 DK 58N/NY	97	22	TX 92	
THOMSON	63 MN 32/N/P1P	109	5	ICC5	
THOMSON	63 MS 32	97	22	TX 92	
THOMSON	70 DE 32VT	97	22	TX 92	
THOMSON	70 DK 58N/NY	97	22	TX 92	
THOMSON	70 MS 30	92	23	ICC6	
THOMSON	72 DN 31/N/E/S	109	5	ICC5	
THOMSON	72 MN 32/E/N/D2M	109	5	ICC5	
THOMSON	P63 MS 30	92	23	ICC6	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
THOMSON		92	10	ICC7(14)	
THOMSON		90	22	TX 92	
THOMSON		99	29	TX807	
THOMSON		96	31	ICC19-2H	
THOMSON		96	7	TX 90	
TIASHAN		96	9		
TOSHIBA	1413XC	115	3		
TOSHIBA	1450XN/XNE	102	7		
TOSHIBA	1458XNH	102	7		
TOSHIBA	1460TE/TLA/TM/XS/	90	13		
TOSHIBA	1460XN/XSC/XNE/XM/RE	90	13		
TOSHIBA	1652RE/TE	90	13		
TOSHIBA	199X4M	96	5		
TOSHIBA	2013XC	118	3		
TOSHIBA	2035XC	121	3		
TOSHIBA	2050XN	102	7		
TOSHIBA	2065XR	55	30		
TOSHIBA	2104XC	112	3		
TOSHIBA	2125XH	103	9		
TOSHIBA	2135XC	121	3		
TOSHIBA	2140TS	97	15	C4E	
TOSHIBA	2150XH/XHE	104	7		
TOSHIBA	2150XHC	104	7		
TOSHIBA	2150XS	104	7		
TOSHIBA	215R8W	106	5		
TOSHIBA	2160/RE/XSC/XMJ/TMJ	90	13		
TOSHIBA	2160XN/XNE/XM/TE/TM	90	13		
TOSHIBA	2162TR	87	13	C4E-R	
TOSHIBA	2165XR	90	13		
TOSHIBA	2185XR	59	30		
TOSHIBA	218D7S	93	15		
TOSHIBA	218X8M	98	9		
TOSHIBA	218X9M	100	9		
TOSHIBA	2806XH/XHE	64	30		
TOSHIBA	285D8D	102	5		
TOSHIBA	2863DR	94	13	C6SR	
TOSHIBA	289X6M2	100	26		
TOSHIBA	2929DD	97	20		
TOSHIBA	32W3DXR	69	30		
TV COLOR	5140PS	4	8		
TVT	25152/28162	1	12		
TVT	2594/2894	124	3		
VESTEL	MULTIVISION 5530/6330	120	5		
WALTHAM	TS 3341	136	1		
WALTHAM	TS 3341/TXT	116	4		
WALTHAM	TS 3342	116	4		
WALTHAM	TS 3343	116	4		
WALTHAM	TS 3350	89	8		
WALTHAM	TS 3625PSN	119	4		
WALTHAM	TS 3659PSN	119	4		
WALTHAM	TS 4351	99	27		
WALTHAM	TS 4352	121	4		
WALTHAM	TS 5355	121	4		
WALTHAM	TS 5356	107	31		
WALTHAM	TS 6354	121	4		
WALTHAM	TS 6355	107	31		
WALTHAM	TS 8351	107	31		
WALTHAM		134	1		
	???	90	21		
	DCT-1405S	57	28	DY-300/321/350	

Фирма	Модель	Стр.	Альб.	Шасси	Пульт
	DCT-1455S	57	28	DY-300/321/350	
	DCT-1465S	57	28	DY-300/321/350	
	DCT-1475S	57	28	DY-300/321/350	
	DCT-1485S	57	28	DY-300/321/350	
	DCT-1495S	57	28	DY-300/321/350	
	DCT-2005S	57	28	DY-300/321/350	
	DCT-2055S	57	28	DY-300/321/350	
	DCT-2065S	57	28	DY-300/321/350	
	DCT-2075S	57	28	DY-300/321/350	
	DCT-2085S	57	28	DY-300/321/350	
	DCT-2095S	57	28	DY-300/321/350	
	DCT-8210S	57	28	DY-300/321/350	
	DCT-8215S	57	28	DY-300/321/350	
	GD-889	94	8		
	Made in China	98	21		
	Made in China	99	21		
	Made in China	100	21		
	Made in China	9	21		
	S717	101	21		
	STV-3755	104	28	11AKO8	
	STV5186	88	30	11AK10	
	STV5565	90	30	11AK10-14	
	STV6392	82	30	11AK12/12-4	
	SW5101R(PSBDNN)	22	26		