

MAKE	MODEL	CHASSIS/EQUIVALENT	COMMENTS	COMMENTS	COMMENTS	COMMENTS			
Aiwa	TV14MT11		2004, £90-£110						
Aiwa	TV21MT11		2004, £165						
Aiwa	TVF21TS1U	Sony BX1 chassis							
Aiwa	TVSE1430K	Daewoo CP385	2003, £199	remote RMZ5200					
Aiwa	TVSE2130K	Daewoo CP385							
Aiwa	VX14MW1U	CP082S (Daewoo CP082)	2003						
Aiwa	VX21MW1U	CP082S (Daewoo CP082)	2003						
Aiwa	VXD1420K	combi Orion chassis, deck OVD-6S	PCB marked TM9423A, video VM9171B	Micro OEC0085B, option codes	LOPTr Q406 2SD2599				
Aiwa	VXD1450K	combi Orion chassis, deck OVD-7							
Aiwa	VXD2120K	combi Orion chassis, deck OVD-6S	PCB marked TM9450A, video VM9171B	Micro OEC0085B, option codes in	EEPROM address 100H				
Aiwa	VXD2121K	combi Orion chassis, deck OVD-6S	PCB marked TMA523A, video VMA239A	Micro OEC0113B					
Aiwa	VXD2150K	combi Orion chassis, deck OVD-7	PCB marked TMA523A, video VMA239A	Micro OEC0113B					
Aiwa	VXF2121K	combi Orion chassis, deck OVD-6S	PCB marked TMX477A, video VMX199A	Micro OEC0096A					
Aiwa	VXG140K	combi Orion chassis, deck OVD-5	PCB marked TM7379, video VM7125	Micro OEC6044D					
Aiwa	VXG142K	combi Orion chassis, deck OVD-5A	PCB marked TM7379B, video VM7125	Micro OEC6044D					
Aiwa	VXG143K	combi Orion chassis, deck OVD-6	PCB marked TM9423A, video VM9162D	Micro OEC0078C, option codes	EEPROM address 100H				
Aiwa	VXG143KAL (has "A" circle)	combi Orion chassis, deck OVD-6S	PCB marked TMX473A, video VMX193B	Micro OEC0093B					
Aiwa	VXG145K	combi Orion chassis, deck OVD-7	main PCB VMA230A, PSU PCB VPA150A	Micro OEC0107B, option codes	EEPROM address 0B4h (0B4->0B4h)				
Aiwa	VX11410K	combi Orion chassis, deck OVD-4A		Micro OEC6018					
Aiwa	VX11420K	combi Orion chassis, deck OVD-4A	PCB marked TM4316, video VM4079	Micro OEC6025A					
Aiwa	VX1145K	combi Orion chassis, deck OVD-5	PCB marked TM8395A, video VM7125D	Micro OEC6044D					
Aiwa	VX1147K	combi Orion chassis, deck OVD-5A	PCB marked TM8395B, video VM7125	Micro OEC6044D	PSU IC501 STRF6653				
Aiwa	VX11480K	combi Orion chassis, deck OVD-5	PCB marked TM7379A, video VM7125A	Micro OEC6044A					
Aiwa	VX1149K	combi Orion chassis, deck OVD-6	PCB marked TM9423A, video VM9162D	Micro OEC0078C, option codes	EEPROM address 100H				
Aiwa	VX1149KAL (has "A" circle)	combi Orion chassis, deck OVD-6S	PCB marked TMX473A, video VMX193B	Micro OEC0093B					
Aiwa	VX12010K	combi, deck TN5900	1992						
Aikai	CT1417	Onwa							
Aikai	CT2115UK	Samsung P58SC							
Aikai	CT2125	Samsung P58SC							
Aikai	CT2137	Akai CT2157							
Aikai	CT2157	Akai CT2137							
Aikai	CT2158	Sanyo E4-A21							
Aikai	CT2159U	Onwa							
Aikai	CT2161	Stereo plus							
Aikai	CT2162UNT	Onwa							
Aikai	CT2185	Sanyo A5-A21							
Aikai	CT2565	Stereo plus							
Aikai	CT2567	Stereo plus	Goodmans 285DPL						
Aikai	CT2570	Compact D2	ITT						
Aikai	CT2579N	Nokia Compact D-E							
Aikai	CT2585N	Eurostereo2							
Aikai	CT2820	Compact D2	ITT						
Aikai	CT2862UNT	Onwa K9228							
Aikai	CT2865	Stereo plus							
Aikai	CT2867	Stereo plus							
Aikai	CT2870N	Nokia Compact D2-E							
Aikai	CT2879N	Nokia Compac D-E							
Aikai	CT2885N	Eurostereo2							
Aikai	MP237H1 (MP2 37 H1)	Mono Plus 2 (MP2)	=TV1420UK						
Aikai	MZ82R1	Nokia/Salora/Luxor MZ-chassis							
Aikai	SN63B6	Stereo Plus-2, same as TV2551TN	Nokia TV2881T						
Aikai	SN71B6	Stereo Plus-2, same as TV2851TN	Nokia TV2881T						
Aikai	SW72B2	Stereo Plus-2, same as TV2881T	Nokia TV2881T						
Aikai	TV2551TN	Stereo Plus-2 (SN/SW chassis)	Nokia TV2881T						
Aikai	TV2835T	Schneider TV9.7							
Aikai	TV2851TN	Stereo Plus-2 (SN/SW chassis)	Nokia TV2881T						
Aikai	TV2852TN	Stereo Plus-2 (SN/SW chassis)	Nokia TV2881T						
Aikai	TV2881T	Stereo Plus-2 (SN/SW chassis)	Nokia TV2881T						
Aikai	TV2891T	Nokia/Salora/Luxor MZ-chassis							
Aikai	TV3291T	Nokia/Salora/Luxor MZ-chassis							
Aikai	WSP28NTFSFDGB	PT92 +DVD							
Aikai	WSP32NTFSFDGB(S)	PT92 +DVD							
Aikai	TV1420UK (TV1420TUK)	Mono Plus 2 (MP2)	remote RCN622						
Aikai	TV1421(T)	Mono Plus 2 (MP2)							
Aikai	TV2020(T)UK	Mono Plus 2 (MP2)							
Aikai	TV2021(T)	Mono Plus 2 (MP2)							
Aikai	TV2120(T)	Mono Plus 2 (MP2)							
Aikai	TV2121(T)	Mono Plus 2 (MP2)							
Akashi	1450	Elron EC142							
Akura	ATPTV028FT	PT92 ??							
Akura	ATPTV028WSS	PT92							
Akura	AVTV028WSS	PT92 or 11AK19Pro							
Akura	CX10	Boots CTV10R	Alba CTV10						
Akura	CX10	Nikkai Baby 10	Tourer						
Akura	CX10	Osaki P10R	Thorn P10R						
Akura	CX10	Samsung C1210R							
Akura	CX12	Thorn P14BT							
Akura	CX1400T	CX26							
Akura	CX1400T	Minoka MK 1495T							
Akura	CX18	Thorn P146R							
Akura	CX24								
Akura	CX25								
Akura	CX26	Digital Chassis							
Akura	CX30								
Akura	CX32	Thorn CT51R							
Akura	CX33	Thorn CT51T							
Akura	CX35								
Akura	CX4	Osaki P142	Thorn P142						
Alba	CS1919	Rank A823							
Alba	CTV10	Nikkai Baby 10							
Alba	CTV100	Matsui 1436	Bush 2004						
Alba	CTV1400	Harwood HTV3604R							
Alba	CTV14R	Nikkai TLG14R							
Alba	CTV3309	11AK20M-6	1999-	AK20 prod.code 10000107					
Alba	CTV3359	11AK20M-6	1999-	AK20 prod.code: 10000813	remote 930				
Alba	CTV3409	11AK08-13/14 or 11AK20M-3	11AK20 after 1999	AK20 prod.code 10000112					
Alba	CTV3410	Bush 2007 2033T 2167NTX 2169NTX							
Alba	CTV3411	Orion chassis	PCB marked TMX466B	LOPTr Q401 2SD2599	remote 076R0DG040				
Alba	CTV3418	11AK20M-6	1999, remote 930	AK20 prod.code 10000114					
Alba	CTV3418BLK	11AK36	remote 1940						
Alba	CTV3419SIL	11AK36	remote 1940						
Alba	CTV3451TXT	Orion chassis	PCB marked TMA504A	Micro OECF001A					
Alba	CTV3455	CTV841							
Alba	CTV3458	Bush 2007 2033T 2167NTX 2169NTX							
Alba	CTV3459	11AK08 or 11AK20M-6	11AK20 after 1999	AK20 prod.code 10000113					
Alba	CTV3469	11AK20 or 11AK36	chassis depends on the year						
Alba	CTV3481	Orion chassis	Micro PCJ195C30ECF009A (OECF009A)	Remote 076N0GE030					
Alba	CTV4805	Matsui 1455	Onwa						
Alba	CTV4808	11AK19E3							
Alba	CTV4809	11AK10(older) or 11AK19-5, 11AK19-8A, 11AK19E3 (after 1997)		AK19 prod.code: 10000233					
Alba	CTV4851	11AK19							
Alba	CTV4855	Onwa							
Alba	CTV4856	11AK10							
Alba	CTV4858SIL	11AK19E3 or 11AK30(2002-2003)	chassis depends on the year	11AK30 - 10014185					
Alba	CTV4859	11AK19-8A	1999-	AK19 prod.code: 10000234					
Alba	CTV4861SIL	Beko 12.7 chassis, PCB marked G70.190-10							
Alba	CTV4866	NEW ONWA (Bush 2060NTX)	1997	Micro C69609Y, PSU IC STRS6309					
Alba	CTV4869	11AK10-15, 11AK19-8A	AK19 after 1999	AK19 prod.code: 10000971					
Alba	CTV501	Onwa							
Alba	CTV5105SIL	Beko 12.7 chassis, PCB marked G70.190-03	2003, £100	LOPTr 058.013-TR7, 1142.1816, 003071095; equiv. HR8484, FBT40962					
Alba	CTV5109SIL	11AK30-2, 11AK30A4	2002-2003	AK30 prod.code: 10014183					
Alba	CTV5165SIL	Beko 12.7 chassis							
Alba	CTV5984	11AK19E3							
Alba	CTV6682	11AK12							
Alba	CTV6682A	11AK19							
Alba	CTV6688	11AK19 or 11AK37-8	11AK37 after 2002						
Alba	CTV701	Onwa							
Alba	CTV703	Alba CTV703 CTV704T CTV713	Bush 2020T 2021 2021T	Hinari HIT51T					
Alba	CTV704	Indiana 100	NEI						
Alba	CTV704T	Alba CTV703 CTV704T CTV713	Bush 2020T 2021 2021T	Hinari HIT51T					
Alba	CTV711	Indiana 100							
Alba	CTV712	Indiana 100	NEI						
Alba	CTV713	Alba CTV703 CTV704T CTV713	Bush 2020T 2021 2021T	Hinari HIT51T					
Alba	CTV741	Indiana 100	NEI						
Alba	CTV742	Indiana 100	NEI						
Alba	CTV743	C-43 (Bush 2914)							
Alba	CTV744	Indiana 100	NEI						
Alba	CTV747	Orion 14A chassis							

Alba	CTV748	Orion 14A chassis	PCB marked TM0157M, Micro OEC8034	Scan coils YS-60275K					
Alba	CTV752	Indiana 200	NEI						
Alba	CTV840	Onwa	also Bush 1402, Hinary HIT140RC	Goodmans 1404, 1404A					
Alba	CTV841	also Bush 1452T, Goodmans 147TT							
Alba	CTV841	Bush 2114							
Alba	PTV9C	Goodmans Q9001							
Alba	PTV9C	Samsung BT110							
Alba	T1114	Ferguson 3840							
Alba	T14	Bush 2007 2033T 2167NTX 2169NTX							
Alba	VTV10	Orion chassis (Bush BTV10)							
Amstrad	CTV1400	(new) = Crown CTF14R							
Amstrad	CTV1401	Orion 14PS	Saisho CT1400/Matsui 1410						
Amstrad	CTV1409	Orion 14PR	Saisho CT14R						
Amstrad	CTV1409	Triumph CTV8208							
Amstrad	CTV1410	Orion 14LR chassis	Alba CTV840						
Amstrad	CTV1600	Triumph CTV8205							
Amstrad	CTV20T	similar to CTV1400							
Amstrad	CTV2110	Onwa							
Amstrad	CTV280	Bush 2857							
Amstrad	CTV3014F	PT111 chassis							
Amstrad	CTV3021N	PT111 chassis	1998	Micro CTV352/V1.4					
Amstrad	CTV3021NF	SM1 chassis	1998	Micro CTV352/V1.4					
Amstrad	CTV3028N	SM1 chassis		Micro CTV352/V1.4					
Amstrad	CTV3121N	PT111 chassis							
Amstrad	CTV3128N	SM2 chassis							
Amstrad	CTV3228NF	SM2 chassis	1999						
Amstrad	CTV3321NF	PT92 chassis							
Amstrad	STV20		with sat Rx						
Amstrad	TVR1	Funai							
Amstrad	TVR2	Funai							
Amstrad	TVR3	Funai							
Amstrad	WSTV7328N	11AK19P							
Argaro	1401	Fidelity ZX2000							
Autovox	CTR2282GB	Series 1							
Autovox	CTR2283GB	Series 1							
Autovox	CTR2682GB	Series 1							
Autovox	CTR2683GB	Series 1							
B & O	3000	20AX							
B & O	3140	MX3000							
B & O	3141	MX3000							
B & O	3142	MX3000							
B & O	3143	MX3000							
B & O	3144	MX3000							
B & O	3145	MX3000							
B & O	3146	MX3000							
B & O	3147	MX3000							
B & O	3263	Made 1989							
B & O	3300	20AX							
B & O	3502	20AX							
B & O	3602	20AX							
B & O	3702	20AX							
B & O	3703	LX2800							
B & O	3705	LX2800							
B & O	3707	LX2800							
B & O	3712	LX2800							
B & O	3713	LX2800							
B & O	3714	LX2800							
B & O	3715	LX2800							
B & O	3718	LX2800							
B & O	3720	LX2800							
B & O	3741	LX2500							
B & O	3742	LX2500							
B & O	3743	LX2500							
B & O	3745	LX2500							
B & O	3747	LX2500							
B & O	3752	LX2500							
B & O	3753	LX2500							
B & O	3754	LX2500							
B & O	3755	LX2500							
B & O	3758	LX2500							
B & O	3760	LX2500							
B & O	3800	20AX							
B & O	3802	20AX							
B & O	3900	20AX							
B & O	3923	LX4500							
B & O	4002	20AX							
B & O	4402	20AX							
B & O	5000	39XX							
B & O	5102	77XX							
B & O	6000	39XX							
B & O	6002	20AX							
B & O	7702	7XXX							
B & O	8102	71XX							
B & O	9000	33XX							
B & O	311x	MX2000							
B & O	7433	7702							
B & O	L2500	37XX							
B & O	L2502	38XX							
B & O	L2800	37XX							
B & O	L2802	38XX							
B & O	LX2500	37XX							
B & O	LX2502	38XX							
B & O	LX2800	37XX							
B & O	LX2802	38XX							
B & O	M20	31XX							
B & O	MX1500	78XX							
B & O	MX2000	31XX							
B & O	MX3000	314X							
B & O	MX5500	326X							
Baird	6170	Ferguson TX90							
Baird	6171	Ferguson TX90							
Baird	8233	Ferguson TX10							
Baird	RR5188	Tatung 1790							
Baird	RR5190	Sanyo E4-A21							
Baird	RR5191N	ICC7							
Baird	RR5988	Tatung 180							
Baird	RR5990	Sanyo E4-A25							
Baird	RR5991N	ICC5 IMC							
Baird	RR6890N	Sanyo ED1-2B							
Baird	RR6891	ICC5 IMC							
Beko	10214	10.2 (AT2)							
Beko	11214T	10.2 (AT2)							
Beko	11221T	10.2 (AT2)							
Beko	11225(T)	10.2 (AT2)							
Beko	12220(T) (NX)	10.2 (AT2)							
Beko	14212T (R)	12,1							
Beko	14213T (R)	12,1							
Beko	14242-8TDS	12,8							
Beko	14242T (R)	12,4	PCB marked A99.190-16						
Beko	14272TDS	12,7	2003 E70, 2004 E65	PCB marked G70.190-03					
Beko	15225 (T) (NX)	10.2 (AT2)							
Beko	15325(NX)(T)	10.3 (AT3)							
Beko	16228 (T) (NX)	10.2 (AT2)							
Beko	16328(NX)	10.3 (AT3)							
Beko	17125(NX)(T)	11,1							
Beko	17325(T)(R)	10.3 (AT3)							
Beko	18221 (T) (NX)	10.2 (AT2)							
Beko	19221	10.2 (AT2)							
Beko	19321(NX)(T)	10.3 (AT3)							
Beko	19421(T)	10.4 (AT4)							
Beko	20120NX	11,1							
Beko	20212R (T)	12,1							
Beko	20242-8R	12,8							
Beko	20242T (R)	12,4							
Beko	20272TDS	12,7	PCB marked G70.190-03						
Beko	20320(NX)(T)	10.3 (AT3)							
Beko	20420(T)	10.4 (AT4)							
Beko	21211T	12,1							
Beko	21241T(RD)	12,4							

Beko	21411(ND)	14,1							
Beko	24242TS	12,5							
Beko	25121(T)	11,1							
Beko	25411ND	14,1							
Beko	25421(R)(T)	10.4 (AT4)							
Beko	26114(R) (T)	11,1							
Beko	26414(R)(T)	10.4 (AT4)							
Beko	27120	11,1							
Beko	27420(A)(R)	10.4 (AT4)							
Beko	28128(NX)(T)	11,1							
Beko	28328(NX)(T)	10.3 (AT3)							
Beko	28411(ND)	14,1	PCB 7SZ.190-09						
Beko	28412(VND)	14,1							
Beko	28416(ND)	14,1	PCB marked 7SZ.190-16 or 7SZ.190-19	IC601 MC44608P40, fet 2SK25	LOPTx Termal 058.834-TR2	(003311167, HR8700),	chopper 059.834-EL1(2354.0029),		
Beko	28421(NDS)	14,2							
Beko	284216(WNS)	14,2							
Beko	28422(NDS)	14,2	PCB marked U99.190						
Beko	284248(WNS)	14,2							
Beko	28426(NDS)(ND)	14,2							
Beko	29121(NX)	11,1							
Beko	29321(NX)	10.3 (AT3)							
Beko	30128(NX)(T)	11,1							
Beko	30128T	11,1							
Beko	30328(NX)(T)	10.3 (AT3)							
Beko	31114	11,1							
Beko	31414	10.4 (AT4)							
Beko	32120(R)(T)	11,1							
Beko	32420(R))	10.4 (AT4)							
Beko	32426(NDS)(ND)	14,2							
Beko	34133ND	11,1							
Beko	35228PD	11,2							
Beko	36233PD	11,2	PCB marked 6SZ.190-11						
Beko	38328NX	10.3 (AT3)							
Binatone	*01/9014"	Boots CTV1414R							
Binatone	*01/9014"	Dansai CTV1477							
Binatone	*01/9014"	Matsui 1450, 1455							
Binatone	*01/9014"	Saisho CTV147R							
Black Diamond	BD14T	11AK20S							
Black Diamond	BD20T	11AK19-8A, 11AK19P4	1999-2000-2001-					AK19 prod.code: 10000173	
Black Diamond	BD21L	11AK19-8A	1999-					AK19 prod.code: 10001034	
Black Diamond	BD21S	11AK19-8A	1999-					AK19 prod.code: 10000303	
Black Diamond	BD21T	11AK19-8A	1999-					AK19 prod.code: 10000302	
Black Diamond	BD3251WD	11AK33							
Black Diamond	BD32WS	11AK19P4							
Black Diamond	BD3251WS	11AK19P5							
Black Diamond	BDS1451UK	11AK20SE or 11AK36							
Black Diamond	BDS2051T	11AK30-A4							
Black Diamond	BDS2151S	11AK30							
Black Diamond	BDS21S	11AK19-8A	1999-					AK19 prod.code: 10000304	
Black Diamond	BDS2851WD	11AK19P, 11AK33J2(2001), 11AK33J3(2002), 1	2000-2004						
Black Diamond	BDS28WS	11AK19P4	(R629=27R)						
Black Diamond	BD29S	11AK19P							
Black Diamond	BDS29S	11AK19P4							
Black Diamond	BDS3251WS	11AK19P5							
Black Diamond	BDS32S	11AK19Pro							
Black Diamond	BDS32WS	11AK19Pro							
Black Diamond	MD2850PFS	11AK33J3	2002-2003					10014196	
Black Diamond	MD3250PFS	11AK33J4							
Glaupunkt	Milano IL32	FM100							
Boots	CTV10R	Akura CX10							
Boots	CTV10R	Nikkai Baby 10							
Boots	CTV1410	Decca 160							
Boots	CTV1411R	Decca 190							
Boots	CTV1412R	Decca 190							
Boots	CTV1414R	Matsui 1450 / Saisho CT147R							
Boots	TV14	Thorn 1690/1691							
Britannia	B10114S	Fidelity ZX4000							
Britannia	B1014R	Fidelity ZX4000							
Britannia	B14M11	Fidelity C14R06							
Bush	1400	Alba CTV1300	Alba CTV1400					Harwood HTV3604R	
Bush	1402	Orion 14LR chassis	Alba CTV840, Hinary HIT140RC					Goodmans 1404, 1404A	
Bush	1407	Orion 14LR chassis	Alba CTV840						
Bush	1427T	Alba CTV841							
Bush	1430	Sanyo EC2-B14							
Bush	1431	Grundig G1000							
Bush	1432	Grundig G1000							
Bush	1433 (10000108)	11AK08 (remote 900) or 11AK20 (remote 930)	depends on the year, AK20 after 1999					AK20 prod.code: 10000108	
Bush	1433AL-BLUE(10000109)	11AK20M-6	1999-					AK20 prod.code: 10000109	
Bush	1433 (silver)	11AK20M-6	1999-					AK20 prod.code: 10000129, 10000811	
Bush	1433 (white) (10001493)	11AK20M-6	1999-					AK20 prod.code: 10001493	
Bush	1433(yellow)	11AK20M-6	1999-					AK20 prod.code: 10000132, 10000810	
Bush	1433BLU3 (10013255)	11AK36-2(2002), 11AK36A2(2003)	2002-2003					AK36 prod.code: 10013255	
Bush	1433(GRN) (10000809)	11AK20M-6	1999-					AK20 prod.code: 10000809	
Bush	1433GRN2	11AK20S							
Bush	1433SIL (10013014)	11AK36A2	2002-2003					AK36 prod.code: 10013014	
Bush	1433/CORN (10000807)	11AK20M-6	1999-					AK20 prod.code: 10000807	
Bush	1433/LILAC (10000808)	11AK20M-6	1999-					AK20 prod.code: 10000808	
Bush	1433/MINT (10000806)	11AK20M-6	1999-					AK20 prod.code: 10000806	
Bush	1434	11AK08 or 11AK20M-6	depends on the year, AK20 after 1999					AK20 prod.code: 10000110	
Bush	1435	11AK08, 11AK36							
Bush	1435GTV (silver)	11AK20M-6	1999-					AK20 prod.code: 10001494	remote 930
Bush	1436	11AK08-13 or 11AK20M-6	11AK20 after 1999					AK20 prod.code: 10000131	
Bush	1438 (10001492)	11AK20D2, 11AK20SE, 11AK20M-6						AK20 prod.code: 10001492	
Bush	1438SIL (10061680)	11AK20S	2000						
Bush	1438SIL	11AK36A2							
Bush	1439	PT11							
Bush	1442	11AK20S							
Bush	1444 (10008717)	11AK20SE	2001					AK20 prod.code: 10008717	remote 1940, part 30000054
Bush	1452T	Same as Alba CTV841	Kong Wah K-91151T					also Bush 1452T, Matsui 2074	Goldstar CIS4441
Bush	1459T	Onwa							
Bush	1470T	1480TS							
Bush	1471T	Grundig G1000							
Bush	1472T	Grundig G1000							
Bush	1473T	11AK08-12 or 11AK20M-6	depends on the year, AK20 after 1999					AK20 prod.code: 10000106	
Bush	1473T (blue) (10000812)	11AK20M-6	1999-					AK20 prod.code: 10000812	
Bush	1473T (silver)(10000130)	11AK20M-6	1999-					AK20 prod.code: 10000130	
Bush	1473T (green)(10000802)	11AK20M-6	1999-					AK20 prod.code: 10000802	
Bush	1473T (white)(10000804)	11AK20M-6	1999-					AK20 prod.code: 10000804	
Bush	1473T (yellow)(10000803)	11AK20M-6	1999-					AK20 prod.code: 10000803	
Bush	1473T/LILIAC (10001491)	11AK20M-6	1999-					AK20 prod.code: 10001491	
Bush	1473T/MINT (10001490)	11AK20M-6	1999-					AK20 prod.code: 10001490	
Bush	1474T	11AK08-14 or 11AK20M-6	depends on the year, AK20 after 1999					AK20 prod.code: 10000111, 10000805	
Bush	1476T	11AK08							
Bush	1477T	chassis EC							
Bush	1478T	11AK20M-6							
Bush	1478TSIL	11AK36	2003, £69.99						
Bush	147TT	same as Alba CTV841	also Bush 1452T						
Bush	1480TS	1470T							
Bush	1497TV	11AK20S (with Internet access)							
Bush	1557NTX								
Bush	170KA	-Bush 1773T	Micro CTV322S V1.2						
Bush	1773T	Orion CTN chassis (label says PT6T)	LOPTx 40337-53, serv. Mode - short Micro	remote RC2143					
Bush	2002	Kong Wah K-91151T	Alba CTV841	Matsui 2074				Goldstar CIS4441	
Bush	2002	Onwa							
Bush	2004	Matsui 1436	Alba CTV100						
Bush	2004T	Indiana 100							
Bush	2007	2007 2033T 2167NTX 2169NTX	Alba CTV3458						
Bush	2009		Alba CTV601						
Bush	2009B	Onwa							
Bush	2011	11AK19-8A	1999-					AK19 prod.code: 10000232	
Bush	2017SIL	11AK30-2(2002), 11AK30A4(2002-2003), 11AK30	2002-2004						
Bush	2020	11AK01	Kong Wah K-91151T, Alba CTV841	Matsui 2074				Goldstar CIS4441	
Bush	2020	Matsui 1580	Saisho CM159TX						
Bush	2023T	11AK10-11, 11AK19-8A, 11AK19B-1	AK19 after 1999					AK19 prod.code: 10000231	
Bush	2027T	PT9601 (Goodmans GTV211)							
Bush	2028T	11AK10-17						prod.code: 10000258, 10000970	
Bush	2030T	11AK19-8A							
Bush	2031T	11AK19-8A	1999-					AK19 prod.code: 10000230	
Bush	2033T	2007 2033T 2167NTX 2169NTX	Alba CTV3458						

Bush	2034T	11AK19 or 11AK30(2002-2003)		11AK30 - 10014182				
Bush	2037TSIL	11AK30A4	2002-2003		10014184			
Bush	2038TSIL	Beko 12.7		PCB marked G70.190-10				
Bush	2052	Kong Wah K-91151T	Alba CTV841	Matsui 2074	Goldstar C1S4441			
Bush	2052T	Onwa						
Bush	2057	Bush 2059	Bush 2157	Bush 2159				
Bush	2059	see Bush 2057						
Bush	2060NTX	NEW ONWA	similar to Alba CTV4886					
Bush	2063NTX	11AK10-8						
Bush	2063NTX/A	11AK10-15		AK10 prod.code: 1000257				
Bush	2067NTX	PT9601 (Goodmans GTV211)						
Bush	2068NTX	11AK10-17						
Bush	2071NTX	11AK19-8A, 11AK19E3(2000), 11AK19P5(2002)	1999-2002	AK19 prod.code: 10000229				
Bush	2077NTXSIL	11AK30-2 (2002), 11AK30A4 (2002-2003), 11AK30	2002-2004					
Bush	2102	Onwa						
Bush	2114	11AK01	Kong Wah K-91151T, Alba CTV841	Matsui 2074	Goldstar C1S4441			
Bush	2131TSIL	11AK19P4, 11AK19P5		AK19 prod.code: 10006073				
Bush	2134TSIL	11AK30	£130					
Bush	2136TSIL	Beko						
Bush	2137TSIL	11AK30	2002-2003, £149.99	prod.code: 10015421				
Bush	2138TSIL	Beko 12.7	2003, £149.99	PCB marked G70.190-6	Micro SDA5535-A062			
Bush	2151(TX)	Indiana 100						
Bush	2152	Kong Wah K-91151T	Alba CTV841	Matsui 2074	Goldstar C1S4441			
Bush	2152T	Onwa						
Bush	2157	see Bush 2057						
Bush	2159	see Bush 2057						
Bush	2160NTX	Grundig G1000						
Bush	2164NTX	11AK19-8A, 11AK19B-1	1999-	AK19 prod.code: 10000364	Micro SDA5255-A059(11AK19-xx), SDA5255-A073(11AK19-8A), SDA5255-A045(11AK			
Bush	2167NTX	2007 2033T 2167NTX 2169NTX	Alba CTV3458					
Bush	2169NTX	2007 2033T 2167NTX 2169NTX	Alba CTV3458					
Bush	2171NTX	11AK19-8A	1999-	AK19 prod.code: 10000363				
Bush	2171NTXSIL	11AK19P5		AK19 prod.code: 10006101				
Bush	2177NTXSIL	11AK30-2(2002), 11AK30A4(2002-2003), 11AK30	2002-2004					
Bush	2214	Osume CTV1474R	Alba CTV841					
Bush	2321	11AK01	Kong Wah K-91151T, Alba CTV841	Matsui 2074	Goldstar C1S4441			
Bush	2420 (2420 Mk I)	chassis C600						
Bush	2514T	Indiana 100						
Bush	2515T	Indiana 100						
Bush	2520TX	Indiana 100						
Bush	2521TX	Indiana 100		Turkish				
Bush	2534TSIL	11AK19P5		Turkish				
Bush	2541(TX)	Indiana 100		prod.code: 10014200				
Bush	2550NTX	Schneider TV4	Serv. Mode: see Bush 2850NTX					
Bush	2550NTX/A	Schneider TV8						
Bush	2568NTX	11AK19-08						
Bush	2571NTX	11AK19-8A, 11AK19E3	1998-2000	AK19 prod.code: 10001134, 100006102				
Bush	2574NTXSIL	11AK19P4, 11AK19P5	2001-2002	AK19 prod.code: 10009365				
Bush	2714	11AK03						
Bush	2720	11AK03						
Bush	2721	11AK03						
Bush	2768NTSIL	SM2						
Bush	2814T	11AK03						
Bush	2820T	11AK03						
Bush	2821T	11AK03						
Bush	2850NTX	Schneider TV4	Serv. mode: press RED and BLUE on R/C together then within 5 sec press P- and V+ together on TV. If you do not have original remote, use any Philips RC5 remot					
Bush	2850NTX/A	Schneider TV8						
Bush	2855WD	Schneider TV4						
Bush	2857NTX	Harwood HTV9425RTN	Amstrad CTV280					
Bush	2863NTX	11AK12						
Bush	2863NTX/A	11AK19-8A						
Bush	2866NTX	SM1 Stereo						
Bush	2866NTXSM2	SM2						
Bush	2867NTX	11AK12 or 11AK19						
Bush	2868NTX	11AK19-5, 11AK19-8A	1999-	AK19 prod.code: 10000518				
Bush	2870VPL	11AK19-8A						
Bush	2871NTX	11AK19-8A, 11AK19E3 (from March2000), 11AK19P5 (from Apr2002)		AK19 prod.code: 10000517, 10006103				
Bush	2872NTX	11AK19E3						
Bush	2874NTX	11AK19E3						
Bush	2874NTXSIL	11AK37-6	2002					
Bush	2876NTX	PT92	2001					
Bush	2877NTXSIL	11AK19P4, 11AK19P5 or 11AK37-8	2001-2002(11AK19), 2003(11AK37)	AK19 prod.code: 10009515				
Bush	2879	C43 (Alba CTV-743)						
Bush	28ZKA	4400 chassis						
Bush	28ZKF	4400 chassis						
Bush	2914	C43 (Alba CTV-743)						
Bush	2920T	Alba CTV703 CTV704T CTV713	Hinari HIT51T					
Bush	2921	Alba CTV703 CTV704T CTV713	Hinari HIT51T					
Bush	2921T	Alba CTV703 CTV704T CTV713	Hinari HIT51T					
Bush	3114	Orion 14EBS	Saisho CT149X	(TVS 89-90 P231)				
Bush	3114A/AS	Orion 14LR chassis	Matsui 1466, Hinary HIT140RC					
Bush	3114AT		Osaki 3114AT					
Bush	3370VPL	11AK19						
Bush	3463NTX	4400 chassis	around £700-£800					
Bush	3472NTX (34BKD)	4400 chassis						
Bush	6690D	11AK19B1 +digibox		AK19 prod.code: 10003064				
Bush	6693D	11AK33J4 +digibox	2003 £349, 2004 £299	10019795				
Bush	7690D	11AK19B1 +digibox						
Bush	7693D	11AK33J4 +digibox	2003, 2004 £399	10019794				
Bush	AC5465	Rank T23A						
Bush	BC6004	Murphy MC6124	Murphy 6425					
Bush	BC6268	T22A	BC6238	BC6468				
Bush	BC7100	Saba chassis						
Bush	BC7200	T24E	Murphy MC7240					
Bush	BC7300	T26A						
Bush	BT14	chassis TV14	Bush BTV140T					
Bush	BTV10	Orion chassis (Alba VTV10)						
Bush	BTV140T		Bush BTV14					
Bush	BTV16	similar to BTV20	Serv.mode: MENU-MUTE-PAUSE-MUTE					
Bush	BTV17	Orion chassis, deck OVD-6; same as Goodmans	PCB marked TM9423A, video VM9162A	Micro OEC0078A, option codes	PSU IC STRF6707			
Bush	BTV17/OVD7	Orion chassis, deck OVD-7			PSU IC STRG6653			
Bush	BTV17SIL/OVD7	Orion chassis, deck OVD-7	PCB marked VMA230A					
Bush	BTV170TBLK	Orion chassis	PCB marked TM9423A		PSU IC STRF6707			
Bush	BTV17A	similar to BTV17	PCB marked VMX193G	Micro OEC0093	PSU IC STRF6707			
Bush	BTV180TSI		2004 £99					
Bush	BTV183DVD	TV/VCR/DVD	2003, £249; 2004 £199					
Bush	BTV18SIL	Orion chassis, deck OVD-7, 2003 £99	PSU PCB VPA150A					
Bush	BTV18SIL/VA	Orion chassis, deck OVD-7	PCB marked VMB290A	Micro OEC0133A				
Bush	BTV20	similar to BTV16	Serv.mode: MENU-MUTE-PAUSE-MUTE					
Bush	BTV213DVD	TV/VCR/DVD	2003, £329					
Bush	CTV1400	Harwood HTV3604R						
Bush	DVD142RC	11AK46-1 +DVD	Serv.mode: INSTALL-4-7-2-5	remote				
Bush	DVD142TV	11AK46-1, 11AK46-5 +DVD	2003, £170	remote				
Bush	DVD143TVFNT1	PT90 +DVD		remote 631020001381				
Bush	DVD144RC		2004, £99					
Bush	DVD145TV		2003, £140					
Bush	DVD660TV	PT90 +DVD		remote 631020001381				
Bush	DVD660TVSIL/A	PT92 +DVD						
Bush	IBX260	INTERNET Box double scart		Vestel prod.code: 10009407				
Bush	ITV2100	Beko 14.1						
Bush	ITV2112	Beko 12.4 with Internet access	Micro SDA555x (SB7640-03/TXT), video N	serv.mode: MENU, then 7.5.9.2				
Bush	ITV2800	Beko 14.1 with Internet	PCB 7SZ.190-14, remote KWR2020	Micro SAA5563PS/M3, jungle TDA8843, sound MSP3410D				
Bush	ITV6600	Beko 14.1	PCB 7SZ.190-17					
Bush	ITV8401	11AK20S with Internet access						
Bush	M1400	Fidelity ZX3000 Mk2						
Bush	M1500	Fidelity ZX3000 Mk2						
Bush	M20T01	Fidelity ZX4000						
Bush	M22T01	Fidelity ZX4000						
Bush	RF6682VPL	Beko 14.1 or 14.2	2001(14.1); 2002(14.2)	14.1 - PCB marked 7SZ.190-18; 14.2 - PCB marked S99.190-04, S99.190-07				
Bush	RF7682VPL	Beko 14.1 or 14.2	14.2 - PCB marked S99.190-07					
Bush	WS5673SIL (10016197)	11AK37-10, 11AK37-11		AK37 prod.code: 10016197				
Bush	WS5676SIL	11AK37						
Bush	WS5680		2004, £180					
Bush	WS6667 (28ZKA)	4400 chassis						
Bush	WS6668SIL (28ZKV)	4400 chassis	PCB marked B-4411					
Bush	WS6671 (10004932)	11AK19P4, 11AK19P5	in 11AK19P4 Micro is 19V1.OFT-A14	AK19 prod.code: 10004932				
Bush	WS6671SIL (10006104)	11AK19P4, 11AK19P5		AK19 prod.code: 10006104				
Bush	WS6671SIL (10014467)	11AK37-8		AK37 prod.code: 10014467				
Bush	WS6672	PT92						
Bush	WS6673	11AK19P5						

Bush	WS6673 (10014458)	11AK37-8	2002-	AK37 prod.code: 10014458					
Bush	WS6673SIL (10008659)	11AK19P4, 11AK19P5	2001-2002	AK19 prod.code: 10008659					
Bush	WS6673SIL (10014469)	11AK37-8	2002-	AK37 prod.code: 10014469					
Bush	WS6674	PT92	2002/2003, £199						
Bush	WS6677	11AK19							
Bush	WS6680SIL	Beko 14.2 chassis	2003, £250	PCB U99.190-07					
Bush	WS7667	4400 chassis							
Bush	WS7671	11AK19B1, 11AK19P4							
Bush	WS7673	11AK19P5 or 11AK37-6 (after 2002)	in 11AK19 Micro 19V1.OFT-A14						
Bush	WS7673SIL (10008660)	11AK19P4, 11AK19P5	2001-2002	AK19 prod.code: 10008660					
Bush	WS7673SIL (10014465)	11AK37-6		AK37 prod.code: 10014465					
Bush	WS7674SIL	PT92							
Bush	WS7680SIL	Beko 14.2 chassis							
Bush	WS766 (28ZKF)	4400 chassis	PCB marked B-4410	Options: Op1-A8, Op2-F8, Op3-1B					
Cathay	CT3520	Indiana 100	NEI						
Cathay	CTV1481R	Indiana 100	NEI						
Cathay	CTV2004T	Indiana 100	NEI						
Cathay	ST4000	Indiana 100	NEI						
Co-op	6348	Rank T20							
Crown	CF9528NFT	F11							
Crown	CF961417/W	F10/F12/F14							
Crown	CR10	Baby 10							
Crown	CR1406FT	Akura CX26							
Crown	CR20NT	Akura CX26							
Crown	CR2894R	Akura CX26							
Crown	CRP14(T)	SM1 Mono	also see Matsui 1496, 2096 etc						
Crown	CRP2190NT	SM1 Mono							
Crown	CRP21NT (T/T/S)	SM1 Mono							
Crown	CRP26NT	SM1 Stereo							
Crown	CRT9655RTN	11AK10							
Crown	CRV37	11AK08							
Crown	CRV47	11AK08-13							
Crown	CRV72NT	11AK12							
Crown	CTF139TSL		2003, £100	Serv.mode: remove R/C top cover and press hidden button on the left hand side, then press OK. Use P+/- to navigate, V					
Crown	CTF1401R	G1000							
Crown	CTF1402T	G1000							
Crown	CTF14R	Amstrad CTV1400 (new)							
Crown	CTF2001R	G1000							
Crown	CTF2005NFT	G1000							
Crown	CTF2805NFT	E2000							
Crown	CTF28NFT		similar CTF29NF						
Crown	CTF29NF		similar CTF28NFT						
Daewoo	14C3	CP005 or CP185							
Daewoo	14C4	CP005 or CP185							
Daewoo	14C5	CP005							
Daewoo	14H3	CP082							
Daewoo	14Q1 14Q2 14Q3	CP370 (1-speaker)	VM -without TEXT, TM-with TEXT						
Daewoo	14T1 14T2 14T3	CP370 (2-speakers)	VM -without TEXT, TM-with TEXT						
Daewoo	14U1	CP005							
Daewoo	14V1	CP005							
Daewoo	14V2	CP005							
Daewoo	14V3	CP005 or CP185							
Daewoo	14V5	CP005							
Daewoo	20A1	CP330							
Daewoo	20C4	CP005							
Daewoo	20C5	CP005							
Daewoo	20H4	CP082							
Daewoo	20Q1 20Q2 20Q3	CP370 (1-speaker)	VM -without TEXT, TM-with TEXT						
Daewoo	20T1 20T2 20T3	CP370 (2-speakers)	VM -without TEXT, TM-with TEXT						
Daewoo	20U1	CP005							
Daewoo	20V1	CP005							
Daewoo	20V3	CP005 or CP185							
Daewoo	20V4	CP005							
Daewoo	20V5	CP005							
Daewoo	21C6	CP005							
Daewoo	21Q1 21Q2	CP370 (1-speaker)	VM -without TEXT, TM-with TEXT						
Daewoo	21T1 21T2	CP370 (2-speakers)	VM -without TEXT, TM-with TEXT						
Daewoo	21U1	CP005							
Daewoo	21U3	CP005							
Daewoo	21V1	CP005							
Daewoo	21V2	CP005							
Daewoo	21V3	CP005 or CP185							
Daewoo	21V4	CP005							
Daewoo	21V6	CP005							
Daewoo	25G7	CP785	PSU I801 STRF6653						
Daewoo	2880Z	CP820	2003						
Daewoo	2881Z	CP820F	2003						
Daewoo	28A6Z	CP820	2003						
Daewoo	28A7	CP785	PSU I801 STRF6653						
Daewoo	28A7Z	CP820	2003						
Daewoo	28B1	CP785(50Hz) or CP810(100Hz)							
Daewoo	28B1Z	CP820	2003						
Daewoo	28B2Z	CP820	2003						
Daewoo	28G6Z	CP820	2003						
Daewoo	28G7	CP785	PSU I801 STRF6653						
Daewoo	28G7Z	CP820	2003						
Daewoo	28G8Z	CP820	2003						
Daewoo	28W5Z	CP820	2003						
Daewoo	28W8Z	CP820F	2003						
Daewoo	29U7Z	CP820F	2003						
Daewoo	29U8	CP885F							
Daewoo	29U8Z	CP820F	2003						
Daewoo	DDT14H9S	CP099F (TV/DVD Combi)	2002	remote R-52B02					
Daewoo	DDT21H9S	CP099F (TV/DVD Combi)	2002	remote R-52B02					
Daewoo	DMQ1454	C901	DMQ2154	Thorn P1480R					
Daewoo	DMQ1457	CP315							
Daewoo	DMQ1494	CP315							
Daewoo	DMQ2057	CP315							
Daewoo	DMQ2072	CP320							
Daewoo	DMQ2154	C901	DMQ1454	Thorn P1480R					
Daewoo	DMQ2159	CP315							
Daewoo	DP32SM/SP	SP115 (plasma)	2002	R-V28A(E)					
Daewoo	DP42GM/GP	SP115 (plasma)	2002	R-V28A(E)					
Daewoo	DP42SM/SP	SP115 (plasma)	2002	R-V28A(E)					
Daewoo	DP42WM/WP	SP115 (plasma)	2002	R-V28A(E)					
Daewoo	DSC3210E	SC140	2002, Multisystem B/G, D/K, I	R-46G22					
Daewoo	DSC3220E	SC150	2002/2003, Multisystem B/G, D/K, I	Remote R-46G22					
Daewoo	DSC3220L	SC150	2002/2003, Multisystem B/G, D/K, I	Remote R-46G22					
Daewoo	DSC3261H	SC132	2002, Multisystem B/G, D/K, I	RV-22N	=NEC PF32W01				
Daewoo	DSC3270EGB	SC130	2001, Multisystem B/G, D/K, I	RV-22D					
Daewoo	DSJ6000LHM	SJ210H (LCD Projection HDTV monitor)	2003						
Daewoo	DSJ6000LN	SJ210H (LCD Projection HDTV monitor)	2002						
Daewoo	DSP4210GM	SP110 (plasma)	2001						
Daewoo	DTA20T1	CP385	PSU I801 STRF6653						
Daewoo	DTA20T2	CP385	PSU I801 STRF6653						
Daewoo	DTA20T3	CP385	PSU I801 STRF6653						
Daewoo	DTA20T8	CP385	PSU I801 STRF6653						
Daewoo	DTA21T1	CP385	PSU I801 STRF6653						
Daewoo	DTA21T2	CP385	PSU I801 STRF6653						
Daewoo	DTA21T5	CP385	PSU I801 STRF6653						
Daewoo	DTA21T9	CP385	PSU I801 STRF6653						
Daewoo	DTA21Y1	CP385	PSU I801 STRF6653						
Daewoo	DTB21U6	CP185F	2002, Multisystem B/G, D/K, I	R-40A10 (nontext), R-40A01(text AAA battery), R-44C05 (text AA battery)					
Daewoo	DTC14T6	CP390	1998, Multi-standard I, B/G, D/K						
Daewoo	DTC14U1	CP002	2000						
Daewoo	DTC14V1	CP002	2000						
Daewoo	DTC14V3	CP002	2000						
Daewoo	DTC14V4	CP002	2000						
Daewoo	DTC14V5	CP002	2000						
Daewoo	DTC20T6	CP390	1998, Multi-standard I, B/G, D/K						
Daewoo	DTC20V1	CP002	2000						
Daewoo	DTC20V3	CP002	2000						
Daewoo	DTC20V4	CP002	2000						
Daewoo	DTC20V5	CP002	2000						
Daewoo	DTC21T7	CP390	1998, Multi-standard I, B/G, D/K						
Daewoo	DTC21U1	CP002	2000						
Daewoo	DTC21U3	CP002	2000						
Daewoo	DTC21V1	CP002	2000						
Daewoo	DTC21V3	CP002	2000						

[illegible]

Decca	DN1253	120 Chassis							
Decca	DN1256	120/125 Chassis							
Decca	DN1259	120/130 Chassis							
Decca	DN1451	140 Chassis							
Decca	DN1471	140 Chassis							
Decca	DN1651A	160 Chassis							
Decca	DN1670	160 Chassis							
Decca	DN1671	160 Chassis							
Decca	DN1672	160 Chassis							
Decca	DN1674	160 Chassis							
Decca	DN8452	140 Chassis							
Decca	DN8472	140 Chassis							
Decca	DN8652	165 Chassis							
Decca	DN8951	190 Chassis	Boots C1411/2		Matsui 1424				
Decca	DN8951	190 Chassis							
Decca	DN8955	190 Chassis							
Decca	DN9256	120/125 Chassis							
Decca	DN9257	120/125 Chassis							
Decca	DN9259	120/130 Chassis							
Decca	DP1257	120/130 Chassis							
Decca	DP1453	140 Chassis							
Decca	DP1473	140 Chassis							
Decca	DP1653/A	160 Chassis							
Decca	DP1673	160 Chassis							
Decca	DP8454	140 Chassis							
Decca	DP8474	140 Chassis							
Decca	DP9257	120/130 Chassis							
Decca	DP8454	140 Chassis							
Decca	DT1253	120 Chassis							
Decca	DT1257	120/125 Chassis							
Decca	DT1260	120 Chassis							
Decca	DT1263	120 Chassis							
Decca	DT1455	140 Chassis							
Decca	DT1475	140 Chassis							
Decca	DT1655	160 Chassis							
Decca	DT1675	160 Chassis							
Decca	DT8456	140 Chassis							
Decca	DT8459	140 Chassis							
Decca	DT8466	145A Chassis							
Decca	DT8476	145A Chassis							
Decca	DT8496	145A Chassis							
Decca	DT9253	120 Chassis							
Decca	DT9255	120/125 Chassis							
Decca	DT9260	120/125 Chassis							
Decca	DT9456	140 Chassis							
Decca	DT9459	140 Chassis							
Decca	DT9466	145A Chassis							
Decca	DT9476	145A Chassis							
Decca	DT9496	145A Chassis							
Decca	DT9497	140 Chassis							
Decca	DT9770	190/195 Chassis							
Decca	DT9772	171 Chassis							
Decca	DU8670M	165 Chassis							
Decca	DU8688	165 Chassis							
Decca	DV1254	120 Chassis							
Decca	DV1351	130 Chassis							
Decca	DV1353	130 Chassis							
Decca	DV1360	130 Chassis							
Decca	DV1361	130 Chassis							
Decca	DV1457	140 Chassis							
Decca	DV1462	140 Chassis							
Decca	DV1475	140 Chassis							
Decca	DV1477	140 Chassis							
Decca	DV1657	160 Chassis							
Decca	DV1677	160 Chassis							
Decca	DV8458	140 Chassis							
Decca	DV8460	140 Chassis							
Decca	DV8468	145A Chassis							
Decca	DV8478	147 Chassis							
Decca	DV8498	145A Chassis							
Decca	DV8554	150 Chassis							
Decca	DV9101	111 Chassis							
Decca	DV9151	111 Chassis							
Decca	DV9254	120 Chassis							
Decca	DV9351	130 Chassis							
Decca	DV9352	130 Chassis							
Decca	DV9357	131 Chassis							
Decca	DV9458	140 Chassis							
Decca	DV9460	140 Chassis							
Decca	DV9468	145A Chassis							
Decca	DV9498	145A Chassis							
Decca	DV9499	140 Chassis							
Decca	DV9551	150 Chassis							
Decca	DV9758	170/180 Chassis							
Decca	DVS9893C	180 Chassis							
Decca	DZ1352	130 Chassis							
Decca	DZ1362	130 Chassis							
Decca	DZ3152	111 Chassis							
Decca	DZ3352	130 Chassis							
Decca	DZ3354	130 Chassis							
Decca	DZ3358	120/130 Chassis							
Decca	DZ3362	130 Chassis							
Decca	DZ9555	150 Chassis							
Decca	PT9255	120/125 Chassis							
Decca	PV9352	130 Chassis							
Decca	PZ9354	130 Chassis							
Decca		10	Bradford						
Decca		30	Bradford						
Decca		70							
Decca		80	Granada C20SD1 / C20TD1						
Decca		90							
Decca		100							
Decca		110							
Decca		120							
Decca		125							
Decca		130							
Decca		140							
Decca		141							
Decca		145							
Decca		150							
Decca		160				Tatung TV9448			
Decca		161				Tashiko 16E891			
Decca		162	GEC C1410						
Decca		165	GEC C2000						
Decca		166							
Decca		170	Proline 360TT			Tatung TUV9731/4			
Decca		180	Proline NV2400/NV2700			Tatung TYS9824			
Decca		185							
Decca		A Series							
Decca		B Series							
Decca		C Series	Tatung DU6C22						
Decca		C Series	Tatung TU2C52						
Decca		C Series	Tatung VU2CEO						
Dynatron	267475SK	Philips K40							
Etron	EC142	Akashi 1450							
Expert	2061	Hitachi CPT2051							
Ferguson	14C1	TX90							
Ferguson	14C2	TX90							
Ferguson	14C9	TX90							
Ferguson	14D1	TX85							
Ferguson	14D2	TX85/90							
Ferguson	14J1	TX85							
Ferguson	14J2	TX85/90							
Ferguson	14J9	TX85							
Ferguson	14K1	TX85							
Ferguson	14K2	TX85							
Ferguson	14K9	TX85							
Ferguson	14L1	TX86							
Ferguson	14L2	TX86							

Ferguson	14L9	TX86							
Ferguson	14M1	TX86							
Ferguson	14M2	TX89							
Ferguson	14M9	TX86							
Ferguson	16A1	TX90							
Ferguson	16A2	TX90							
Ferguson	16A3	TX90							
Ferguson	16H2	TX99							
Ferguson	16H3	TX99							
Ferguson	170	TX9							
Ferguson	171	TX9							
Ferguson	1764	9700							
Ferguson	1765	9700							
Ferguson	1785	TX10							
Ferguson	1791	9700							
Ferguson	1796	9750							
Ferguson	1799	9700							
Ferguson	190	TX9							
Ferguson	200	TX90							
Ferguson	2000	TX90							
Ferguson	20A1	TX100							
Ferguson	20A2	TX100							
Ferguson	20A3	TX100							
Ferguson	20A4	TX100							
Ferguson	20C2	TX100							
Ferguson	20C3	TX100							
Ferguson	20C4	TX100							
Ferguson	20E1	TX90							
Ferguson	20E2	TX90							
Ferguson	20G1	TX100							
Ferguson	20G2	TX100							
Ferguson	20G3	TX100							
Ferguson	20H1	TX100							
Ferguson	20H2	TX100							
Ferguson	20H3	TX100							
Ferguson	20K2	TX95							
Ferguson	20K3	TX95							
Ferguson	22B1	TX100							
Ferguson	22B2	TX100							
Ferguson	22B3	TX100							
Ferguson	22B4	TX100							
Ferguson	22B5	TX10							
Ferguson	22D1	TX100							
Ferguson	22D2	TX100							
Ferguson	22D3	TX100							
Ferguson	22D4	TX100							
Ferguson	22G1	TX100							
Ferguson	22G2	TX100							
Ferguson	22G3	TX100							
Ferguson	22H1	TX100							
Ferguson	22H2	TX100							
Ferguson	22H3	TX100							
Ferguson	232	TX10							
Ferguson	2323	TX100							
Ferguson	233	TX10							
Ferguson	2343	TX100							
Ferguson	2353	TX100							
Ferguson	2403	TX10							
Ferguson	2422	TX100							
Ferguson	2423	TX100							
Ferguson	2452	TX100							
Ferguson	2453	TX100							
Ferguson	2463	TX100							
Ferguson	262	TX9							
Ferguson	26D1	TX100							
Ferguson	26D2	TX100							
Ferguson	26D3	TX100							
Ferguson	26G2	TX100							
Ferguson	26G3	TX100							
Ferguson	26H1	TX100							
Ferguson	26H2	TX100							
Ferguson	26H3	TX100							
Ferguson	271	TX9							
Ferguson	273	TX9							
Ferguson	282	TX10							
Ferguson	283	TX10							
Ferguson	2841	1590							
Ferguson	289	TX10							
Ferguson	311	TX10							
Ferguson	3170	TX9							
Ferguson	3171	TX9							
Ferguson	3190	TX9							
Ferguson	3232	TX10							
Ferguson	3233	TX10							
Ferguson	3262	TX9							
Ferguson	3271	TX9							
Ferguson	3272	TX9							
Ferguson	3273	TX9							
Ferguson	3282	TX10							
Ferguson	3283	TX10							
Ferguson	3289	TX10							
Ferguson	32WS650D	ICC19							
Ferguson	3311	TX10							
Ferguson	3579	TX571							
Ferguson	36040	TX9							
Ferguson	36140	TX90							
Ferguson	36141	TX90							
Ferguson	36152	TX9							
Ferguson	36310	TX90							
Ferguson	36311	TX90							
Ferguson	36351	TX9							
Ferguson	36H2	TX99							
Ferguson	36H3	TX99							
Ferguson	36K2	TX89							
Ferguson	36K3	TX99/89							
Ferguson	37003	TX9							
Ferguson	37003	TX9							
Ferguson	37023	TX9							
Ferguson	37023	TX9							
Ferguson	37041	TX9							
Ferguson	37041	TX9							
Ferguson	37051	TX10							
Ferguson	37060	TX10							
Ferguson	37060	TX10							
Ferguson	37063	TX10							
Ferguson	37063	TX10							
Ferguson	37081	TX9							
Ferguson	37081	TX9							
Ferguson	37090	TX9							
Ferguson	37090	TX9							
Ferguson	37093	TX9							
Ferguson	37093	TX9							
Ferguson	37100	TX9							
Ferguson	37100	TX9							
Ferguson	37101	TX9							
Ferguson	37101	TX9							
Ferguson	37103	TX9							
Ferguson	37140	TX90							
Ferguson	37141	TX90							
Ferguson	37147	TX90							
Ferguson	37149	TX90							
Ferguson	37311	TX10							
Ferguson	3734	9600							
Ferguson	37340	TX10							
Ferguson	37340	TX10							
Ferguson	37341	TX10							
Ferguson	37341	TX10							
Ferguson	37350	TX9							
Ferguson	37350	TX9							

Ferguson	37351	TX9							
Ferguson	37351	TX9							
Ferguson	37353	TX9							
Ferguson	37353	TX9							
Ferguson	3736	9600							
Ferguson	37360	TX9							
Ferguson	37360	TX9							
Ferguson	37361	TX9							
Ferguson	37361	TX9							
Ferguson	37363	TX10							
Ferguson	37363	TX9							
Ferguson	3737	9600							
Ferguson	37370	TX10							
Ferguson	37370	TX10							
Ferguson	37371	TX10							
Ferguson	37373	TX10							
Ferguson	37373	TX10							
Ferguson	3743	9600							
Ferguson	37430	TX10							
Ferguson	3745	9800							
Ferguson	37460	TX10							
Ferguson	37463	TX10							
Ferguson	37463	TX10							
Ferguson	3747	9600							
Ferguson	3749	9600							
Ferguson	37493	TX9							
Ferguson	37493	TX9							
Ferguson	3752	9800							
Ferguson	3755	TX9							
Ferguson	3755	TX9							
Ferguson	37559	TX9							
Ferguson	3756	TX9							
Ferguson	3756	TX9							
Ferguson	3757	9900							
Ferguson	3758	9900							
Ferguson	3759	9600							
Ferguson	3760	TX9							
Ferguson	3760	TX9							
Ferguson	37600	TX9							
Ferguson	3762	9600							
Ferguson	3763	9600							
Ferguson	3764	9600							
Ferguson	3765	TX10							
Ferguson	3765	TX10							
Ferguson	37650	TX10							
Ferguson	37650	TX10							
Ferguson	3766	TX10							
Ferguson	3767	TX10							
Ferguson	3767	TX10							
Ferguson	3768	TX9							
Ferguson	3768	TX9							
Ferguson	3769	TX9							
Ferguson	3769	TX9							
Ferguson	3776	9600							
Ferguson	3780	TX9							
Ferguson	3780	TX9							
Ferguson	37800	TX9							
Ferguson	37800	TX9							
Ferguson	37801	TX9							
Ferguson	37801	TX9							
Ferguson	3781	TX9							
Ferguson	3781	TX9							
Ferguson	3782	9650							
Ferguson	3784	9602							
Ferguson	3785	TX10							
Ferguson	3785	TX10							
Ferguson	37850	TX10							
Ferguson	37850	TX10							
Ferguson	3786	TX10							
Ferguson	3787	NORD-FV1							
Ferguson	3787	Nordmende 8180 chassis (1978)	Nordmende 4230						
Ferguson	3788	TX10							
Ferguson	3788	TX10							
Ferguson	3789	9653							
Ferguson	3790	TX9							
Ferguson	3790	TX9							
Ferguson	3791	TX10							
Ferguson	3791	TX10							
Ferguson	3792	TX9							
Ferguson	3792	TX9							
Ferguson	3793	9653							
Ferguson	3794	TX10							
Ferguson	3795	TX10							
Ferguson	3795	TX10							
Ferguson	37953	TX10							
Ferguson	37953	TX10							
Ferguson	3796	TX10							
Ferguson	3796	TX10							
Ferguson	37963	TX10							
Ferguson	37963	TX10							
Ferguson	38000	1696							
Ferguson	38010	1696							
Ferguson	38020	1790-1791							
Ferguson	38030	1790							
Ferguson	38050	1790							
Ferguson	3838	1613							
Ferguson	3839	1613							
Ferguson	3840	1690-1691	Alba T1114						
Ferguson	3845	1690-1691							
Ferguson	3847	1690-1691							
Ferguson	3848	1690-1691							
Ferguson	3850	1615							
Ferguson	38500	1615							
Ferguson	3852	1615							
Ferguson	38520	1615							
Ferguson	3853	1694							
Ferguson	3854	1694							
Ferguson	3857	1694							
Ferguson	3858	1694							
Ferguson	3870	1697							
Ferguson	3871	1697							
Ferguson	38710	1697							
Ferguson	3C02	TX571							
Ferguson	3MC01	TX90							
Ferguson	3MC05	TX90							
Ferguson	40MK10	TX90E							
Ferguson	40MPR45	TX90E							
Ferguson	41H2	TX99							
Ferguson	41H3	TX99							
Ferguson	41K3	TX98							
Ferguson	41P3	IKC2							
Ferguson	4838	1612							
Ferguson	5170	TX9							
Ferguson	5171	TX9							
Ferguson	5190	TX9							
Ferguson	51A0	TX100							
Ferguson	51A1	TX100							
Ferguson	51A2	TX100							
Ferguson	51A3	TX100							
Ferguson	51A4	TX100							
Ferguson	51A5	TX100							
Ferguson	51A8	TX100							
Ferguson	51D1	TX100							
Ferguson	51G2	TX100							
Ferguson	51G3	TX100							
Ferguson	51H2	TX99							
Ferguson	51H3	TX100							
Ferguson	51H4	TX100							
Ferguson	51H5	TX100							

Ferguson	51H8	TX100								
Ferguson	51J7	TX99								
Ferguson	51J8	TX99								
Ferguson	51K2	TX99								
Ferguson	51K3	TX99								
Ferguson	51K4	ICC5								
Ferguson	51K5	ICC5								
Ferguson	51K7	ICC5								
Ferguson	51L3	ICC5								
Ferguson	51L5Q	ICC5	Nicam							
Ferguson	51L7	ICC5								
Ferguson	51P7	TX98								
Ferguson	51Q7	TX98								
Ferguson	5232	TX10								
Ferguson	5233	TX10								
Ferguson	5262	TX9								
Ferguson	5271	TX9								
Ferguson	5272	TX9								
Ferguson	5273	TX9								
Ferguson	5281	TX10								
Ferguson	5282	TX10								
Ferguson	5283	TX10								
Ferguson	5289	TX10								
Ferguson	5311	TX10								
Ferguson	59B1	TX100								
Ferguson	59B2	TX100								
Ferguson	59B3	TX100								
Ferguson	59B4	TX100								
Ferguson	59B5	TX100								
Ferguson	59B8	TX100								
Ferguson	59D2	TX100								
Ferguson	59D3	TX100								
Ferguson	59G2	TX100								
Ferguson	59G3	TX100								
Ferguson	59H2	TX100								
Ferguson	59H3	TX100								
Ferguson	59H4	TX100								
Ferguson	59H5	TX100								
Ferguson	59J7	TX100								
Ferguson	59K4	ICC5								
Ferguson	59K5	ICC5								
Ferguson	59K7	ICC5								
Ferguson	59L5	ICC5								
Ferguson	59L7	ICC5								
Ferguson	59M2	ICC5								
Ferguson	59M5	ICC5								
Ferguson	59P7	ICC5								
Ferguson	59P7A	ICC5								
Ferguson	6003	TX10								
Ferguson	6004	TX10								
Ferguson	6012	TX10								
Ferguson	6013	TX10								
Ferguson	6019	TX10								
Ferguson	6021	TX9								
Ferguson	6023	TX9								
Ferguson	6031	TX9								
Ferguson	6053	TX9								
Ferguson	6070	TX9								
Ferguson	6071	TX9								
Ferguson	6076	TX9								
Ferguson	6083	TX10								
Ferguson	6093	TX9								
Ferguson	6103	TX10								
Ferguson	6116	TX9								
Ferguson	6121	TX9								
Ferguson	6144	TX10								
Ferguson	6170	TX90								
Ferguson	6171	TX90								
Ferguson	6175	TX90								
Ferguson	6213	TX9								
Ferguson	6245	TX10								
Ferguson	626R	TX807								
Ferguson	6603	TX10								
Ferguson	66B2	TX100								
Ferguson	66B3	TX100								
Ferguson	66B5	TX100								
Ferguson	66B8	TX100								
Ferguson	66H2	TX100								
Ferguson	66H3	TX100								
Ferguson	66H4	TX100								
Ferguson	66H5	TX100								
Ferguson	66K4	ICC5								
Ferguson	66M3	ICC5	1993							
Ferguson	6735	9600								
Ferguson	6745	9800								
Ferguson	6749	9800								
Ferguson	6770	9900								
Ferguson	6771	TX9								
Ferguson	6775	9600								
Ferguson	6830	1612								
Ferguson	6838	1613								
Ferguson	6839	1613								
Ferguson	6840	1690								
Ferguson	6850	1615								
Ferguson	6852	1615								
Ferguson	68K4	ICC5								
Ferguson	68K4BQ	ICC5								
Ferguson	68M5	ICC5								
Ferguson	7170	TX9								
Ferguson	7171	TX9								
Ferguson	7190	TX9								
Ferguson	7232	TX10								
Ferguson	7233	TX10								
Ferguson	7262	TX9								
Ferguson	7271	TX9								
Ferguson	7272	TX9								
Ferguson	7273	TX9								
Ferguson	7281	TX10								
Ferguson	7282	TX10								
Ferguson	7283	TX10								
Ferguson	7289	TX10								
Ferguson	7311	TX10								
Ferguson	7741	TX100								
Ferguson	7742	TX100								
Ferguson	7841	TX100								
Ferguson	7842	TX100								
Ferguson	78M5	ICC5								
Ferguson	8143	TX10								
Ferguson	8170	TX9								
Ferguson	8171	TX9								
Ferguson	8190	TX9								
Ferguson	8203	TX10								
Ferguson	8232	TX10								
Ferguson	8233	TX10								
Ferguson	8243	TX9								
Ferguson	8262	TX9								
Ferguson	8271	TX9								
Ferguson	8272	TX9								
Ferguson	8273	TX9								
Ferguson	8281	TX10								
Ferguson	8282	TX10								
Ferguson	8283	TX10								
Ferguson	8289	TX10								
Ferguson	8311	TX10								
Ferguson	8787	NORDMENDE FV1								
Ferguson	A10R	TX80								
Ferguson	A14R	TX90E								
Ferguson	A36F	IKC2								
Ferguson	A36F	TX80								

Ferguson	A36R	TX80					
Ferguson	A51EAL	TX100					
Ferguson	A51F	ICC2					
Ferguson	A51N	ICC7					
Ferguson	A59EAK	TX100					
Ferguson	A59EAS	TX100					
Ferguson	A59F	ICC7					
Ferguson	A59N	ICC7/8					
Ferguson	A68N	ICC7					
Ferguson	AXF51	TX100					
Ferguson	B14C	TX90E					
Ferguson	B14R	TX90E					
Ferguson	B39F	TX90E					
Ferguson	B49F	TX90E					
Ferguson	B51F	ICC7					
Ferguson	B51NX	ICC8					
Ferguson	B59F	ICC7					
Ferguson	B59N	ICC8					
Ferguson	B59NX	ICC8					
Ferguson	B68N	ICC8					
Ferguson	B68NX	ICC8					
Ferguson	B78NT/X	ICC5					
Ferguson	C14C	TX90E					
Ferguson	C15012R	Samsung P68 chassis					
Ferguson	C2152	TX100					
Ferguson	C2153	TX100					
Ferguson	C3615UT	Eurocombo2					
Ferguson	C39F	TX90E					
Ferguson	C49F	TX90E					
Ferguson	C51F	ICC6					
Ferguson	C51N	ICC8					
Ferguson	C51ND	ICC7					
Ferguson	C51NX	ICC8					
Ferguson	C59NX	ICC8					
Ferguson	C68F	ICC7					
Ferguson	C68NX	ICC8					
Ferguson	D14R	TX805					
Ferguson	D51N	ICC9					
Ferguson	D51ND	ICC9	NICAM				
Ferguson	D51NDD	ICC9					
Ferguson	D59F	ICC9	Mono sound				
Ferguson	D59N	ICC9	NICAM				
Ferguson	D68N	ICC9	NICAM				
Ferguson	D78N	ICC9	NICAM				
Ferguson	DSF68NX	IDC2					
Ferguson	F16/17	ICC7?					
Ferguson	FG14CB12V	CP-310 (Daewoo)	Goodmans TVC1400 TVC14VP	Daewoo DVT1484D			
Ferguson	FG20CB12V	CP-310 (Daewoo)	Goodmans TVC1400 TVC14VP	Daewoo DVT1484D			
Ferguson	FTV28WN1	11AK37	2004 E250				
Ferguson	M3610U	TX807					
Ferguson	M3615UT	TX807					
Ferguson	M3673GC(T)	TX91G					
Ferguson	M51131RH	TX807C					
Ferguson	M5115UT	TX807					
Ferguson	M5515UT	TX807					
Ferguson	M5518U	ICC17					
Ferguson	M5519U	TX91G					
Ferguson	M5520U	TX91G					
Ferguson	M5573GF	TX91G					
Ferguson	M6322U	ICC17					
Ferguson	M6373GH	TX92F					
Ferguson	M7017U	TX807CS					
Ferguson	M7022U	ICC17					
Ferguson	M7073GH	TX92F					
Ferguson	M8122U	ICC17					
Ferguson	M8123U	ICC17					
Ferguson	M8421U	ICC17					
Ferguson	M8422U	ICC17					
Ferguson	MC01	TX90	Receiver/Monitor				
Ferguson	MC05	TX90	Receiver/Monitor				
Ferguson	MC09	TX85					
Ferguson	MC09	TX90					
Ferguson	RR5191N	ICC7					
Ferguson	S59N	ICC9	NICAM+				
Ferguson	S68N	ICC9	NICAM+				
Ferguson	S7971	TX100					
Ferguson	S7981	TX100					
Ferguson	T10R	TX90	Mains/Batt portable 10"				
Ferguson	T14R	TX805					
Ferguson	T14T	TX91					
Ferguson	T25DPL	ICC9					
Ferguson	T28DPL	ICC9					
Ferguson	T49F	TX91					
Ferguson	T5173GF	TX91G					
Ferguson	T51F	TX91					
Ferguson	T59F	TX92	Thompson Digital Chassis				
Ferguson	T59FB	TX92F					
Ferguson	T59N	TX92					
Ferguson	T59NB	TX92F					
Ferguson	T68N	TX92					
Ferguson	T7021U	ICC17					
Ferguson	T7025UD	ICC17					
Ferguson	T78DPL	ICC9					
Ferguson	T78N	TX92					
Ferguson	T94N	ICC9					
Ferguson	TB6013C	TX10					
Ferguson	TB6023	TX9					
Ferguson	TB6213	TX9					
Ferguson	U2001	TX100					
Ferguson	U2201	TX100					
Ferguson	V51NB	TX91G					
Ferguson	W70201S	ICC17					
Ferguson	W7022U	ICC17					
Ferguson	W7023U	ICC17					
Ferguson	WF70401G	ICC20	(Telefunken chassis 446X)				
Ferguson	X51FB	TX91G					
Fidelity	1482	ZX2000					
Fidelity	AVS1600	ZX3000					
Fidelity	AVS2000	ZX3000					
Fidelity	C14M06/R06	ZX1415	Brittania B14M11				
Fidelity	C14M07	Solarvox 140 chassis	Nikkai TLG88				
Fidelity	C14M08	Solarvox 141 chassis	Nikkai TLG99				
Fidelity	C14R08	ZX4000					
Fidelity	C14T01	ZX5000					
Fidelity	C20R03	ZX4222					
Fidelity	C20T03	ZX4223					
Fidelity	C20T04	ZX5000 (Digital)	Saisho/Matsui CM260T				
Fidelity	C51T01	ZX5000					
Fidelity	CTM14	ZX3000					
Fidelity	CTM14	ZX3000 Mk2					
Fidelity	CTM1400	ZX3000 Mk2					
Fidelity	CTM2000	ZX3000					
Fidelity	CTM2001	ZX3000					
Fidelity	CTM2002	ZX3000					
Fidelity	CTM2003R/T	ZX3000					
Fidelity	CTM2003TX	ZX4200					
Fidelity	CTM200TX	ZX4200					
Fidelity	CTV14	ZX2000					
Fidelity	CTV14 Mk2	ZX3000	Triumph CTV8209				
Fidelity	CTV140	ZX2000					
Fidelity	CTV1404	ZX1411	Murphy M14R01				
Fidelity	CTV1404R	ZX4000					
Fidelity	CTV1404S	ZX4000					
Fidelity	CTV1405	ZX3000					
Fidelity	CTV1405S	ZX4000					
Fidelity	CTV140R	ZX4010					
Fidelity	CTV14R	ZX2000					
Fidelity	CTV14S	ZX2000/3000					
Fidelity	CTV20	ZX4120					

Fidelity	CTV2001	ZX3000							
Fidelity	CTV2020	ZX3000							
Fidelity	CTV2022	ZX3000 Mk2							
Fidelity	CTV2024	ZX3000/2000							
Fidelity	CTV2026	ZX3000							
Fidelity	CTV20R	ZX3000/2000							
Fidelity	CTV20T	ZX3000							
Fidelity	CTV2201	ZX3000							
Fidelity	CTV2201S	ZX4230							
Fidelity	CTV2201T	ZX4231							
Fidelity	CTV2210	ZX3000							
Fidelity	CTV2224	ZX3000							
Fidelity	CTV2226	ZX3000							
Fidelity	CTV22R	ZX3000							
Fidelity	CTV22T	ZX3000							
Fidelity	WSTV7028NF	11AK19-8A							
Fidelity	WSTV7028NF	11AK19-8A							
Finlandia	A. Model numbers:-	E.G. C59CZ7 C=colour; 59=crt size;	C=year of manuf.; Z=Finlandia	7= version (higher the vers.	the more features)				
Finlandia	AZ			Salora J	Ipsalo 2				
Finlandia	BZ			Salora J	Ipsalo 2				
Finlandia	CZ			Salora K	Ipsalo 3				
Finlandia	DZ	Salora 15L37/20L30 etc		Salora L	Ipsalo 3				
Finlandia	EZ	Tashiko 51E941/942	Hitachi CPT2658	Salora K	Ipsalo 3				
Finlandia	FZ		Nokia	Salora M	Digital				
Finlandia	GZ		Hitachi CS2852TA	Salora M	Digital				
Finlandia	HZ		Nokia	Salora M	Digital				
Finlandia	JZ			Salora N					
Finlandia	NZ								
Finlandia	PZ								
Finlandia	SZ	Salora 1F3		Salora F					
Finlandia	TZ			Salora F					
Finlandia	VZ			Salora F					
Finlandia	XZ	Salora 1G3/1G5		Salora G/H	Ipsalo 1/2				
Finlandia	YZ			Salora J	Ipsalo 2				
Finlandia		Salora 1H4		Salora H	Ipsalo 2				
Finlandia		Salora 21/25/28M87	Hitachi CPT6608	Salora M	Digital				
Finlandia		Salora 22J40	Hitachi CPT2050/2250	Salora J	Ipsalo 2				
Finlandia		Salora 22K30 etc	Hitachi CPT2188/2568 etc	Salora K	Ipsalo 3				
Finlandia		Salora 24K7H / 22K37	Hitachi CPT2488	Salora K	Ipsalo 3				
Finlandia			Hitachi CPT2625	Salora J	Ipsalo 2				
Finlandia			Hitachi CPT2060/2260/2660	Salora J	Ipsalo 2				
Finlandia			Hitachi C15-P108	Salora L	Ipsalo 3				
Finlandia			Hitachi C17-P118	Salora L	Ipsalo 3				
Finlandia			Hitachi CPT1556	Salora L	Ipsalo 3				
Finlandia			Hitachi CPT2656	Salora K	Ipsalo 3				
Finlandia			Hitachi C28-P759						
Finlandia			Hitachi CPT2888	Salora K	Ipsalo 3				
Finlux	1013	160							
Finlux	1014	145							
Finlux	1014M	145 chassis Tatung							
Finlux	1015	165							
Finlux	1016	160							
Finlux	10B28	3000							
Finlux	10B35	3000							
Finlux	1101	165							
Finlux	1111	1000 Mono							
Finlux	1119	1000 Mono							
Finlux	1122	1000 Mono							
Finlux	1131	1000 Mono							
Finlux	1141	1000 Mono							
Finlux	1406	1000 Stereo							
Finlux	1412	1000 Stereo							
Finlux	1418	1000 Stereo							
Finlux	1422	1000 Stereo							
Finlux	14A1TX	Mono Plus 2 (MP2)							
Finlux	1622	3000							
Finlux	1632	1000 Stereo							
Finlux	1642	1000 Mono							
Finlux	2015	170							
Finlux	21A17	5000							
Finlux	21E17.	5000							
Finlux	21F12	5000							
Finlux	21S20	5100							
Finlux	21S22	5100							
Finlux	21S34	5000							
Finlux	21S38	5000							
Finlux	2472	2000							
Finlux	2482	2000							
Finlux	25C28	5000							
Finlux	25F14	5000							
Finlux	25K10	5000							
Finlux	25K30	5000							
Finlux	25S22	5100							
Finlux	25S24	5000							
Finlux	25S34	5000							
Finlux	25S38	5000							
Finlux	25S52	5000							
Finlux	2633	2000 Stereo							
Finlux	26E12.	5000							
Finlux	26E17.	5000							
Finlux	2872	2000							
Finlux	2882	2000							
Finlux	28C26	5100							
Finlux	28E17.	5000							
Finlux	28F12	5000							
Finlux	28K10	5000							
Finlux	28K30	5000							
Finlux	28S22	5100							
Finlux	28S24	5000							
Finlux	28S34	5000							
Finlux	28S38	5000							
Finlux	28W25	Eurodigi							
Finlux	3021F	3000							
Finlux	3024F	3000							
Finlux	3024F	3000							
Finlux	3028F	3000							
Finlux	3029	3000							
Finlux	3029V	3000							
Finlux	3029V	3000							
Finlux	32A21	3800							
Finlux	32W25	Eurodigi							
Finlux	32W35	Eurodigi							
Finlux	34A21	3600							
Finlux	34F12	3600							
Finlux	3621	3600							
Finlux	3624	3600							
Finlux	3628	3600							
Finlux	3720	CBT-9508							
Finlux	3815	C-8500							
Finlux	3821	8500							
Finlux	6021	C-8500							
Finlux	5021A65	5000							
Finlux	5021F12	5000							
Finlux	5025(S) 25524	5000							
Finlux	5025E17	5000							
Finlux	5025F12	5000							
Finlux	5025K10	5000							
Finlux	5025M14	5000							
Finlux	5025N65	5000							
Finlux	5028E17	5000							
Finlux	5028F12	5000							
Finlux	5028K10	5000							
Finlux	5028M14	5000							
Finlux	5028N65	5000							
Finlux	5029A65	5000							
Finlux	50F21	3600							
Finlux	50F25	3000							
Finlux	50F28	3000							
Finlux	50V29	3000							

Finlux	51A1TX	Mono Plus 2 (MP2)							
Finlux	55A1TX	Mono Plus 2 (MP2)							
Finlux	80D28	4000							
Finlux	82R100	Nokia/Salora/Luxor MZ-chassis							
Finlux	9560RC	3000							
Finlux	FTS5510	1000							
Finlux	FTS6310	1000							
Finlux	FTS7110	1000							
Finlux	FTS7111	1000							
Fisher	CFB1410P	Sanyo 80P							
Fisher	CFB1810P	Sanyo 80P							
Fisher	CFB2144	Sanyo E2-B21							
GEC	C1402	ITT	CVC801						
GEC	C1403	ITT	PICO-1A						
GEC	C1404	ITT	PICO-1A						
GEC	C1405	Hitachi	NP84						
GEC	C1409	Hitachi 2176							
GEC	C1410	Tatung 161							
GEC	C1502	Decca	160						
GEC	C1503	Decca	161						
GEC	C1650	Hitachi	NP8CQ						
GEC	C1655	ITT	PICO-1A						
GEC	C1656	ITT	PICO-1A						
GEC	C1657	Hitachi	NP84						
GEC	C1659	Hitachi 2176							
GEC	C1818		PIL						
GEC	C2000	Hitachi 2176							
GEC	C2001	Decca	140						
GEC	C2002	Decca	140						
GEC	C2004	Decca	171						
GEC	C2005	Decca	171						
GEC	C2026H	PIL CHASSIS							
GEC	C2036	PIL CHASSIS							
GEC	C2041	2040							
GEC	C2055	Hitachi	NP8CQ						
GEC	C2057	Hitachi	NP8CQ						
GEC	C2058	Hitachi 208/222							
GEC	C2067H	Hitachi	NP81CQ						
GEC	C2069H	Hitachi	NP81CQ						
GEC	C2073	2040							
GEC	C2074	2040							
GEC	C2085	Hitachi 2024							
GEC	C2086	Hitachi 2024							
GEC	C2087	Hitachi	NP81CQ						
GEC	C2087H	Hitachi	NP83CQ						
GEC	C2089H	Hitachi	NP83CQ						
GEC	C2090H	Hitachi	NP83CQ						
GEC	C2093H	Hitachi	NP84CQ						
GEC	C2095	Hitachi 2176							
GEC	C2096H	DECCA 140							
GEC	C2097H	DECCA 140							
GEC	C2100	2040							
GEC	C2102	DECCA 170/180							
GEC	C2103	2040							
GEC	C2107	2040							
GEC	C2108	2040							
GEC	C2111	2110 Series							
GEC	C2112	2110 Series							
GEC	C2113	2110 Series							
GEC	C2115	2040							
GEC	C2118	2110 Series							
GEC	C2119	2110 Series							
GEC	C2120	2110 Series							
GEC	C2121	2110 Series							
GEC	C2136	2110 Series							
GEC	C2137	2110 Series							
GEC	C2140	2110 Series							
GEC	C2141	2110 Series							
GEC	C2147	2110 Series							
GEC	C2148	2110 Series							
GEC	C2149	2110 Series							
GEC	C2150	Decca 160							
GEC	C2151	Decca 160							
GEC	C2153	Decca 171							
GEC	C2154	Decca 171							
GEC	C2200	Hitachi 2176							
GEC	C2201	Decca 146							
GEC	C2202	Decca 140							
GEC	C2204	Decca 171							
GEC	C2205	Decca 171							
GEC	C2206	2110H							
GEC	C2217	20AX Mk1							
GEC	C2218	20AX Mk1							
GEC	C2219	2110H							
GEC	C2233	20AX Mk1							
GEC	C2236H	20AX Mk1							
GEC	C2255	Hitachi	NP8CQ						
GEC	C2257	Hitachi	NP8CQ						
GEC	C2260H	20AX Mk1							
GEC	C2267H	Hitachi	NP81CQ						
GEC	C2269H	Hitachi	NP81CQ						
GEC	C2285	Hitachi 2224							
GEC	C2286H	Hitachi	NP83CQ						
GEC	C2287H	Hitachi	NP83CQ						
GEC	C2287H	Hitachi 2224							
GEC	C2288H	Hitachi 2234	NP81CQ Mk2						
GEC	C2289H	Hitachi	NP83CQ						
GEC	C2290H	Hitachi 2036	NP83CQ						
GEC	C2295	Hitachi 2176							
GEC	C2296	Decca	140						
GEC	C2297	Decca	140						
GEC	C2501	Decca	180						
GEC	C2502	Decca	180						
GEC	C2601H	2110H							
GEC	C2611H	2110 Series							
GEC	C2626H	2110 Series							
GEC	C2627	20AX Mk1							
GEC	C2628	20AX Mk1							
GEC	C2640	20AX Mk2							
GEC	C2641	20AX Mk2							
GEC	C2645	20AX Mk2							
GEC	C2659H	Hitachi CBP260	NP9A						
GEC	C2661H	Decca	180						
GEC	C2695H	Hitachi CBP260	NP9A						
GEC	C9502	Decca	180						
Genexia	CTV1001	Akura CX10	Boots CTV10R						
Genexia	CTV1001	Nikkai Baby 10	Osaki P10R						
Genexia	CTV1001	Samsung 1221R							
Genexxa	CTV10	Goodmans Compact-110							
Goldstar	see LG								
Goldstar	see LG								
Goldstar	see LG								
Goodmans	1404(A)	Alba CTV840	also Bush 1404, Hinary HIT140RC						
Goodmans	1410	Ferguson TX805							
Goodmans	1418R	CP325							
Goodmans	1425RS	CP375							
Goodmans	1430R/W	Onwa							
Goodmans	1445RS	Orion chassis	remote 076R0DG040						
Goodmans	1450T	Onwa							
Goodmans	145TT	Orion 14A chassis							
Goodmans	1476TS	CP005	2003 around £85						
Goodmans	147TT	same as Alba CTV841	also Bush 1452T						
Goodmans	1490T-IB	Formenti FPC203 (PCB marked FPC230.1)	remote SF5, LOPTx 1142.1695, LOPTr BU	Tuning - hold [...] for >5 sec, this is the same button that bring MAIN menu if quickly pressed.					
Goodmans	1495T-IB	Formenti FPC2002	2002 around £90 from Comet						
Goodmans	1790T		2003, £149						
Goodmans	2019R	Onwa							
Goodmans	2025RS	CP375							
Goodmans	2029T	Onwa							
Goodmans	2032	Nikkai NT20							

Goodmans	2043	Goldstar PC04A								
Goodmans	2045TS	CP375								
Goodmans	2050R	Tatung C Series								
Goodmans	2053T	Tatung (A Series ?)								
Goodmans	205N	CP365								
Goodmans	2065TS	Daewoo CP005								
Goodmans	2066TS	Daewoo CP005	2003, £99							
Goodmans	206NS	Daewoo CP380	serv. Mode - special remote R-30SVC							
Goodmans	2145TS	Daewoo CP375								
Goodmans	2155PF	Daewoo CP485								
Goodmans	215N	Daewoo CP365								
Goodmans	2160PF		2003 £180-£150; 2004 £140							
Goodmans	216NS	Daewoo CP380								
Goodmans	217NS	Daewoo (CP785)	=257NS							
Goodmans	2180	Nikkai								
Goodmans	218NS	Daewoo CP385								
Goodmans	2195T	Daewoo CP330								
Goodmans	255NS	Daewoo CP775								
Goodmans	256NS	Philips L6.2								
Goodmans	2575	Formenti F11								
Goodmans	257NS	Daewoo CP785								
Goodmans	258NS	Daewoo chassis	2003, £199							
Goodmans	285DPL	Stereo plus								
Goodmans	285NS	Daewoo CP775								
Goodmans	286NS/05	Philips L6.2AA chassis								
Goodmans	2875	Formenti F11								
Goodmans	288NS	Daewoo (CP785)	Multistandard PAL/SECAM, I, B/G							
Goodmans	295NS		2003, £199							
Goodmans	336NS	F16								
Goodmans	336NS-A	F19								
Goodmans	3375	Formenti F11								
Goodmans	5160TT	HinariCT15/ST200/VT200/CDTV2	Hinari CT14							
Goodmans	C141	Nikkai								
Goodmans	C210	10" remote control TV	2003, £179							
Goodmans	CTV20XRT	Osaki 20	Fidelity ZX3000							
Goodmans	CTV2R	Nikkai TLG2121								
Goodmans	CTV2T	Nikkai TLG2121								
Goodmans	CTX14X	Fidelity ZX4000	Jackson Mk2							
Goodmans	F28WTF	FPC2001 (TWIST) flat screen	2003 around £350							
Goodmans	F32WTF	FPC2001 (TWIST) flat screen	2003 around £499							
Goodmans	FST51TT	Murphy 3510T	Murphy CTV3540T							
Goodmans	GD2580	Ferguson TX92								
Goodmans	GD2580D	TX92F								
Goodmans	GD2880A	ICC9								
Goodmans	GD2880B	FTX92								
Goodmans	GD2880D	TX92F								
Goodmans	GTV147	11AK08, 11AK20M-6(after 1999)				AK20 prod.code: 10000675				
Goodmans	GTV148T	11AK08, 11AK20M-6(after 1999)				AK20 prod.code: 10000676				
Goodmans	GTV14DVD	chassis P1420 (TV+DVD)	2003, £139			PCB marked 0707-A20261-03 (	LOPTx CF0801, LOPTr 2SD2599, chopper Tr 2SD2500, Micro CTV322S V1.2 (PCA84C			
Goodmans	GTV14DVDXI	TV +DVD	2003, £159							
Goodmans	GTV211	PT9601 (Bush 2027T)								
Goodmans	GTV257	11AK19-5								
Goodmans	GTV288	11AK19-8A								
Goodmans	GTV288SIL	11AK19E3, 11AK19P4, 11AK19P5	2000-2002			AK19 prod.code: 10006762				
Goodmans	GTV34R2	11AK20M-6	1999-			AK20 prod.code: 10000677				
Goodmans	GTV34R6SIL	11AK20SE1								
Goodmans	GTV34RDVD	chassis P1420 (TV+DVD)	2002			PCB marked 0707-A20261-03				
Goodmans	GTV34RDVDXI	11AK46 (TV+DVD)								
Goodmans	GTV34T2	11AK20M-6	1999-			AK20 prod.code: 10000678				
Goodmans	GTV34T6SIL	11AK36								
Goodmans	GTV370VCRX		serv.mode see Bush BTV16, BTV20							
Goodmans	GTV371VCR	Bush BTY17, Tatung TVC563, deck OVD-6	PCB marked TM9423A, video VM9162A			Micro OEC0078A, option codes EEPROM address 100H				
Goodmans	GTV372VCR	Orion chassis				Micro OEC0093B				
Goodmans	GTV376VCR		2004 £89							
Goodmans	GTV400	Grundig G1000								
Goodmans	GTV401	Grundig G1000								
Goodmans	GTV48T2	PT11 (??)								
Goodmans	GTV51N1	11AK19				remote				
Goodmans	GTV51N2DVD		2004, £165							
Goodmans	GTV51N3BLU4	11AK19				remote				
Goodmans	GTV51NDVD	11AK?? +DVD	2004, £199							
Goodmans	GTV62W1SIL	11AK37-11								
Goodmans	GTV66N3	11AK19P4								
Goodmans	GTV66W1	11AK19B1	Micro SDA5457-B001							
Goodmans	GTV66W2 28ZKQ	4400								
Goodmans	GTV69RF2	11AK37-10 (10019793)	2003							
Goodmans	GTV69W2DT	11AK33 with digibox	2004 £360							
Goodmans	GTV69W3BLK	11AK37-8	2002							
Goodmans	GTV69W3SIL	11AK19Pro or 11AK37	11AK37 after 2002							
Goodmans	GTV69W5SIL	11AK19P5 or 11AK37	11AK37 after 2002			AK19 prod.code:10014298, AK37 prod.code:10014462				
Goodmans	GTV76RF1	11AK37-10 (10019792)	2003							
Goodmans	GTV76W1	11AK19								
Goodmans	GTV76W2SIL	11AK19P2, 11AK19P5								
Goodmans	GTV76W4SIL	11AK37-6	2002, 2003							
Goodmans	GTV9200	Samsung C1125								
Goodmans	K1405T		2003 £65-£69, 2004 £65							
Goodmans	K2005T		2004, £99							
Goodmans	K2105	11AK30A4	2003 £130, 2004 £120							
Goodmans	K24W10		2004 £199							
Goodmans	K28W05		2003 around £200-£250, 2004 £199							
Goodmans	Q9001	Alba PTV9C	Samsung BT110							
Goodmans	RC7051	LG D17 chassis								
Goodmans	TD1540	TV+DVD	2003, £179							
Goodmans	TVC100S	combi	2004, £99							
Goodmans	TVC1400	CP310 (Daewoo)	Ferguson FG14CB12V			Daewoo DVT1484D				
Goodmans	TVC141	CP420 (Daewoo, K-Mecha Deck)								
Goodmans	TVC142T	CP420 (Daewoo, K-Mecha Deck)								
Goodmans	TVC143TS	CP082 (Daewoo)	2003, £140							
Goodmans	TVC145TW	CP420 (Daewoo, K-Mecha Deck)	Daewoo DVT14F8PA							
Goodmans	TVC146T	CP420 (Daewoo, K-Mecha Deck)								
Goodmans	TVC146TWS	CP420 (Daewoo, K-Mecha Deck)	Daewoo DVT14F6PA							
Goodmans	TVC147TWS	CP082 (Daewoo)	2003, £149							
Goodmans	TVC14VP	CP310 (Daewoo)	Ferguson FG14CB12V			Daewoo DVT1484D				
Goodmans	TVC201T	CP420 (Daewoo, K-Mecha Deck)								
Goodmans	TVC202TS	CP082 (Daewoo)	2003, £179							
Goodmans	TW28D11		2003 £300-£350; 2004 £280							
Goodmans	TW32D11		2003 around £450							
Goodmans	UG0FL37M12G230	see Goodmans 1490T-IB								
Goodmans	W280NS	F16 or F19 (depends on the year)								
Goodmans	W282NS	F19								
Goodmans	W282NS-T	FPC2001 (Formenti-Seleco)								
Goodmans	W288NS	F16 or F19 (depends on the year)								
Goodmans	W288NS-A	F19								
Goodmans	W321NS	F16 or F19 (depends on the year)								
Goodmans	W321NS-A	F19	LOPTx 1372.0052A (equiv. 1362.5001A, HR8770, FBT40828)							
Goodmans	W322NS	F19								
Goodmans	W325NS-T	FPC2001 (Formenti-Seleco)	2003 around £380							
Goodmans	W32T1	PT92								
Graetz	25C60	ITT Core 110								
Graetz	Burggraf 2891	Nokia digital chassis B-E2								
Granada	12C011	Thorn 1790								
Granada	14C011	Thorn 1790								
Granada	14C012	Thorn TX90								
Granada	14C013	Thorn TX90								
Granada	14C021	Sanyo CTP3141	Tashiko 14D961							
Granada	14C022	Sanyo E2	Sanyo CTP3144							
Granada	14C031	Toshiba 140E4B								
Granada	14C032	Toshiba 140E4B								
Granada	14C041	Sharp C1410HD								
Granada	14C051	Philips 1014								
Granada	14C052	Philips CTX	Philips 2206							
Granada	14C061	PanasonicM12H	Panasonic TC430G							
Granada	14C062	PanasonicM12C	Panasonic TC431GR							
Granada	14C063	Panasonic M12	TC450							
Granada	14C071	Sony XE3 KV1430UB								
Granada	14C111	Mitsubishi CP1424B								
Granada	14D031	Toshiba 14E7B								
Granada	14D032	Toshiba 145E7B								
Granada	14D041	Sharp C1411								

Granada	14D061	Panasonic TC1460							
Granada	14D121	Hitachi 1474							
Granada	14D122	Hitachi 1476							
Granada	14E011.	Ferguson 14C2 / 14J2							
Granada	14E041.	Sharp C1420							
Granada	14E071.	Sony KV1460UB							
Granada	14E072.	Sony 1462UB							
Granada	14E091.	ITT CP3120							
Granada	14E191.	Network NE14CD							
Granada	14E211.	Fidelity 1405S							
Granada	14E212.	Fidelity 1405R							
Granada	14E252.	Hinari TVA1							
Granada	16C011	Thorn TX9	Ferguson 37801						
Granada	16C012	Thorn TX9	Ferguson 37023						
Granada	16C051	Philips 2016							
Granada	16C052	Philips CTX	Philips 2216						
Granada	16C151	GEC 1657							
Granada	16C152	GEC 1658							
Granada	16E061.	Panasonic TC1675							
Granada	16E221.	Zanussi 16ZB32							
Granada	20C011	Ferguson 1X100	Ferguson 20C4						
Granada	20C012	Thorn TX9	Ferguson 37493						
Granada	20C021	Hitachi 2044 / 2074							
Granada	20C021	Sanyo CTP6134							
Granada	20C022	Hitachi 2076							
Granada	20C022	Sanyo 83P-D20	Sanyo CTP6135						
Granada	20C051	Philips 2036	Panasonic TC2061						
Granada	20C061	Panasonic U5							
Granada	20C071	Sony XE3	Sony KV2060UB						
Granada	20C081	Grundig 512201							
Granada	20C082	Grundig 512406							
Granada	20D031	Toshiba 202R5B							
Granada	20E091.	ITT CT3326							
Granada	20E091.	ITT Monoprint B	ITT CT3315M						
Granada	20E221.	Zanussi 20ZA374							
Granada	22C011	Ferguson 22B5							
Granada	22C011	Ferguson TX10							
Granada	22C021	Sanyo CTP7133							
Granada	22C022	Sanyo CTP7134							
Granada	22C023	Sanyo 80P	Sanyo CTP7135						
Granada	22C031	Toshiba 222E5B							
Granada	22C032	Toshiba 222R5B							
Granada	22C051	Philips 5240							
Granada	22C052	Philips 5751							
Granada	22C053	Philips CTX	Pye 2060						
Granada	22C061	Panasonic U5	Panasonic TX5500						
Granada	22C071	Sony YE2	Sony KV2212UB						
Granada	22C081	Grundig 562201							
Granada	22C111	Mitsubishi CT2224B							
Granada	22C112	Mitsubishi CT2227BM							
Granada	22C121	Hitachi 2276							
Granada	22C122	Hitachi 2278							
Granada	22C151	GEC 2295							
Granada	22D051	Philips 2061							
Granada	26C031	Toshiba 261T							
Granada	26C061	Panasonic U5W	Panasonic TX2656						
Granada	36C031	Toshiba 159R4B							
Granada	36C051	Philips 2309							
Granada	36C091	ITT CT3725							
Granada	36C111	Mitsubishi CT1501BM							
Granada	36D121	Hitachi 1596							
Granada	41C061	Panasonic U5	Panasonic TX1752						
Granada	51C011	Ferguson TX100 51A3							
Granada	51C031	Toshiba 211E4B							
Granada	51C032	Toshiba 212T4B							
Granada	51C033	Toshiba 212R4B							
Granada	51C051	Philips 4829							
Granada	51C061	Panasonic U5							
Granada	51C062	Panasonic TX1							
Granada	51C122	Hitachi 2158							
Granada	51D031	Toshiba 210R6B							
Granada	51D051	Philips 2340							
Granada	51D061	Panasonic TC2175							
Granada	51D111	Mitsubishi CT2117BM							
Granada	51D112	Mitsubishi CT2101TX							
Granada	51D121	Hitachi 2176							
Granada	51D123	Hitachi 2174							
Granada	51D124	Hitachi 2178							
Granada	51E011.	Ferguson TX100 51G3							
Granada	51E021.	Sanyo CTP2146							
Granada	51E051.	Philips 1551							
Granada	51E071.	Sony KV21MXU							
Granada	51E072.	Sony AE1 KV21XMTU							
Granada	51E073.	Sony SX KV21XRTU							
Granada	59C121	Hitachi 2568							
Granada	59D121	Hitachi 2476							
Granada	59D122	Hitachi 2478							
Granada	59E031.	Toshiba 258T							
Granada	59E051.	Philips 2370							
Granada	59E052.	Philips 3570							
Granada	59E221.	Zanussi 24ZM360							
Granada	59E222.	Zanussi 24ZM366							
Granada	59E223.	Zanussi 24ZS366							
Granada	66D121	Hitachi 2888							
Granada	66E071.	Sony SX							
Granada	69E221.	Zanussi 28ZM360							
Granada	78E061.	Panasonic TX3370							
Granada	C09EN1	Panasonic 9200							
Granada	C09EV1	Philips 10CX1120							
Granada	C10EV1	Toshiba 1071							
Granada	C13KV1	Sony 1320							
Granada	C14AS1	Sanyo CPT3131							
Granada	C14AY1/2	Sharp							
Granada	C14BA1	GEC C1405H	Hitachi NP84 Mk1						
Granada	C14BS1	Sanyo CPT3131							
Granada	C14EA3	GEC 1409							
Granada	C14EP1	Philips							
Granada	C14EP3	Philips 14CE1201							
Granada	C14EP4	Philips 14CN2201							
Granada	C14ER1	Panasonic TC1470							
Granada	C14ER4	Panasonic TC1475							
Granada	C14ES1	Sanyo CBP3144							
Granada	C14ES2	Sanyo CBP3144							
Granada	C14ES3	Hinari CT5							
Granada	C14ET2	Toshiba 145							
Granada	C14ET3	Toshiba 145R							
Granada	C14EV1	Hinari CT4							
Granada	C14EV2	Panasonic TC1480							
Granada	C14EJ2	Sharp 1490							
Granada	C14EV3	ITT CP3120							
Granada	C14EV3	ITT CP3126							
Granada	C14EV4	Panasonic TC1485							
Granada	C14FD1	Hinari CT17							
Granada	C14FD3	Hinari CT18							
Granada	C14FS1	Hinari CT17							
Granada	C14FS1	Sanyo CBP3001							
Granada	C14FS2	Sanyo CBP3011							
Granada	C14FS5	Sanyo OEM							
Granada	C14FT3	JVC C140EY							
Granada	C14GP1	Philips 14CN2001							
Granada	C14GP2	Philips 14GR1021							
Granada	C14GP3	Philips 14GR1021	Tashiko						
Granada	C14GP4	Philips 14GR1221	Tashiko						
Granada	C14GP5	Philips 14GR1221							
Granada	C14GS1	Sanyo CBP3011							
Granada	C14GS1	Sanyo CBP3012							
Granada	C14GS5	Sanyo CBP3011							
Granada	C14GY1	Pye 37KN2010							
Granada	C14GY2	Pye 37KN2012							

Granada	C14HS5	Sanyo CBP3011							
Granada	C14HS5	Sanyo CBP3012							
Granada	C14HT2	JVC 1480							
Granada	C14HV2	Sharp C1421HBK							
Granada	C14HY2	Pye 37KV1242							
Granada	C14HY2	Sharp C1431HBK							
Granada	C14JS2	Sanyo CBP3012							
Granada	C14KS2	Sanyo CBP3015							
Granada	C14KS2	Sanyo CBP3018							
Granada	C14KS3	Sanyo CBP3024							
Granada	C14KX2	Toshiba 1400R							
Granada	C14LP3	Philips 1221B							
Granada	C14LX2	Toshiba 1400R							
Granada	C14LZ2	Nokia Mono Plus							
Granada	C14LZ3	Nokia OEM							
Granada	C14MN2	Panasonic TC14S1R							
Granada	C14MP2	Philips 14PT1277							
Granada	C14MY3	Sharp VT3700							
Granada	C14MZ2	Nokia OEM							
Granada	C14NN2	Panasonic TC14S1R							
Granada	C14NN4	Panasonic TX14S1T							
Granada	C14NP2	Philips 14136B							
Granada	C14NP4	Philips 14136B							
Granada	C14NS2	Sanyo EC2-A14							
Granada	C14NX4	Toshiba 1510RT							
Granada	C14PX4	Panasonic TX14S2T							
Granada	C14PP2	Philips 14PT1332							
Granada	C14PP3	Philips 14PV162							
Granada	C14PS2	Sanyo 14M1							
Granada	C14RN2	Panasonic TC14B3R							
Granada	C14RN2	Panasonic TX14B3T							
Granada	C14RP3	Philips 14PV172							
Granada	C16ER3	Panasonic TC1665							
Granada	C16ER3	Panasonic TC1675							
Granada	C16ES1	Sanyo CP14144							
Granada	C16ES2	Sanyo CP14144							
Granada	C16ES3	Sanyo CP14144							
Granada	C16ES4	Sanyo CP14144							
Granada	C16EV1	Nordmende 3636							
Granada	C16EV3	Decca 8485							
Granada	C16EV3	Ferguson 16A21							
Granada	C16EV3	Panasonic 8454							
Granada	C16EV5	Ferguson 16A3							
Granada	C17EV7	Seleco 17466							
Granada	C20AA4	GEC C2087H	Hitachi NP83CQ						
Granada	C20BY4	Rediffusion Mk 4A							
Granada	C20CD4	Tatung 145X							
Granada	C20DS4	Sanyo CPT3141							
Granada	C20EC3	Sanyo CTP6143							
Granada	C20ED1	Decca DN1672							
Granada	C20ED1	Decca DT1455							
Granada	C20ED1	Decca DT1655							
Granada	C20EK1	ITT 3307							
Granada	C20EK3	ITT CT3327							
Granada	C20EK5	ITT CT3327T							
Granada	C20ET3	Ferguson 2042							
Granada	C20ET3	Ferguson 20H2							
Granada	C20ET4	Ferguson 20E2H							
Granada	C20ET5	Ferguson 20A3T							
Granada	C20ET5	Ferguson 20C3H							
Granada	C20EV1	B&O M20							
Granada	C20EV2	Mitsubishi CT2033							
Granada	C20EV3	Sanyo CTP6144							
Granada	C20EV4	Ferguson 20A2T							
Granada	C20EV4	Ferguson 20E1H							
Granada	C20EV4	Mitsubishi CT20A2							
Granada	C20EV5	Mitsubishi CT2078							
Granada	C20EX3	Mitsubishi CT2040							
Granada	C20EX5	Fidelity 20T0							
Granada	C20EX5	Fidelity C20T04							
Granada	C20EY5	Pye 51KT2366							
Granada	C20RP3	Philips 20PV164							
Granada	C20RY1/2/3	Rediffusion Mk3							
Granada	C20TY1/2/3/5	Rediffusion Mk3							
Granada	C20VA1	GEC C2026H							
Granada	C20WY1/2/3/5	Rediffusion Mk4							
Granada	C20XA1	GEC C2067H	Hitachi NP81CQ						
Granada	C22AA4	GEC C2287H	Hitachi NP83CQ						
Granada	C22BY4	Rediffusion Mk 4A							
Granada	C22CD4	Tatung 145X							
Granada	C22DS4	Sanyo CPT3141							
Granada	C22ET3	Toshiba 222R5							
Granada	C22ET4	Ferguson 22D2H							
Granada	C22EV1	Pye 56EK2610							
Granada	C22EV5	Hitachi 2278							
Granada	C22EV5	Pye 56EK2615							
Granada	C22EV5	Sony 2217							
Granada	C22EV7	Nordmende 5432							
Granada	C22RY1/2/3	Rediffusion Mk3							
Granada	C22TY1/2/3/5	Rediffusion Mk3							
Granada	C22VA1	GEC C2236H							
Granada	C22VA3	GEC C2260H							
Granada	C22WY1/2/3/5	Rediffusion Mk4							
Granada	C22XA1	GEC C2267H	Hitachi NP81CQ						
Granada	C22XA5	GEC C2269H	Hitachi NP81CQ						
Granada	C24EV7	Seleco 24497							
Granada	C26BY4	Rediffusion Mk 4A							
Granada	C26BZ7	Salora J							
Granada	C26DS4	Sanyo CPT3141							
Granada	C26EK1	ITT 3715							
Granada	C26ES3	Sony 2762							
Granada	C26ES5	Hitachi 2658							
Granada	C26ET3	Ferguson 26D2H							
Granada	C26ET5	Ferguson 26D3H							
Granada	C26ET5	Ferguson 26D3H							
Granada	C26ET6	Toshiba 261T							
Granada	C26EV3	Mitsubishi CT2627							
Granada	C26RY1/2/3	Rediffusion Mk3							
Granada	C26TY1/2/3/5	Rediffusion Mk3							
Granada	C26WY1/2/3/5	Rediffusion Mk4							
Granada	C27EK7	ITT 3888							
Granada	C27EK8	ITT 888							
Granada	C27EK9	ITT 888							
Granada	C36EA3	GEC C1502							
Granada	C36EA4	GEC C1503							
Granada	C36EP1	Philips 15CE1010							
Granada	C36EP3	Philips 15CE1210							
Granada	C36EP4	Philips							
Granada	C36FD6	Tatung							
Granada	C36FY5	Pye 38KE1185							
Granada	C36GP5	Philips 15CE1518							
Granada	C36GP6	Philips 15GR2530							
Granada	C36GX2	Toshiba 155R9BZ							
Granada	C36HP6	Philips 15GR2530							
Granada	C36HX2	Toshiba 156R9BT							
Granada	C36JP6	Philips 2331							
Granada	C36JS2	Sanyo DeGraaf							
Granada	C37JK7	Panasonic HTZ							
Granada	C41EB4	Sanyo 1747							
Granada	C41EP4	Philips 17CE1230							
Granada	C41EP5	Philips 17CE1530							
Granada	C41EP6	Philips 17CE1538							
Granada	C41EV7	Seleco? (Sharp?) 1746							
Granada	C41EY5	Pye 43KT2196							
Granada	C41FK5	Panasonic TX1786							
Granada	C41FP2	Philips 17CE1230							
Granada	C41FS3	Sanyo CBP1748							
Granada	C41FS5	Sanyo CBP1740							
Granada	C41FS6	Sanyo CBP1748							

Granada	C41GS5	Sanyo CBP1748								
Granada	C41HS2	Sanyo	Granada							
Granada	C41HS4	Sanyo E4 chassis	DeGraaf							
Granada	C41JH4	Hitachi C1709T								
Granada	C41JP2	Philips 17GR2341								
Granada	C41JP6	Philips 17GR2341								
Granada	C41KH4	Hitachi C1719T								
Granada	C41LX4	Toshiba 1721TB								
Granada	C41MP4	Philips 17PT166A								
Granada	C41NX4	Toshiba 1722TB								
Granada	C41NX4	Toshiba 1752TB								
Granada	C41PX4	Toshiba 1752TB								
Granada	C49JY2	Pye 1256								
Granada	C49KT4	Ferguson B49F								
Granada	C49LR4	Goldstar 9902F								
Granada	C49MZ2	Nokia 5124UK								
Granada	C49NT4	Ferguson T49F								
Granada	C51EA3	GEC C2150								
Granada	C51EB5	Sanyo 2148								
Granada	C51EB5	Sanyo 2149								
Granada	C51EC5	Sanyo CBP2146								
Granada	C51EG3	Grundig 5245								
Granada	C51EG3	Grundig 55245								
Granada	C51EK7	ITT 3487								
Granada	C51EP1	Philips 21CE1051								
Granada	C51EP3	Philips 21CE1250								
Granada	C51EP4	Philips 21CE1251								
Granada	C51EP5	Philips 21CE1558								
Granada	C51EP6	Philips 21CE1550								
Granada	C51EP7	Philips 7650								
Granada	C51ER1	Panasonic 2178								
Granada	C51ER2	Panasonic TX21								
Granada	C51ER2	Panasonic XC21								
Granada	C51ER3	Panasonic XC21								
Granada	C51ER4	Panasonic TC2175								
Granada	C51ER5	Panasonic TC2172								
Granada	C51ES1	Hitachi CPT2174								
Granada	C51ES1	Sanyo CBP2174								
Granada	C51ES3	Hitachi CPT2176								
Granada	C51ES3	Sanyo CBP2176								
Granada	C51ES5	Sanyo CBP2146								
Granada	C51ES6	Hitachi CPT2158								
Granada	C51ES7	Hitachi CPT2188								
Granada	C51ET1	Toshiba 213D								
Granada	C51ET3	Toshiba 213R								
Granada	C51ET3	Toshiba 231R								
Granada	C51ET4	Ferguson 51A2W								
Granada	C51ET4	Toshiba 214R								
Granada	C51ET4	Toshiba 51A2W								
Granada	C51ET5	Toshiba 214T								
Granada	C51ET7	Toshiba 210T								
Granada	C51EV3	JVC 210								
Granada	C51EV4	Mitsubishi CT2117								
Granada	C51EV6	Selec0 21566								
Granada	C51EV6	Sharp 2156								
Granada	C51EV3	Hinari CT8								
Granada	C51EY3	Pye 52KE1512								
Granada	C51EY5	Pye 51HT2366								
Granada	C51EY5	Pye 52KE2406								
Granada	C51EY6	Pye 52KE1515								
Granada	C51EZ4	Salora OEM								
Granada	C51EZ5	Salora OEM								
Granada	C51FA5	Mitsubishi CT2146								
Granada	C51FD3	Hinari CT14								
Granada	C51FK3	Panasonic TC2185								
Granada	C51FK5	Panasonic TX21								
Granada	C51FP2	Philips								
Granada	C51FP3	Philips 21CE1557								
Granada	C51FP4	Philips 21CE1558								
Granada	C51FP5	Philips 21CE1557								
Granada	C51FP6	Philips 21CE1558								
Granada	C51FR1	Meta								
Granada	C51FR2	Meta								
Granada	C51FR3	Panasonic TC2185								
Granada	C51FR5	Goldstar 2175								
Granada	C51FS2	Sanyo CBP2147								
Granada	C51FS3	Hinari CT14								
Granada	C51FS4	Sanyo CBP2148								
Granada	C51FS6	Sony KV211XMT								
Granada	C51FT2	JVC C210EKY								
Granada	C51FV2	Sharp CV2121H								
Granada	C51FV4	Sharp CV2123H								
Granada	C51FX1	Toshiba 214E7B								
Granada	C51FX2	Toshiba 214R7B								
Granada	C51FX3	Toshiba 215R8B								
Granada	C51FX4	Toshiba 214T7B								
Granada	C51FX5	Mitsubishi CT2146								
Granada	C51FX5	Toshiba 215T								
Granada	C51FX6	Sony KV211XTM								
Granada	C51FX7	Sony KV211XTM								
Granada	C51FY5	Pye 52KE1585								
Granada	C51FZ1	Salora OEM								
Granada	C51FZ2	Salora OEM								
Granada	C51FZ4	Salora OEM								
Granada	C51FZ5	Salora (DeGraaf) CST2151								
Granada	C51FZ5	Salora OEM								
Granada	C51GK2	Panasonic TC2195								
Granada	C51GK4	Panasonic TX3								
Granada	C51GMW	Finlux 3621								
Granada	C51GP2	Philips 21GR2350								
Granada	C51GP3	Philips 21GR2550								
Granada	C51GP4	Philips 21GR2550								
Granada	C51GP5	Philips 21GR2550								
Granada	C51GP6	Philips 21GR2550								
Granada	C51GS2	Sanyo CBP2162								
Granada	C51GV2	Sharp CV2131H								
Granada	C51GV4	Sharp CV2133H								
Granada	C51GX2	Toshiba 216R9B								
Granada	C51GX4	Toshiba 216T9B								
Granada	C51GXW	Sony K VX2529U								
Granada	C51GY4	Pye 52KV2525								
Granada	C51GZ5	Salora OEM								
Granada	C51HA5	Mitsubishi CT2154TX								
Granada	C51HK2	Panasonic TX21R1								
Granada	C51HK4	Panasonic TX21T1								
Granada	C51HK6	Panasonic TX21								
Granada	C51HRW	Finlux 3621F								
Granada	C51HS2	Sanyo CBP2162								
Granada	C51HS4	Sanyo CBP2152								
Granada	C51HS5	Sanyo CBP2182								
Granada	C51HSW	Sanyo CBP2149								
Granada	C51HV4	Sharp CV2133H								
Granada	C51HX4	Toshiba 2101TB								
Granada	C51HY2	Pye 52KV2523								
Granada	C51HY5	Pye 6725								
Granada	C51HZ5	Luxor 5595	N-chassis	DeGraaf						
Granada	C51JG4	Grundig 5544								
Granada	C51JG7	Grundig 5544								
Granada	C51JH4	Hitachi C2118T								
Granada	C51JP4	Philips 21GR2554								
Granada	C51JS2	Sanyo CBP3012	DeGraaf							
Granada	C51JY2	Pye 1528								
Granada	C51JZ5	Nokia	N-chassis							
Granada	C51KF6	Finlux 5021F12 (chassis 5000)								
Granada	C51KH4	Hitachi C2119T								
Granada	C51KP6	Philips 2731								
Granada	C51KS4	Sanyo	DeGraaf							
Granada	C51KS5	Sanyo CBP2168								
Granada	C51KS6	Sanyo	DeGraaf							

Granada	C51KX4	Toshiba 2100TB							
Granada	C51KX4	Toshiba 2103TB							
Granada	C51LH4	Hitachi C2114T							
Granada	C51LP6	Philips 2731							
Granada	C51LS2	Sanyo							
Granada	C51LS4	Sanyo							
Granada	C51LZ6	Nokia OEM							
Granada	C51LZ8	Nokia OEM							
Granada	C51MA5	Mitsubishi CT21A5ST							
Granada	C51MH4	Hitachi C214T							
Granada	C51MH6	Hitachi C2164TN							
Granada	C51MP6	Philips 21PT532A							
Granada	C51MP7	Philips 21522B							
Granada	C51MS2	Sanyo OEM							
Granada	C51MS4	Sanyo CB5146							
Granada	C51MS5	Sanyo EC1-B21	1997						
Granada	C51MT6	Ferguson D51ND							
Granada	C51MX3	Toshiba 2145DB							
Granada	C51MX4	Toshiba 2141TB							
Granada	C51MX6	Toshiba 2132DB							
Granada	C51MZ6	Finlux chassis 5000							
Granada	C51NH6	Hitachi C2146TN							
Granada	C51NN6	Panasonic TX21MN1							
Granada	C51NP4	Philips 21PT165B							
Granada	C51NP6	Philips 21PT442B/05	GR2.2						
Granada	C51NS4	Sanyo CB5156G							
Granada	C51NT6	Ferguson TX91							
Granada	C51PN4	Panasonic TX21S1T							
Granada	C51PN6	Panasonic TX21ND1							
Granada	C51PP4	Philips 21PT1532	Anubis A						
Granada	C51PS6	Sanyo 21D1							
Granada	C51PX6	Toshiba 2163DB							
Granada	C51RH6	Hitachi C2156TN							
Granada	C51RH7	Hitachi C2186TN							
Granada	C51RN4	Panasonic TX21S3T							
Granada	C51RP4	Philips 21PT1653	L6.2						
Granada	C51RS4	Sanyo 21MT2							
Granada	C51RS6	Sanyo 21BN1							
Granada	C51RX6	Toshiba 2173DB							
Granada	C56EZ4	Salora OEM							
Granada	C56EZ5	Salora OEM							
Granada	C56FZ1	Salora OEM							
Granada	C56FZ2	Salora OEM							
Granada	C56FZ4	Salora OEM							
Granada	C56FZ5	Salora OEM							
Granada	C56GZ5	Salora OEM							
Granada	C56NZ8	Nokia 6197UK							
Granada	C59EB7	Sanyo 2566							
Granada	C59EG5	Grundig 63375							
Granada	C59EK3	ITT 3576							
Granada	C59EK5	ITT 35467							
Granada	C59EK7	ITT 35767							
Granada	C59EP2	Philips 24CE4579	2B						
Granada	C59EP3	Philips 24CE3270	CP110						
Granada	C59EP5	Philips				Philips			
Granada	C59EP6	Philips 24CE3570	CP110						
Granada	C59ER3	Panasonic 2475							
Granada	C59ER5	Panasonic TX2472							
Granada	C59ER6	Panasonic 2464							
Granada	C59ER7	Panasonic TX2450							
Granada	C59ES3	Hitachi CPT2476							
Granada	C59ET5	Toshiba 255T							
Granada	C59ET7	Toshiba 258T							
Granada	C59EV1	Sharp 2448							
Granada	C59EV5	Selec 24567							
Granada	C59EV5	Sharp 2456							
Granada	C59EV6	Sharp 2449							
Granada	C59EV7	Selec 24487							
Granada	C59EV7	Selec 24569							
Granada	C59EV7	Sharp 2456							
Granada	C59EY3	Pye 59KE2703							
Granada	C59EY5	Pye 59KE2706							
Granada	C59EY6	Dynatron 106							
Granada	C59FK4	Panasonic TX2482							
Granada	C59FK5	Panasonic TX2482							
Granada	C59FP2	Philips 24CE3271	CP110						
Granada	C59FP3	Philips 24CE3271	CP110						
Granada	C59FP4	Philips 24CE3588	CP110						
Granada	C59FP5	Philips 24CE3578	CP110						
Granada	C59FP6	Philips 24CE3588	CP110						
Granada	C59FX7	Sony X25T							
Granada	C59FY5	Pye 59KE3785							
Granada	C59FZ4	Hitachi CPT2658	Salora L						
Granada	C59FZ6	Salora OEM							
Granada	C59FZ7	Hitachi C25P759							
Granada	C59GK4	Panasonic TX2492							
Granada	C59GK5	Panasonic TX24T1							
Granada	C59GK6	Panasonic TX24W1							
Granada	C59GP2	Philips 25GR3271							
Granada	C59GP4	Philips 25CE6570							
Granada	C59GP6	Philips 25GR5763							
Granada	C59GP7	Philips 25CE6574							
Granada	C59GS4	Sanyo CBP2552							
Granada	C59GX7	Toshiba 2590							
Granada	C59GY7	Pye 5637							
Granada	C59GZ6	Salora OEM							
Granada	C59GZ7	Hitachi C25P759							
Granada	C59HA4	Hitachi 5029							
Granada	C59HP6	Philips 25CE5764							
Granada	C59HP7	Philips 25GR9763							
Granada	C59HS4	Sanyo							
Granada	C59HY5	Pye 63KE6725							
Granada	C59HZ5	Luxor (Salora N)	6395			DeGraaf			
Granada	C59HZ6	Salora	OEM			Finlandia			
Granada	C59JG4	Grundig 6346							
Granada	C59JG7	Grundig 6356							
Granada	C59JP4	Philips 25CE6570							
Granada	C59JP5	Philips 25ST1550							
Granada	C59JP6	Philips 25ST1724							
Granada	C59JP7	Philips 5760							
Granada	C59JP8	Philips 1750							
Granada	C59JP9	Philips 1724							
Granada	C59JY4	Pye 6772							
Granada	C59JZ5	Nokia	N-chassis			Finlandia			
Granada	C59KP6	Philips 25ST2761							
Granada	C59KZ6	Nokia 25N8C	Eurostereo 2 B-F			Finlandia			
Granada	C59LH4	Hitachi C2514T							
Granada	C59LH7	Hitachi C2574TN							
Granada	C59LP6	Philips 25PT482A							
Granada	C59LZ6	Nokia	OEM			Finlandia			
Granada	C59LZ8	Nokia	OEM			Finlandia			
Granada	C59MA4	Mitsubishi CT25M3TX							
Granada	C59MA6	Mitsubishi CT25A5ST							
Granada	C59MH6	Hitachi C2565TN							
Granada	C59MN6	Panasonic TX25X1							
Granada	C59MN7	Panasonic TX25X1DP							
Granada	C59MP5	Philips 25410A							
Granada	C59MP7	Philips 25PT532B							
Granada	C59MP8	Philips 25822AS							
Granada	C59MX3	Toshiba 2545DB							
Granada	C59MX5	Toshiba 2535DB							
Granada	C59MX7	Toshiba 2539DB							
Granada	C59MZ5	Nokia	OEM			Finlandia			
Granada	C59MZ6	Finlux (Nokia)	5000 chassis						
Granada	C59MZ8	Nokia 5000 with built-in sat. receiver				Finlandia			
Granada	C59NA4	Mitsubishi CT25M5BT							
Granada	C59NH6	Hitachi C2546TN							
Granada	C59NH7	Hitachi C2576TNY							
Granada	C59NN6	Panasonic TX25MD1							

Granada	C59NN7	Panasonic TX25AD1DP								
Granada	C59NP5	Philips 25632AC								
Granada	C59NP6	Philips 25421								
Granada	C59NP7	Philips 25727BP								
Granada	C59NP8	Philips 259021								
Granada	C59NX5	Toshiba 2555DB								
Granada	C59NX6	Toshiba 2552DB								
Granada	C59PH7	Hitachi C2548TN								
Granada	C59PS4	Sanyo 25MT1								
Granada	C59PX6	Toshiba 2563DB								
Granada	C59RH6	Hitachi C2556TN								
Granada	C59RH7	Hitachi C2586TN								
Granada	C59RN6	Panasonic TX25MD3								
Granada	C59RP6	Philips 25PT4523								
Granada	C59RS4	Sanyo 25MT2								
Granada	C66EB6	Sanyo 2866								
Granada	C66EB7	Sanyo 2865								
Granada	C66EK7	ITT 3896								
Granada	C66EK7	ITT 38767								
Granada	C66EP1	Philips 7690								
Granada	C66EP4	Philips 27CE3290								
Granada	C66EP5	Philips 27CE3598								
Granada	C66EP6	Philips27CE3590								
Granada	C66ET5	Toshiba 289T								
Granada	C66EV1	Sharp 2848								
Granada	C66EV3	Seleco 28362								
Granada	C66EV5	Sharp 2836								
Granada	C66EV7	Nordmende 9387								
Granada	C66EV7	Nordmende 2401S								
Granada	C66EV7	Seleco 28487								
Granada	C66EvV1	Sharp 2248								
Granada	C66EY5	Dynatron D820								
Granada	C66EY5	Pye 820								
Granada	C66EZ4	Salora	OEM			Finlandia				
Granada	C66EZ5	Salora	OEM			Finlandia				
Granada	C66FK7	ITT 3898								
Granada	C66FP7	Philips 27CE7593								
Granada	C66FP7	Pye 7593								
Granada	C66FR5	Panasonic XC78								
Granada	C66FR7	Panasonic XC78								
Granada	C66FY5	Pye 68KE3985								
Granada	C66FZ1	Salora	OEM			Finlandia				
Granada	C66FZ2	Salora	OEM			Finlandia				
Granada	C66FZ4	Salora	OEM			Finlandia				
Granada	C66FZ5	Salora	OEM			Finlandia				
Granada	C66FZ6	Salora	OEM			Finlandia				
Granada	C66FZ7	Salora	OEM			Finlandia				
Granada	C66GK6	Panasonic TX28W1								
Granada	C66GK7	Panasonic TX28A1								
Granada	C66GY4	Pye 27CE3598								
Granada	C66GZ6	Salora	OEM			Finlandia				
Granada	C66GZ7	Salora	OEM			Finlandia				
Granada	C66HK6	Panasonic TX28W1								
Granada	C66HP5	Philips 6590								
Granada	C66HZ5	Luxor 7005	Salora N			DeGraaf				
Granada	C66HZ6	Salora	Salora M			Finlandia				
Granada	C66JG6	Grundig 7460								
Granada	C66JS6	Sanyo CBP2876								
Granada	C66JZ5	Nokia	N-chassis			Finlandia				
Granada	C66Kp6	Philips 25ST2781								
Granada	C66KZ6	Nokia 28N8C	Eurostero 2 B-F							
Granada	C66LH7	Hitachi C2874TN								
Granada	C66LP6	Philips 28PT482A								
Granada	C66LZ6	Finlux 5000	Nokia 5000			Finlandia				
Granada	C66LZ8	As C66LZ6 with built in sat rx	Nokia 5000			Finlandia				
Granada	C66MH6	Hitachi C2865TN								
Granada	C66MN6	Panasonic TX28X1								
Granada	C66MN7	Panasonic TX28X1DP								
Granada	C66MP6	Philips 28PT512A								
Granada	C66MP7	Philips 28PT532B								
Granada	C66MP8	6770C								
Granada	C66MZ6	Finlux	5000 chassis			Finlandia				
Granada	C66MZ8	Finlux	5000 with built-in sat. receiver			Finlandia				
Granada	C66NH6	Hitachi C2846TN								
Granada	C66NH7	Hitachi C2976TNY								
Granada	C66NP6	Philips 284521								
Granada	C66NX7	Toshiba 2857DB								
Granada	C66PH7	Hitachi C2848TN								
Granada	C66PX7	Toshiba 2857DB								
Granada	C66RH7	Hitachi C2886TN								
Granada	C66RN6	Panasonic TX28MD3								
Granada	C66RP6	Philips 28PT4523								
Granada	C66RX7	Toshiba 2877DB								
Granada	C67KP9	Philips 28ML8916								
Granada	C67KP9	Philips 28ML8762								
Granada	C67MP9	Philips 28PW632A								
Granada	C67MZ7	Nokia 7296UK								
Granada	C67NP8	Philips 28PW9631								
Granada	C67NP9	Philips 28PW662B								
Granada	C68LH7	Hitachi C2984TN								
Granada	C68MP8	Philips 29PT822B								
Granada	C68MX7	Toshiba 2939DB								
Granada	C68NN6	Panasonic TX29AD1								
Granada	C68NN7	Panasonic TX29AD1DP								
Granada	C68NP5	Philips 29PT832A								
Granada	C68NP7	Philips 29PT727B								
Granada	C68NP8	Philips 29PT9021								
Granada	C68NP9	Philips 29PT828CP								
Granada	C68RN7	Panasonic TX29AD2DP								
Granada	C78MP9	Philips 32PW962								
Granada	C78MT6	Ferguson D78N								
Granada	C78NP9	Philips 32PW9631								
Granada	C78PP9	Philips 32W9612								
Granada	C80MX7	Toshiba 3339DB								
Granada	CV66MX5	Toshiba 2835DB								
Granada	D16VP1	Philips KT3 16C928								
Granada	D16VP2	Philips G11								
Granada	D16VY3	Philips KT3								
Granada	D20VP3	Philips KT3								
Granada	D20VY3	Philips KT3								
Granada	D22VP3	Philips G11								
Granada	D22WP1	Philips K30								
Granada	D22XP5	Philips K30								
Granada	D22XY5	Philips K30								
Granada	D26TP2	Philips G11								
Granada	D26WP3	Philips K30								
Granada	D26XY5	Philips K30								
Grundig	14GR3000	TV/DV/DVCR	2004 £120							
Grundig	6100	CUC42								
Grundig	7600	CUC740	8600							
Grundig	1514/1614	GSC100	6415							
Grundig	1644GB	GSC200								
Grundig	1645GB	GSC200								
Grundig	2463/3102/3103/3104	CUC40	4102/4103/4104	6232						
Grundig	28WF100	Orion 8500	2003, 100Hz, £399	Serv.mode: switch on while holding MENU on front panel, when red LED is on release MENU and press STBY on R/C.						
Grundig	28XKB GW7060	Orion 2500								
Grundig	32EKB GW8260	Orion chassis	around £500							
Grundig	32WF100	Orion 8500		serv.mode: see 28WF100						
Grundig	32WF8000	4400, Pureflat CRT	2003, £429							
Grundig	3302/3303/3304/3305	CUC52c	3306/3307/3308	3362/3403/3404						
Grundig	3302/3303/3304/3312	CUC50	3313/3314/3402/	3403/3404/6630						
Grundig	4245GB	GSC200								
Grundig	4445GB	GSC200								
Grundig	6245GB	GSC200								
Grundig	6445/1645	GSC200								
Grundig	6445GB	GSC200								
Grundig	70WF8000	2500 (Orion chassis)	2003 around £400	serv.mode: see W70-2100						
Grundig	C2402	CUC51KT								
Grundig	C8400	CUC70KT	C7402	C7400						

[illegible]

Grundig	T55-540	CUC5301							
Grundig	T55-645	G1000							
Grundig	T55-730 text/GB	CUC7301	1996, Pal I	TP711					
Grundig	T55-731	CUC7301							
Grundig	T55-750	CUC7350							
Grundig	T55-830 FT/GB	CUC7303	2000, Pal I	TP750C					
Grundig	T55-830 Multi MegASIS	CUC2003H	1998, Multistandard B/G, D/K, I	TP800 Hotel					
Grundig	T55-830 Multi/ICN	CUC2003H	1998, Multistandard B/G, D/K, I	TP715 Hotel					
Grundig	T55-930 FT/GB	CUC7303	2000, Pal I	TP750C					
Grundig	T6335	CUC5310							
Grundig	T6348	CUC6310							
Grundig	T63-530	CUC5310							
Grundig	T63-539	CUC5310							
Grundig	T63-640	CUC6310							
Grundig	T70-1020 (28BNK)	4400 (Orion chassis)							
Grundig	T70-1020A (28EKB)	2500 (Orion chassis)	Micro TDA9363, power TEA1504, frame T	LOPTx 2 types used. One marked 40348A-16 (part S031010000), another marked 40348A-20 (part S031010030). Not in					
Grundig	T70-1021	E12 (Evelux)		Serv.mode: press TV, i, STOP withing 5 sec from switching set on. To exit press STOP. Values are stored automatically					
Grundig	T70-1022	2500 or 2550 ?? / unconfirmed							
Grundig	T70-340	CUC3410							
Grundig	T70-440/1 TEXT/GB	CUC4410	CUC4410 similar to CUC4411						
Grundig	T70-449	CUC4411							
Grundig	T70-540	CUC3400							
Grundig	T70-540F	CUC3400							
Grundig	T70-640	CUC6310							
Grundig	T70-755	CUC6360							
Grundig	TVR3710 GB	Philips Turbo deck	1997						
Grundig	TVR3715	Orion chassis							
Grundig	TVR3720 GB	Philips Turbo deck	1997						
Grundig	TVR3725 FT/GB	Orion chassis	PCB marked TM9123A, video PCB VM9171B						
Grundig	TVR3730 Text/GB	Philips Turbo deck	1998						
Grundig	TVR3740 FT/GB	CP425 (Daewoo CP420 , K-Mecha Deck)	1999	PSU I801 STRS5707, I807 TOP210					
Grundig	TVR3805	Orion chassis (no TEXT)	PSU VPA150A, video PCB VMA230A	PIN code: Enter any pin code 3 times until "PIN CODE ERROR" is displayed, then hold "Vol-" on the unit and "7" on R/C					
Grundig	TVR3815(A)	Orion chassis (like TVR3805 but with TEXT)	PIN code: see TVR3805						
Grundig	TVR3820	Orion chassis	PCB marked TMA523A, video PCB VMA23	Micro OEC0113B					
Grundig	TVR4500	CUC4100	PIN code: Disconnect the cable and pull the video recorder out of the cabinet towards the back, connect the unit to the mains and switch it on, short the service test						
Grundig	TVR4510	CUC4100	PIN code - see TVR4500						
Grundig	TVR5100 GB	Philips Turbo deck	1997						
Grundig	TVR5120	Orion chassis	PCB marked TMA523A, video PCB VMA239A.						
Grundig	TVR5130 Text/GB	Philips Turbo deck	1998						
Grundig	TVR5504	CUC3500							
Grundig	TVR5510	CUC4100	PIN code - see TVR4500						
Grundig	TVR5540 FT/GB	CP425 (Daewoo CP420 , K-Mecha Deck)	1999	PSU I801 STRS5707, I807 TOP210					
Grundig	W56-2020	E12 (Evelux)	2003, £230	Serv.mode: press TV, i, STOP withing 5 sec from switching set on. To exit press STOP. Values are stored automatically					
Grundig	W70-2020	E12 (Evelux)	2003, Currys £199.99	Serv.mode: press TV, i, STOP \remote PR106					
Grundig	W70-2030	E9A(Made in Slovenia 2001/2002 by Evelux)	Micro SDA555XFL, LOPTx 1372.9005A	Serv.mode: press TV, i, STOP \remote PR106 £14.97 inclust	Options: Op1-20, Op2-91, Op3-00, Op4-10, Op5-04				
Grundig	W70-2100	2550 (Orion chassis) or 8500(on later sets??)	2004, Currys £269.99	Serv.mode: switch on while holding MENU on front panel, when green LED is on release MENU and press STBY on R/C					
Grundig	W82-2030	E9A(Made in Slovenia 2001/2002 by Evelux)	LOPTx 1372.9005A	Serv.mode: press TV, i, STOP withing 5 sec from switching s	remote PR106				
Grundig	W82-2030A	E12 (Made in Slovenia by Evelux)	2003						
Grundig	WF56-3020 (24AF)	2550 (Orion chassis)		serv.mode: see W70-2100					
Grundig	WF70-3020	Orion chassis, same as Matsui 28WN05A	PCB TMA520B, sub-PCB TMA521B	LOPTx 043228005R LOPTx 2SD2499, Micro OECF003B					
Grundig	WF82-3020	4400 (Orion chassis)		remote S068244000					
Grundig	WF82-3020A	2500 (Orion chassis)							
Grundig	XS 55/9	CUC7350							
Grundig	XS 63/8 FT/GB	CUC5360							
Grundig	XS 63/81	CUC6330							
Grundig	XS 70/81	CUC6330							
Harwood	CT14	Fidelity ZX4000							
Harwood	CTV1401	Fidelity ZX4000							
Harwood	Har14	Fidelity ZX4000							
Harwood	HNI6696BLK	chassis F11	Goodmans 2575 2875 3375						
Harwood	HTV3604R	Alba CTV1400	Bush CTV1400						
Harwood	HTV9014R	Osume CTV1484R							
Harwood	HTV9014R	Solarvox 141							
Harwood	HTV9425RTN	Bush 2857NTX							
Hinari	CT15	Goodmans 5160TT	Hinari ST200	Hinari TVA1					
Hinari	CT16	Goodmans Compact-100							
Hinari	CT4	Osaki P20H							
Hinari	CT4 / 5	Solarvox CML14							
Hinari	HIT140RC	Alba CTV840	also Bush 1402, Goodmans 1404(A)						
Hinari	HIT14R	Orion 14A chassis							
Hinari	HIT14RC	Alba CTV840							
Hinari	HIT14S (HIT14T)	Orion 14A chassis							
Hinari	ST200	Hinari CT15							
Hinari	Traveller	Nikkai Baby 10							
Hinari	TVA1	Hinari CT15	Nikkai TLG101						
Hinari	VTV200	Goodmans 1560TT	Hinari CT15						
Hitachi	C1410R/T	MONOPLUS-90							
Hitachi	C1411R/T	Daewoo CP330							
Hitachi	C1420VT	Combi ECO Philips	also see Mitsubishi CT14MV1B	Child lock. PIN - press Vol+, Vol-, Pr-, Pr+ followed by OK.					
Hitachi	C1421R/T	Daewoo CP375							
Hitachi	C1422R/RS	F1R (Tatung F series)	S-silver						
Hitachi	C1422T/TS	F1Y (Tatung F series)	T-text, S-silver						
Hitachi	C1424R/T	Daewoo CP185							
Hitachi	C1426R	11AK30	2003						
Hitachi	C1432TB/TY	see C1422T (F1Y chassis, Tatung F series)	T-text, B-blue, Y-yellow						
Hitachi	C14P216	G8Q							
Hitachi	C14-P216	G8Q/P	G7P Mk2						
Hitachi	C14-P218	G8Q/P	G7P Mk2						
Hitachi	C15-P218	Salora L							
Hitachi	C1709T	G7PS/L							
Hitachi	C1719T	G7PS/L							
Hitachi	C2055H (GEC)	NP8CQ							
Hitachi	C2057H (GEC)	NP8CQ							
Hitachi	C2114R/T-311	G7PS3	1993						
Hitachi	C2114RE(TE)	similar to C2117T	1997						
Hitachi	C2117T	similar to C2114TE(RE) <not "C2114T" !>	1997						
Hitachi	C2118R/T	G7PS2	1990						
Hitachi	C2119R/T	G7PS/2							
Hitachi	C2121R	Daewoo CP375	1997						
Hitachi	C2121T-TEXT	Daewoo CP375	1997						
Hitachi	C2122T	F4Y (Tatung F series)	1998						
Hitachi	C2125S/T	11AK19K, 11AK19Y4	2000	LOPTx 30002826, DNF-FDA0001, equiv. HR8528, FBT40723					
Hitachi	C2126S	11AK30	2002						
Hitachi	C2133MN	S3-M4 chassis (PAL-SECAM-NTSC)							
Hitachi	C2133TN	STEREO PLUS							
Hitachi	C2135MN	S3-M4 chassis (PAL-SECAM-NTSC)							
Hitachi	C2142N/S	11AK19K	2000						
Hitachi	C2143S	11AK30	2002						
Hitachi	C2144S	11AK30	2002						
Hitachi	C2146TN	A4	1995						
Hitachi	C2156TN	A7	1998						
Hitachi	C2164TN	G10Q							
Hitachi	C2166TN	A4							
Hitachi	C2186TN	A7	1998						
Hitachi	C2196	G8Q/P							
Hitachi	C2198	G8Q/P							
Hitachi	C21F45N	V2E	2000						
Hitachi	C21P226	G8Q/P							
Hitachi	C21P228	G8Q/P							
Hitachi	C21P818	G8Q/P							
Hitachi	C21P819	G8Q/P							
Hitachi	C2255H (GEC)	NP8CQ							
Hitachi	C2257H (GEC)	NP8CQ							
Hitachi	C24W1TN	A7	1998						
Hitachi	C24W410SN	A7	2000/2001						
Hitachi	C24W430N-311	A7	2000/2001						
Hitachi	C24W511TN	A7	2000/2001						
Hitachi	C2509R/T	G7PS/L							
Hitachi	C2514T	G7PS3S	1993						
Hitachi	C2514TZ-311	G7PS3S							
Hitachi	C2514TE		1997						
Hitachi	C2519R/T	G8Q							
Hitachi	C2524R/T	G7PSL	1991						
Hitachi	C2544TN	G10Q	1992						
Hitachi	C2546TN	A4	1995						
Hitachi	C2547TN	A4							
Hitachi	C2548TN	A6	1997						
Hitachi	C2556TN	A7	1998						
Hitachi	C2557N	V2E	2000						

[illegible]

Hitachi	CPT1492	NP84C2								
Hitachi	CPT1493	NP84C2								
Hitachi	CPT1494	NP84C2								
Hitachi	CPT1497	NP84C2								
Hitachi	CPT1499	NP84C2								
Hitachi	CPT1556	Salora L								
Hitachi	CPT1557	Salora L								
Hitachi	CPT1558	Luxor 18036549								
Hitachi	CPT1624	NP82CQ								
Hitachi	CPT1626	NP82CQ								
Hitachi	CPT1644	NP84CQ								
Hitachi	CPT1646	NP84CQ								
Hitachi	CPT1646R	NP84CQ								
Hitachi	CPT1657	NP8C								
Hitachi	CPT1674	NP84CQ/4								
Hitachi	CPT1676	NP84CQ/4								
Hitachi	CPT2016	NP81CQ/2								
Hitachi	CPT2024	NP82CQ	GEC C2086							
Hitachi	CPT2026	NP83CQ								
Hitachi	CPT2028	NP83CQ								
Hitachi	CPT2036	NP83CQ	GEC 2090 / C2295							
Hitachi	CPT2038	NP83CQ								
Hitachi	CPT2044	NP83CQ/2	GEC2294H							
Hitachi	CPT2046	NP83CQ/2	GEC2294H							
Hitachi	CPT2048	NP83CQ/2								
Hitachi	CPT2050	Salora J 22J40								
Hitachi	CPT2051	NP800/CR	Expert 2061							
Hitachi	CPT2055	NP80C								
Hitachi	CPT2060	Salora J								
Hitachi	CPT2066	NP85CQ/2								
Hitachi	CPT2068	NP85CQ/2								
Hitachi	CPT2071	NP80/CR								
Hitachi	CPT2074	NP83CQ/2								
Hitachi	CPT2076	NP83CQ/2								
Hitachi	CPT2078	NP83CQ/2								
Hitachi	CPT2091	NP83CQ								
Hitachi	CPT2118	G6P								
Hitachi	CPT2128	G7P/2								
Hitachi	CPT2138	G7PS/2								
Hitachi	CPT2158	NP85CQ/2								
Hitachi	CPT2174	G6P								
Hitachi	CPT2176	G6P	GEC C2095 / C2200 / C2295							
Hitachi	CPT2178	G6P								
Hitachi	CPT2188	Salora K								
Hitachi	CPT2196	G8Q/P								
Hitachi	CPT2198	G8Q/P								
Hitachi	CPT2210	NP81CQ/2								
Hitachi	CPT2216	NP81CQ/2								
Hitachi	CPT2218	NP81CQ/2								
Hitachi	CPT2224	NP81CQ/2	GEC C2085 / C2285 / C2288							
Hitachi	CPT2226	NP81CQ/2	GEC C2286							
Hitachi	CPT2228	NP83CQ/2								
Hitachi	CPT2234	NP83CQ	GEC 2288H	GEC2089H						
Hitachi	CPT2236	NP83CQ								
Hitachi	CPT2238	NP83CQ								
Hitachi	CPT2244	NP83CQ/2	GEC2294H							
Hitachi	CPT2246	NP83CQ/2	GEC2294H							
Hitachi	CPT2248	NP83CQ/2								
Hitachi	CPT2250	Salora J								
Hitachi	CPT2260	Salora J	IPSALO-2							
Hitachi	CPT2274	NP83CQ/2								
Hitachi	CPT2276	NP83CQ/2								
Hitachi	CPT2278	NP83CQ/2								
Hitachi	CPT2476	G6P								
Hitachi	CPT2478	G6P								
Hitachi	CPT2488	Salora K								
Hitachi	CPT2508	G7P MK2								
Hitachi	CPT2524	G7P/2								
Hitachi	CPT2528	G7P								
Hitachi	CPT2538	G7P MK2								
Hitachi	CPT2550	Salora J								
Hitachi	CPT2568	NP86UQ/2								
Hitachi	CPT2578	G8Q/P								
Hitachi	CPT2596	G8Q/P								
Hitachi	CPT2598	G8Q/P								
Hitachi	CPT2598A	G8Q								
Hitachi	CPT2625	Sakora J								
Hitachi	CPT2626	NP83CQ								
Hitachi	CPT2650	Salora J								
Hitachi	CPT2656	Salora L								
Hitachi	CPT2658	Salora L								
Hitachi	CPT2660	Salora J	IPSALO-2							
Hitachi	CPT2808	G7P-MK2								
Hitachi	CPT2888	Salora K								
Hitachi	CPT3308	G6P								
Hitachi	CPT5908	Salora M								
Hitachi	CPT6608	Salora M								
Hitachi	CPY2055	NP80C								
Hitachi	CRP143	NP6C								
Hitachi	CRP146	PAL4								
Hitachi	CRP147	PAL4								
Hitachi	CRP148	PAL4								
Hitachi	CTP202	PAL4								
Hitachi	CTP203	NP6C								
Hitachi	CTP205	PAL4								
Hitachi	CTP206	PAL4								
Hitachi	CTP208	NP8CQ								
Hitachi	CTP209	PAL4								
Hitachi	CTP213	NP6C								
Hitachi	CTP215	NP6C								
Hitachi	CTP216	NP6C								
Hitachi	CTP217	NP6C								
Hitachi	CTP230	NP8C								
Hitachi	CWP132	NP6C								
Hitachi	CWP300	NP8CQ								
Hitachi	D36WF840N	D8 (A8 plus digibox but without feature box)	2001							
Hitachi	GIRD3000	USAT001								
Hitachi	GRD100	OMNI								
Hitachi	P26	SJ								
Hitachi	P27	SX								
Hitachi	P27FM	SX								
Hitachi	P32	SV								
Huanyu	37C2	similar to Hitachi NP82CQ								
ITT	1530HS	EUROMONO 1	HOTEL							
ITT	1730HS	EUROMONO 1	HOTEL							
ITT	2130HS	EUROMONO 1	HOTEL							
ITT	3578UK	COMPACT D								
ITT	3588UK	COMPACT D								
ITT	3878UK	COMPACT D								
ITT	3888UK	COMPACT D								
ITT	3988MS	DIGI B 110								
ITT	848C	COMPACT B								
ITT	Compact B Mk2	CT3425 / CT3437	CT3548	FX3448						
ITT	Compact D2 FST	ST25TX								
ITT	Core 110*	5520 / 6320 / 7140								
ITT	Core 2	CP3128								
ITT	CP2212	CVC1110/12								
ITT	CP2342	CVC1110/12 PICO 1A								
ITT	CP2352	CVC1110/12 PICO 1A								
ITT	CP3104	PICO S								
ITT	CP3104/16	PICO S/2								
ITT	CP3106	MONOPRINT A								
ITT	CP3120	ZX4200								
ITT	CP3125/T	PICO S/2-3								
ITT	CP3126	MONOPRINT B								
ITT	CP3128	CORE 2 90DEG								
ITT	CP3200	PICO 1A								
ITT	CP3204	PICO S/22222-3								
ITT	CP3210	PICO A FS								

ITT	CP3225	PICO S+S/2							
ITT	CP3225/1	PICO S/3							
ITT	CP3228	MONOPRINT B							
ITT	CT2500	CVC1175							
ITT	CT2500/2	PICO 1ST/2							
ITT	CT2512	CVC1200							
ITT	CT2512/2	MINI 2 90DEG FS							
ITT	CT2600	CVC1210/15	MINI 2 110DEG STD						
ITT	CT2601	COMPACT 80R DST							
ITT	CT2612	CVC1210/15							
ITT	CT2612/2	MINI 2 110DEG FS							
ITT	CT2613	COMPACT 80R 110DEG							
ITT	CT2700	MINI 2 110DEG STD							
ITT	CT2701	COMPACT 80R DST							
ITT	CT2712	CVC1200	MINI 2 110DEG FS						
ITT	CT2713	COMPACT 80R							
ITT	CT3306	MONOPRINT A							
ITT	CT3307	MONOPRINT A							
ITT	CT3314M	MONOPRINT A							
ITT	CT3315	PICO S-S3							
ITT	CT3325	PICOS2-S3							
ITT	CT3326	MONOPRINT B							
ITT	CT3327	MONOPRINT B							
ITT	CT3414M	80R 110DEG							
ITT	CT3415	80R 110DEG							
ITT	CT3425	80R 110DEG							
ITT	CT3426	COMPACT B							
ITT	CT3435	COMPACT 80R 90DEG							
ITT	CT3436	COMPACT 80R 90DEG							
ITT	CT3437	COMPACT B							
ITT	CT3446	DIGI 3 90DEG							
ITT	CT3448	COMPACT B100DEG							
ITT	CT3535	80R 110DEG							
ITT	CT3537	COMPACT B 110DEG FST							
ITT	CT3548	COMPACT B2 110DEG FST							
ITT	CT3548	COMPACTB							
ITT	CT3548UK	COMPACTB							
ITT	CT3578	COMPACTD							
ITT	CT3598	COMPACTD							
ITT	CT3715	COMPACT 80R							
ITT	CT3724	COMPACT 80R 110DEG							
ITT	CT3724	MONO PLUS							
ITT	CT3835	COMPACT 80R 110DEG FST							
ITT	CT3837	COMPACT B 110DEG							
ITT	CT3878	COMPACTD							
ITT	CT3888	COMPACTD							
ITT	CT4030	CORE 90 FST							
ITT	CT4532	EUROMONO 1/ 2 90 DEG							
ITT	CT5110	CORE 2							
ITT	CT5111	CORE 2 90DEG							
ITT	CT5520	CORE 2 110DEG							
ITT	CT5521	CORE 2 90DEG							
ITT	CT5523	EUROMONO 1/2 90DEG							
ITT	CT6332	EUROMONO 1/2 110DEG							
ITT	CVC1100	Granada YK1							
ITT	CVC1102								
ITT	CVC1110	Granada AK1							
ITT	CVC1112								
ITT	CVC1120								
ITT	CVC1150								
ITT	CVC1175	Solarvox 20S09	CT2500/2						
ITT	CVC1200	Solarvox 20T19							
ITT	CVC1200								
ITT	CVC1202	CT2512							
ITT	CVC1203								
ITT	CVC1204								
ITT	CVC1210	CT2600 / 2700							
ITT	CVC1212								
ITT	CVC1215		TX2612						
ITT	CVC1217								
ITT	CVC20								
ITT	CVC21								
ITT	CVC25								
ITT	CVC30		TX791						
ITT	CVC32								
ITT	CVC40	CP340							
ITT	CVC45								
ITT	CVC5								
ITT	CVC7								
ITT	CVC800								
ITT	CVC801	Granada XK1/5	CP0211/1						
ITT	CVC802	CT1511/2							
ITT	CVC803	CT0500/2							
ITT	CVC820	Granada WK1/5							
ITT	CVC823	CT600/1							
ITT	CVC824	CT3701/3732	CT/TX3432/3732						
ITT	CVC825		ITT 3732						
ITT	CVC830		ITT80-110°						
ITT	CVC9								
ITT	Digi 3	ST3876/3896	ST3576						
ITT	Digivision 6362	Eurostereo 1							
ITT	Digivision 6382	Eurostereo 1							
ITT	Digivision 7162	Eurostereo 1							
ITT	Digivision 7182	Eurostereo 1							
ITT	EuroMono2		FX5532						
ITT	EuroStereo		2BF110NN						
ITT	FS9R	FS10R							
ITT	FX3448	Compact B							
ITT	FX3448UK	Compact B							
ITT	FX3548	Compact B							
ITT	FX3548UK	Compact B							
ITT	FX3724	MONO PLUS							
ITT	FX4030	CORE 2 90DEG							
ITT	FX4530	CORE 2 90DEG							
ITT	FX4532	EUROMONO 1/2 90DEG							
ITT	FX5124	MONOPLUS							
ITT	FX5520	CORE 2 110DEG							
ITT	FX5521	CORE 2 90DEG							
ITT	FX5524	MONO PLUS							
ITT	FX5530	CORE 2 90DEG							
ITT	FX5532	EUROMONO 1/2 90DEG							
ITT	FX6320	CORE 2 110DEG							
ITT	FX6330	CORE 2 110DEG							
ITT	FX6332	EUROMONO 1/ 2 110DEG							
ITT	MC3896	DIGI 3 110DEG							
ITT	Mini 2 ST2/2								
ITT	Monoprint A	CT3306	CP3106						
ITT	Monoprint B	CT3327	CT3326						
ITT	Monoprint B								
ITT	Pico 1A	Granada 14AK1							
ITT	Pico S/2								
ITT	Pico S/3	CT2500	TX2612						
ITT	Pico S/3	Solarvox 16R19	Solarvox 20S19						
ITT	Pico S/3	Tashiko 14F681	Solarvox 14R19						
ITT	SAT7190	M80							
ITT	SFN3578	COMPACT D-2							
ITT	SFN3878	COMPACT D-2							
ITT	SFN5363	EUROSTEREO 1							
ITT	SFN5515	5000							
ITT	SFN5552	EUROSTEREO 1							
ITT	SFN5553	EUROSTEREO 2 B-F							
ITT	SFN5575	STEREO PLUS							
ITT	SFN5581	COMPACT D/E							
ITT	SFN6315	5000							
ITT	SFN6355	STEREO PLUS							
ITT	SFN6361	COMPACT DE							
ITT	SFN6363	EUROSTEREO 1							
ITT	SFN6364	EUROSTEREO 2 B-F							
ITT	SFN6365	STEREO PLUS							

ITT	SFN6380	COMPACT B/2							
ITT	SFN6385	EUROSTEREO PLUS							
ITT	SFN7155	STEREO PLUS							
ITT	SFN7161	COMPACT D/E							
ITT	SFN7163	EUROSTEREO 1							
ITT	SFN7164	EUROSTEREO 2 B-F							
ITT	SFN7165	STEREO PLUS							
ITT	SFN7180	COMPACT D/2							
ITT	SFN7185SR	EUROSTEREO PLUS							
ITT	SFN7284	EURODIGI 16.9							
ITT	SFN7291	EURODIGI 16.9							
ITT	SFN8291	EURODIGI 16.9							
ITT	SFN8294	EURODIGI 16.9							
ITT	SFN9291	EURODIGI 16.9							
ITT	SFN9294	EURODIGI 16.9							
ITT	SFX3489	COMPACT D/2							
ITT	SFX3578	COMPACT D/2							
ITT	SFX3598	COMPACT D/2							
ITT	SFX3878	COMPACT D/2							
ITT	SFX3888	COMPACT D/2							
ITT	ST3487	DIGI 3 110DEG							
ITT	ST3493C	CVC1200							
ITT	ST3576	DIGI 3 110DEG							
ITT	ST35767	DIGI 3 110DEG							
ITT	ST3876	DIGI 3							
ITT	ST38767	DIGI 3							
ITT	TX2512	CVC1200							
ITT	TX2612	CVC1210/15							
ITT	TX2712	CVC1200							
ITT	TX28UK	COMPACTD							
ITT	TX3126	MONOPRINT B							
ITT	TX3325	CVC1200							
ITT	TX3326	MONOPRINT B							
ITT	TX3327	MONOPRINT B							
ITT	TX3446	DIGI 3 90DEG							
ITT	TX3447	DIGI 3 110DEG							
ITT	TX3493C	CVC1200							
ITT	TX3546	DIGI 3 110DEG							
ITT	TX35467	DIGI 3 110DEG							
ITT	TX3835	80R 110DEG FST							
JMB	JMB20NTX (10009379)	11AK19P4, 11AK19P5	2001-2002				AK19 prod.code: 10009379		
JMB	JMB20NTX	11AK30-2							
JMB	JMB20R	Daewoo chassis							
JMB	JMB28NTX (10009380)	11AK19P4, 11AK19P5	2001-2002				AK19 prod.code: 10009380		
JMB	JMB28NTX	11AK37-6	2002-2003						
JMB	JMB66W	11AK19P5, 11AK37-6 (after 2002)							
JMB	JMB76W	PT92							
JMB	JMBM020FTS	PT92							
JMB	JMBN028WSS	PT92							
JMB	JMBTV1402R	CTU-AA	Service mode: switch to channel 75, hold 75				Micro TDA9380PS/N2/110586		
JMB	JMBTV455GR	CTN-BB							
JMB	JMBV028WSS	11AK19Pro							
JMB	JTPTV014K	PT11							
JVC	2151	TX100							
JVC	7943	TX10							
JVC	7731R	TX90	TX9						
JVC	7732T		TX9						
JVC	7741R	TX100							
JVC	7742T	TX100							
JVC	7831R	FERG TX9							
JVC	7832T	TX10							
JVC	7841R	TX100							
JVC	7842T	TX100							
JVC	7933TS	TX10							
JVC	AV1414EE	CG	2002, multisystem B/G, D/K, I				RM-C360GY		
JVC	AV1415EE	CG	2002, multisystem B/G, D/K, I						
JVC	AV1434EE	CG	2002, multisystem B/G, D/K, I				RM-C364GY		
JVC	AV1435 AV1435EE AV1435S	CG	2002, multisystem B/G, D/K, I				RM-C90 or RM-C364		
JVC	AV1438	CG	2002, multisystem B/G, D/K, I				RM-C90 or RM-C364		
JVC	AV14A3	CG	2002, multisystem B/G, D/K, I						
JVC	AV14AMG3	CG	2002, multisystem B/G, D/K, I						
JVC	AV14BJ8EPS	11AK36 (non UK model)							
JVC	AV14F3	CG	2002, multisystem B/G, D/K, I				RM-C90 or RM-C364		
JVC	AV14F43BK	CG	2002, multisystem B/G, D/K, I				RM-C368GY		
JVC	AV14FM	CG	2000, multisystem B/G, D/K, I						
JVC	AV14FMG3B	CG	2002, multisystem B/G, D/K, I				RM-C90 or RM-C364		
JVC	AV14FMT3	CG	2002, multisystem B/G, D/K, I				RM-C90 or RM-C364		
JVC	AV14FTR	CG	2000, multisystem B/G, D/K, I						
JVC	AV16N73	CG	2002, multisystem B/G, D/K, I				RM-C367GY		
JVC	AV20N3	CG	2002, multisystem B/G, D/K, I				RM-C364GY		
JVC	AV20N43BK	CG	2002, multisystem B/G, D/K, I				RM-C368GY		
JVC	AV20N4BK	CG	2000, multisystem B/G, D/K, I						
JVC	AV20NMG3B	CG	2002, multisystem B/G, D/K, I				RM-C364GY		
JVC	AV20NX3	CH	2002, multisystem B/G, D/K, I				RM-C1014-1H		
JVC	AV2105EE	CG	2002, multisystem B/G, D/K, I				RM-C90 or RM-C364		
JVC	AV2115EE	CG	2002, multisystem B/G, D/K, I				RM-C364GY-1H		
JVC	AV2168TEE	CH	2002, multisystem B/G, D/K, I				RM-C1023-1H		
JVC	AV2178TEE	CH	2002, multisystem B/G, D/K, I				RM-C1013-1H		
JVC	AV21A10	CG	2002, multisystem B/G, D/K, I						
JVC	AV21BF11EJS	no chassis	2002, UK PAL I				RM-C1100		
JVC	AV21D43BK	CG	2002, multisystem B/G, D/K, I				RM-C368GY		
JVC	AV21D73	CG	2002, multisystem B/G, D/K, I				RM-C367GY		
JVC	AV21DX3	CH	2002, multisystem B/G, D/K, I				RM-C1014-1H		
JVC	AV21F1EK	JX	1992						
JVC	AV21H1EK	JX III	1993						
JVC	AV21H2EK	JX III	1993						
JVC	AV21SX1EK	BB	1996				RM-C770		
JVC	AV21TS1EK	BB	1996				RM-C760		
JVC	AV21TS4EK	JH	1999/2000						
JVC	AV21VM1EK	BA	1995						
JVC	AV24WT2EK	JF	1997, UK PAL I				RM-C794		
JVC	AV24WT5Exx	JK II	2001				RM-C55 (Silver) or RM-C51 (Black)		
JVC	AV2555TEE	CH	2002, multisystem B/G, D/K, I				RM-C1013-1H		
JVC	AV2568TEE	CH	2002, multisystem B/G, D/K, I				RM-C1013-1H		
JVC	AV25F1EK	JX	1990-1992						
JVC	AV25FX11EK	JX II	1991						
JVC	AV25GS1EK	MXI, II	1993						
JVC	AV25KX3	CH	2002, multisystem B/G, D/K, I				RM-C1014-1H		
JVC	AV25LH3	CH	2002, multisystem B/G, D/K, I				RM-C1011-1H		
JVC	AV25LS3	CH	2002, multisystem B/G, D/K, I				RM-C1010-1H		
JVC	AV25LX3	CH	2002, multisystem B/G, D/K, I				RM-C1014-1H		
JVC	AV25PS	JK	2000, multisystem B/G, D/K, I						
JVC	AV25PX	JK	2000, multisystem B/G, D/K, I						
JVC	AV25S1EK	MX II	1993				RM-C873		
JVC	AV25S4EK	MX IV	1994						
JVC	AV25SD4EK	MX III	1994/1995						
JVC	AV25SX1EK	JA	1996				RM-C770		
JVC	AV25SX2EK	JE	1998				RM-C792		
JVC	AV25SX4EK	JH	1999/2000						
JVC	AV25TS1EK	JC	1996						
JVC	AV25TS4EK	JH	1999/2000				RM-C760		
JVC	AV25VM1EK	JA	1995				RM-C760		
JVC	AV28BD5EKIS	Daewoo CP785	2000, UK PAL I						
JVC	AV28BT5	11AK19 (nonUK)							
JVC	AV28CT1EK	JK II	2002, PAL I				RM-C55 (Silver) or RM-C51 (Black)		
JVC	AV28F1EK	JX	1991						
JVC	AV28GS1EK	MXI, II	1993						
JVC	AV28GT1BJF	11AK45B4	2003				RM-C1512B (VE30021286)		
JVC	AV28GT1SJF	11AK45B4	2003				RM-C1512S (VE30021287)		
JVC	AV28H20EUB (black)	MF II	2002, Euro-multisystem B/G, D/K, I				RM-C50 (black)		
JVC	AV28H20EUS (silver)	MF II	2002, Euro-multisystem B/G, D/K, I				RM-C54H (silver)		
JVC	AV28L2EU	MF	2001						
JVC	AV28R100EKS	JK, colour variant of AV28WFR1EKS	2001						
JVC	AV28R100EKS	JK, colour variant of AV28WFR1EKS	2001						
JVC	AV28R250EKS	JL	2002				RM-C60 (Silver) or RM-C52 (Black)		
JVC	AV28R25EKS	JL	2002				RM-C60 (Silver) or RM-C52 (Black)		
JVC	AV28R25EKS/c	JL2	2003				the /c version is identified by letter "C" at the end of the serial number		
JVC	AV28R370KE	JL2	2003				RM-C1504		
JVC	AV28R4SK	JW	2004				RM-C1502-1C (Silver)		

JVC	AV28S1EK	MX II	1993	RM-C873					
JVC	AV28S2EK	JK	2001	RM-C55					
JVC	AV28S4EK	MX IV	1994						
JVC	AV28SD4EK	MX III	1994/1995						
JVC	AV28T10EKS	JK, colour variant of AV28WFT1EKS	2001						
JVC	AV28T2SEK	JL	2002	RM-C55H (Grey) or RM-C52 (Black)					
JVC	AV28T2SEK/c	JL2	2003	the /c version is identified by letter "C" at the end of the serial number					
JVC	AV28T35SPE	JL2	2003	RM-C1502					
JVC	AV28T4SK (AV28T4BK)	JW	2004	RM-C1502-1C (Silver) or RM-C1502B-2C (Black)					
JVC	AV28T55EK	JL	2002	RM-C55H (Grey) or RM-C52 (Black)					
JVC	AV28T67SKE	JL2	2003	RM-C1500					
JVC	AV28T77SK	JW	2004	RM-C1502-1C (Silver)					
JVC	AV28VM1EK	JA	1995	RM-C760					
JVC	AV28WFR1EKS	JK (Dolby variant of AV28WFT1EKS)	2000/2001 PAL I	RM-C52					
JVC	AV28WFT1EKS	JK	2000/2001 PAL I	RM-C51					
JVC	AV28WFX1EU		multisystem B/G, D/K, I	RM-C50 (black)					
JVC	AV28WH3EP	MC							
JVC	AV28WH5EU	MF	2001, Multistandard B/G, D/K, I	RM-C54					
JVC	AV28WR2EK	JF	1997						
JVC	AV28WR4EK	JF	1999						
JVC	AV28WT2EK	JF	1997, UK PAL I	RM-C794					
JVC	AV28WT4EK	JF	1999						
JVC	AV28WT5EKS	JK II	2001, UK PAL I	RM-C55 (Silver) or RM-C51 (Black)					
JVC	AV28WX1EK	JD	1996	RM-C782					
JVC	AV28X10EKS	MF	2001	RM-C55					
JVC	AV28X25EIGY	MF II	2002, Irish PAL I	RM-C55					
JVC	AV28X25EKG	MF II	2002, UK PAL I	RM-C55					
JVC	AV28X25EUS	MF II	2002, Euro-multisystem B/G, D/K, I	RM-C54					
JVC	AV28X35HKE	ML	2003, PAL I	RM-C55					
JVC	AV28X37HKE	ML	2003, PAL I	RM-C55					
JVC	AV28X4SK (AV29X4SR)	ML2	2004, PAL I	RM-C64H					
JVC	AV28Z10EUS	MF	2001, Multistandard B/G, D/K, I	RM-C58					
JVC	AV2968TEE	CH	2002, multisystem B/G, D/K, I	RM-C1023-1H					
JVC	AV29BD3EK	JE	1998						
JVC	AV29LS2	CH	2002, multisystem B/G, D/K, I	RM-C1020-1H					
JVC	AV29LX2	CH	2002, multisystem B/G, D/K, I	RM-C1024-1H					
JVC	AV29R8B	JK	2000, multisystem B/G, D/K, I						
JVC	AV29RF6	JK	2000, multisystem B/G, D/K, I						
JVC	AV29SX1EK	JA	1995						
JVC	AV29SX2EK	JE	1997-1998	RM-C792					
JVC	AV29SX4EK	JH	1999						
JVC	AV29TS2EK	JE	1998	RM-C795					
JVC	AV29TS4Ex	JH	1999	RM-C795-1E					
JVC	AV29W93	CH	2002, multisystem B/G, D/K, I	RM-C1011-1H					
JVC	AV29W93B	CH	2002, multisystem B/G, D/K, I	RM-C1012-1H					
JVC	AV29WS3	CH	2002, multisystem B/G, D/K, I						
JVC	AV32H20EUS	MF II	2002, Euro-multisystem B/G, D/K, I	RM-C54H (silver)					
JVC	AV32P10EKS/EIS	MF	2001, PAL I (EKS) or multisystem (EIS)	RM-C57					
JVC	AV32R250EKS	JL	2002	RM-C60H					
JVC	AV32R25EKS	JL (Dolby variant of AV32T25EKS)	2002	RM-C60H					
JVC	AV32R25EKS/c	JL2	2003	the /c version is identified by letter "C" at the end of the serial number					
JVC	AV32R370KE	JL2	2003	RM-C1504					
JVC	AV32R4SK	JW	2004	RM-C1502-1C (Silver)					
JVC	AV32T25EKS	JL	2002	RM-C55H (Grey) or RM-C52 (Black)					
JVC	AV32T25EKS/c	JL2	2003	the /c version is identified by letter "C" at the end of the serial number					
JVC	AV32T4SK (AV32T4SR)	JW	2004	RM-C1502-1C (Silver)					
JVC	AV32T55EKS	JL	2002	RM-C55H (Grey) or RM-C52 (Black)					
JVC	AV32T67SKE	JL2	2003	RM-C1500					
JVC	AV32T77SK	JW	2004	RM-C1502-1C (Silver)					
JVC	AV32WFP1EK	MD	1999/2000						
JVC	AV32WFR1EKS	JK (Dolby variant of AV32WFT1EKS)	2000/2001 PAL I	RM-C52					
JVC	AV32WFT1EKS	JK	2000/2001 PAL I	RM-C51					
JVC	AV32WFX1EU		multisystem B/G, D/K, I	RM-C50 (black)					
JVC	AV32WH3EP	MC	1998						
JVC	AV32WL1EK	MD	2000	RM-C55					
JVC	AV32WP2EK	MB	1998						
JVC	AV32WR2EK	JF	1997						
JVC	AV32WR4EK		1999						
JVC	AV32WX1EK	JD	1996	RM-C782					
JVC	AV32X250EUS	MF II	2002, multisystem B/G, D/K, I	RM-C54					
JVC	AV32X25EIGY	MF II	2002, Irish PAL I	RM-C55					
JVC	AV32X25EKG	MF II	2002, UK PAL I	RM-C55					
JVC	AV32X25EUS	MF II	2002, multisystem B/G, D/K, I	RM-C54					
JVC	AV32X35HKE	ML	2003, PAL I	RM-C55					
JVC	AV32X37HKE	ML	2003, PAL I	RM-C55					
JVC	AV32X4SK (AV32X4SR)	ML2	2004, PAL I	RM-C64H					
JVC	AVN280EKT	BYII							
JVC	AVS250	BXII							
JVC	AVS250EK	BXII							
JVC	C1480	BXII							
JVC	C14A1EK	MV							
JVC	C14E1EK	Onwa							
JVC	C14ET1EK	Onwa							
JVC	C2151R	TX100							
JVC	C2152T	TX100							
JVC	C2153TS	TX100							
JVC	C21ET1EK	Onwa	same as C21M3EK						
JVC	C21M3EK	Onwa	same as C21ET1EK						
JVC	C21TX1	MY							
JVC	C21TX1	MYII							
JVC	CS2180	BXII							
JVC	CS2181	BYX							
JVC	CS2181	BYX							
JVC	CS2190	BXII							
JVC	CS2191	BYX							
JVC	CS21M2EK	MYII							
JVC	CS21M3EK	Onwa							
JVC	CV14EKB	CY21EK CVT14EKB							
JVC	CVT14EKB	CY21EK CV14EKB							
JVC	CY21EK	CV14EKB CVT14EKB							
JVC	FXE95TN	DXE95TN							
JVC	HV28P37SJE(SUE)	MM	2003-2004, multisystem, £400-£500	RM-C1800					
JVC	HV29LPZ	MF	2002, multisystem B/G, D/K, I	RM-C214 (TEXT), RM-C215 (without TEXT for /HK model)					
JVC	HV29WZ	MF	2002, multisystem B/G, D/K, I	RM-C1030					
JVC	HV32P37SJE(SUE)	MM	2003-2004, multisystem, £600-£700	RM-C1800					
JVC	HV34LZ	MF	2002, multisystem B/G, D/K, I	RM-C1030					
JVC	HV36P38SJE(SUE)	MM	2003-2004, multisystem, £1000-£1300	RM-C1800					
JVC	HV53PRO	MF	Projection						
JVC	TUC200	E2							
LG	2190	PC04A							
LG	CB20F84	Beko 12.4/12.5							
LG	CE20F60K	MC019A	2001						
LG	CE20J3BX/GX/RX	MC009A	2000						
LG	CE21F60KX	MC019A	2001						
LG	CE21M66KX	MC019A	2001						
LG	CE21Q26ET	MC007B	2000						
LG	CE21Q66	MC007B	2000						
LG	CE21T22KX	MC019A	2001						
LG	CE28A86T	MC007A	2000						
LG	CE29Q10ET	MC991A	1999						
LG	CE29Q28ET	MC007A	2000						
LG	CE29Q46ET	MC007A	2000						
LG	CF21A50F	PC58B							
LG	CF21C28F	PC58B							
LG	CF25A50F	PC58A Chassis							
LG	CF25A56T	PC73A							
LG	CF25A64D/T	PC73A	1997						
LG	CF25C20F	PC33J							
LG	CF25C22F	PC33J							
LG	CF25C28F	PC58A Chassis							
LG	CF28A50F	PC58A Chassis	Saville XPM25						
LG	CF28A64T	PC73A	1997						
LG	CF28C22F	PC33J Chassis							
LG	CF28C28F	PC58A Chassis							
LG	CF29C20N	PC33J							
LG	CF29C42F	PC33J Chassis							
LG	C114A80	PC31A							
LG	C114A80	PC31A Chassis							
LG	C114B50F	Beko 11.1							

LG	C114E20F	PC53A Chassis	1998						
LG	C114F80F	Beko 12.1 (?? not sure)							
LG	C114F84X	Beko 12.4/12.5	user remote part 7F5187, service remote part K99187						
LG	C120A50	PC11A							
LG	C120A80F(A)	PC31A Chassis							
LG	C120A90F	PC31A	1996						
LG	C120A96F	PC53A Chassis							
LG	C120C22F	PC42B Chassis							
LG	C120E20F	PC53A Chassis	1998						
LG	C120F60X	PC81A	1998						
LG	C120F80F	PC81A							
LG	C120F84X	Beko 12.4/12.5							
LG	C121A80F	PC31A Chassis							
LG	C121C22	PC42B Chassis							
LG	C121E20F	PC53A Chassis	1998						
LG	C121F60X	PC81A	1998						
LG	C121F80F	PC81A							
LG	C121Q20ET	PC99DA	1999						
LG	C121T20F	PC81B (=KC121T20F)	multistandard B/G, D/K, I						
LG	C121T24F	PC81B (=C121T20F)	multistandard B/G, D/K, I						
LG	C125H40	PC8KA							
LG	C129H40	PC8KA							
LG	C1S4361	PC04X							
LG	C1S4441	PC04X	Similar to Bush 2114						
LG	CIT2162X	PC08X8							
LG	CIT2165X	PC08X8							
LG	CIT2168F	PC04A							
LG	CIT2170F	PC12B							
LG	CIT2172F	PC07X2							
LG	CIT2175	PC07X2							
LG	CIT2180F	PC04A							
LG	CIT2181F	PC04A							
LG	CIT2190F	PC04A	Matsui 2091						
LG	CIT2191F	PC04A							
LG	CIT2570F	PC12B							
LG	CIT2588	MC05B							
LG	CIT2871F	PC12B							
LG	CIT4172	PC11A							
LG	CIT4175	PC11A							
LG	CIT4441	PC04X							
LG	CIT4442	PC04X							
LG	CIT4782	PC08X8							
LG	CIT4785	PC08X8							
LG	CIT4902	PC04A							
LG	CIT4905	PC04A							
LG	CIT6105	PC04X							
LG	CIT9172	PC11A							
LG	CIT9505	PC08X8							
LG	CIT9508	PC08X8							
LG	CIT9822	PC04A							
LG	CIT9825	PC04A							
LG	CIT9902F	PC04A							
LG	CIT9905	PC04A							
LG	CT2190	Matsui 2090							
LG	CY20B70Y	MC41A							
LG	D128F211	DC26A	2002						
LG	D128Z12	PD81A	1998						
LG	D132F211	DC26A	2002						
LG	D132Q82	PD00JA	2001						
LG	KC120F60X	PC81A	1998						
LG	KC121F60X	PC81A	1998						
LG	KC121T24F	PC81B (=C121T20F)	=C121T20F						
LG	KE14P21B/BX/S/SX	MV025A, Deck D-33	2002						
LG	KE14P2B/BX/GX/PX/SX	MV995B	2000, £175						
LG	KE14U43	MV995A	1999						
LG	KE14U73X	MV995A	1999						
LG	KE15FA91SX(BX)	MV025A	2003						
LG	KE15FA92SX(BX)	MV031A	2003/2004, £199						
LG	KE15FA9SX(BX)	MV995B	2002						
LG	KE20P30X	MV995B	2000, £220						
LG	KE20P31X	MV025A, Deck D-33	2002						
LG	KE20U73X	MV995A	1999						
LG	KE21P10T	MV008A, Deck D-33							
LG	KI14U30	MV55A							
LG	KI14U71	PV71A, Deck D-27							
LG	KI14U72	PV71A, Deck D-27							
LG	KI14V20	PC32A							
LG	KI14V38	MV55A	1996						
LG	KI20U30	MV55A							
LG	KI20U71	PV71A, Deck D-27							
LG	KI20U72	PV71A, Deck D-27							
LG	KI20V38	MV55A	1996						
LG	KY14V30	MC48A							
LG	KY20V30	MC48A							
LG	LAFINION 72	MC035A, see RZ29FC40RB	2003						
LG	LAFINION 82W	MC035A, see RZ32FZ40RB	2003						
LG	LE15A10	MF004A	2000/2001						
LG	LE15A15	ML012A	2001/2002						
LG	LPXG2	NP00EA	2000						
LG	LPXG22	NP00ED	2001						
LG	LPXG24	NP00ED	2001						
LG	MW30LZ10	MF02HA							
LG	MZ40PA10	MP00MA	2001						
LG	MZ40P210	MP00MC	2001						
LG	RE15LA30	MF004A	2000						
LG	RE20CB10MX	MC019A	2002/2003						
LG	RE20LA30	MF002A, LCD	2003, £739						
LG	RE21FB30RX	MC019A	2002						
LG	RE28FZ10PX	MC017A	2001			LOPTx 6174V-6003Q			
LG	RE28FZ10RX	MC022A	2003			LOPTx 6174V-5003G			
LG	RE28FZ30RQ	MC036A	2003						
LG	RE28FZ31RQ	MC022A	2003						
LG	RE29FA31PX	MC017A	2003						
LG	RE29FA33PX(X)	MC017A	2003, £539						
LG	RE32FZ10IP		2003, £569						
LG	RE32FZ10PX	MC017A	2001			LOPTx 6174V-6003E			
LG	RE32FZ30RQ	MC036A	2003						
LG	RE39NZ40RB	MP015D	2003						
LG	RE44SZ20RD	MB02JA	2002						
LG	RE49NZ21RB	MP015D	2002						
LG	RE56NZ21RB	MP015D	2002						
LG	R128CX10RX	Beko				service remote part K99187			
LG	R128CZ10RX	Beko 14.2	2002			chassis marked V180-190.03, V180-190.08			
LG	R132CZ10RX	Beko 14.2	2002						
LG	RZ15LA31	ML012A	2002/2003, £369						
LG	RZ15LA32	ML024A, LCD	2002/2003, £320						
LG	RZ17LZ10	ML027A, LCD	2002/2003, £489						
LG	RZ20LA31	LCD	2003, £719						
LG	RZ23LZ20	LCD	2003, £499						
LG	RZ29FC40RB	MC035A, Lafinion 72	2003						
LG	RZ30LZ19	LCD	2003, £1,995						
LG	RZ32FZ40RB	MC035A, Lafinion 82W	2003						
LG	WE32Q10IP	MC993A	1999						
LG	WF28A12T	MC52C	1996						
LG	WF32A14T	MC52C	1996						
LG	WF32A22DI	PC82A	1998						
Loewe	3781 (Aventos 3781)		2004 £650						
Loewe	63410	C8500							
Loewe	63415	C8500							
Loewe	63417	C8500							
Loewe	63471	C8500							
Loewe	MCP110	C8500							
Loewe	MCP114	C8500							
Logik	690	Orion 20LS	Saisho CT204						
Logik	698	Orion 20LT	Saisho CT208						
Logik	4090	TX90							
Logik	4094	TX90							
Logik	4098	TX100							
Logik	4290	TX100							

Logik	4294	TX100							
Logik	4298	TX10							
Logik	20A1	TX100							
Logik	20E1	TX90							
Logik	4298	TX100							
Logik	M125	KC							
Luxor	3351	L1 Chassis							
Luxor	3392	Mono Plus 2 (MP2)							
Luxor	3654	L1 Chassis							
Luxor	3711	B-2 Chassis							
Luxor	3781	180 Chassis	B-1 Chassis						
Luxor	4211	B-2 Chassis							
Luxor	4723	Nokia 3723							
Luxor	4743	Nokia 3743							
Luxor	4751	A-1 CHASSIS							
Luxor	4781	B-1 CHASSIS							
Luxor	4783	Nokia 3783							
Luxor	4791	B-2 CHASSIS							
Luxor	4854	L-1 CHASSIS							
Luxor	4874	L-2 CHASSIS							
Luxor	5111	BC Chassis	B-2 Chassis						
Luxor	5114	BC Chassis	B-2 Chassis						
Luxor	5134	B3-1 Chassis	SX9 Chassis						
Luxor	5141	SX9 Chassis							
Luxor	5151	A1 Chassis							
Luxor	5191	B2 Chassis							
Luxor	5192	Mono Plus 2 (MP2)							
Luxor	6355	SX9 Chassis							
Luxor	5564	L-2 CHASSIS							
Luxor	5566	K1							
Luxor	5592	Mono Plus 2 (MP2)							
Luxor	5601	BC Chassis	B-2 Chassis						
Luxor	5608	BC Chassis	B-2 Chassis						
Luxor	5609	B-2 Chassis							
Luxor	5619	SX9 Chassis							
Luxor	5634	SX9 Chassis							
Luxor	5636	SX9 Chassis							
Luxor	5639	SX9 Chassis							
Luxor	5644	SX9 Chassis							
Luxor	5661	A-1 CHASSIS							
Luxor	5664	A-1 CHASSIS							
Luxor	5681	B-1 CHASSIS							
Luxor	5691	B-2 Chassis							
Luxor	5698	B-2 Chassis							
Luxor	6355	SX9 Chassis							
Luxor	6368	K-1 Chassis							
Luxor	6385	M Chassis	Salora						
Luxor	6387	L-2 CHASSIS							
Luxor	6615	A-2 CHASSIS							
Luxor	6656	SX9 Chassis							
Luxor	6661	A-1 CHASSIS							
Luxor	6663	A-1 CHASSIS							
Luxor	6664	A-1 CHASSIS							
Luxor	6709	B-2 Chassis							
Luxor	6711	B-2 Chassis							
Luxor	6711	BC Chassis							
Luxor	6714	A-2 CHASSIS							
Luxor	6718	B-2 Chassis							
Luxor	6718	BC Chassis							
Luxor	6719	A-2 CHASSIS							
Luxor	6734	SX9 Chassis							
Luxor	6736	SX9 Chassis							
Luxor	6739	SX9 Chassis							
Luxor	6741	SX9 Chassis							
Luxor	6781	A-1 CHASSIS							
Luxor	6791	B-2 Chassis							
Luxor	6798	B-2 Chassis							
Luxor	7064	L-2 CHASSIS							
Luxor	7068	K-1 Chassis							
Luxor	7075	M Chassis	Salora						
Luxor	7076	M-1 CHASSIS							
Luxor	7085	M Chassis	Salora						
Luxor	7128	EURODIGI 16:9							
Luxor	8228	EURODIGI 16:9							
Luxor	8289	Nokia/Salora/Luxor MZ-chassis							
Luxor	9128	EURODIGI 16:9							
Luxor	18056449	SX9 Chassis							
Luxor	18067349	SX9 Chassis							
Luxor	17L67	L2 Chassis							
Luxor	FS71U1	FEATURE STEREO (FS Chassis)							
Matsui	1091X	Goodmans Compact-100							
Matsui	1400 IRE	11AK36A8	2003-2004	AK36 prod.code: 10023024					
Matsui	1402								
Matsui	1403								
Matsui	1407	orion chassis	PCB marked TM7384A	serv.mode: set volume to minimum, press VOL- on TV and '9' on R/C, navigate using Ch+/Ch-, adjust using Vol+/Vol-, to					
Matsui	1407RS	same chassis to 2107N	serv.mode: see Matsui 1407						
Matsui	1408R	Orion chassis	PCB TM9414A, TM9414B, Micro OEC6053	Remote 076R0BR060					
Matsui	1408T	Orion TV134TX	PCB marked TM9414B, Micro OEC6053A	Remote 07660BQ150					
Matsui	1409T	Orion chassis, serv.mode see 1407	PCB marked TMX468A	076R0DG020	scan coils XY-14016AL2 E157951 fail very often				
Matsui	1409T	Orion chassis, serv.mode see 1407	PCB marked TMX468A	076R0DG010	scan coils XY-14016AL2 E157951 fail very often				
Matsui	140R	=140R Orion chassis	PCB marked TM6362						
Matsui	140T	=140T Orion chassis	PCB marked TM6362						
Matsui	1410	Amstrad CTV1401	Saisho CT1400						
Matsui	1410	Saisho CT142R	ORION 14PS(B)						
Matsui	1410R	Orion CTN BB							
Matsui	1410T	Orion CTN BB							
Matsui	1414R		there is no elec.service mode, but there is child lock, volume lock and tuning lock						
Matsui	1420	Orion 14DS	Saisho CT141						
Matsui	1420A	Saisho CT141X							
Matsui	1420B								
Matsui	1420T	Orion chassis, serv.mode see 1407	2002/2003 £70, 2004 £60	PCB TMA504A, Micro OECF00	INIT 01 -> EEPROM 03H, INIT 02 ->04H and so on				
Matsui	1420TSIL(B)	Orion chassis, serv.mode see 1407	2004	PCB TMB557A, Micro PCM195C30ECF009B (OECF009B)					
Matsui	1421T Silver		2004 £60						
Matsui	1422								
Matsui	1424	TATUNG 190/195							
Matsui	1430								
Matsui	1430A								
Matsui	1434	Tatung 190							
Matsui	1435	Orion 14A chassis	PCB marked TM0176B						
Matsui	1435B	Orion chassis	PCB marked TM0176C						
Matsui	1436	Bush 2004	Alba CTV100						
Matsui	1436XA								
Matsui	1440	Orion 14DR	Saisho CT142R						
Matsui	1440A	Saisho CT142RX							
Matsui	1450	Binatone 01/9014	Boots CTV1414R						
Matsui	1450	Matsui 1455							
Matsui	1450	Saisho CT147R	HINARI CT4	Dansai CTV1477					
Matsui	1455	Alba CTV4805	Onwa						
Matsui	1460	1660 2060							
Matsui	1465								
Matsui	1466	ORION 14LR							
Matsui	1476	Orion chassis	PCB marked TM0280A	LOPTx Q401 2SD2089 LOPTx FCM-14B007A					
Matsui	1480	Saisho CT149							
Matsui	1480A	Orion 14DT	Saisho CT149X						
Matsui	1480B								
Matsui	1481								
Matsui	1481B	Orion 14AT	PCB marked TM0157						
Matsui	1482								
Matsui	1496(T) (R)	Matsui 2096, CHASSIS SR1	Crown CRP2196NT						
Matsui	1498	Onwa							
Matsui	1408R	see 1408R (letter "O" = zero)							
Matsui	14R1	Grundig G1000							
Matsui	14T1	Grundig G1000	GT1402						
Matsui	14TR50	Tatung F chassis							
Matsui	14TV/DVR1	TV/DVD/VCR Combi	2004 £199						
Matsui	14V1	G1000	GT1401						
Matsui	14V1R	GrundigCUC7301	P37-071						
Matsui	14V1T	GrundigCUC7301	P37-731						
Matsui	14V2R	CUC7303							

[illegible]

Mitsubishi	CT15MS1TX	EE2							
Mitsubishi	CT180								
Mitsubishi	CT186								
Mitsubishi	CT1902								
Mitsubishi	CT1905								
Mitsubishi	CT2023								
Mitsubishi	CT2027								
Mitsubishi	CT2027								
Mitsubishi	CT2101								
Mitsubishi	CT2117								
Mitsubishi	CT2124	Euro 4 Chassis							
Mitsubishi	CT2125								
Mitsubishi	CT2131	Euro 4 Chassis							
Mitsubishi	CT2132	Euro 4 Chassis							
Mitsubishi	CT2141	Euro 4 Chassis							
Mitsubishi	CT2142	Euro 4 Chassis							
Mitsubishi	CT2144	Euro 4 Chassis							
Mitsubishi	CT2145	Euro 6 Chassis							
Mitsubishi	CT2145BM	Euro 6 Chassis							
Mitsubishi	CT2146	Euro 6 Chassis							
Mitsubishi	CT21461X	Euro 6 Chassis	EURO 4						
Mitsubishi	CT2153	Euro 4Z Chassis							
Mitsubishi	CT2154	Euro 4 Chassis							
Mitsubishi	CT2155	Euro 4Z Chassis							
Mitsubishi	CT21A2STX(LST)	Euro 12 Chassis							
Mitsubishi	CT21A3STX	Euro 12 Chassis							
Mitsubishi	CT21A5STX	Euro 14FS							
Mitsubishi	CT21AV1B	EE3							
Mitsubishi	CT21M1	Euro 10 Chassis							
Mitsubishi	CT21M1BM	Euro 10 Chassis							
Mitsubishi	CT21M1LM	Euro 10 Chassis							
Mitsubishi	CT21M2	Euro 14							
Mitsubishi	CT21M3	Euro 14							
Mitsubishi	CT21M5B(T)	EE4							
Mitsubishi	CT2206								
Mitsubishi	CT2217								
Mitsubishi	CT2223								
Mitsubishi	CT2224								
Mitsubishi	CT2227								
Mitsubishi	CT2230								
Mitsubishi	CT2517	Euro 1 Chassis							
Mitsubishi	CT2525	Euro 10 Chassis							
Mitsubishi	CT2528	Finlux 9000							
Mitsubishi	CT2531	Euro 4 Chassis							
Mitsubishi	CT2532	Euro 4 Chassis							
Mitsubishi	CT2533								
Mitsubishi	CT2534	Euro 4 Chassis							
Mitsubishi	CT2545	Euro 4 Chassis							
Mitsubishi	CT2553	Euro 4Z Chassis							
Mitsubishi	CT2554								
Mitsubishi	CT2555	Euro 4Z Chassis							
Mitsubishi	CT25A2STX(LST)	Euro 12 Chassis							
Mitsubishi	CT25A3STX	Euro 12 Chassis							
Mitsubishi	CT25A4STX(LST)	Euro 12 Chassis							
Mitsubishi	CT25A5STX	Euro 14FS							
Mitsubishi	CT25A6STX	Euro 12 Chassis							
Mitsubishi	CT25AV1B	EE3							
Mitsubishi	CT25AV1BDS	EE3 Chassis	TV/Sat Rx						
Mitsubishi	CT25B2STX	Euro 11 Chassis							
Mitsubishi	CT25B3ST	B3							
Mitsubishi	CT25M1	M1 Chassis Euro 10 Chassis							
Mitsubishi	CT25M2TX	Euro 14							
Mitsubishi	CT25M3TX	Euro 14							
Mitsubishi	CT25M5BT	EE4							
Mitsubishi	CT28AV1B	EE3							
Mitsubishi	CT28BW2B	EE3 Chassis							
Mitsubishi	CT28BW2BD	EE3W							
Mitsubishi	CT2964	Euro 4Z Chassis							
Mitsubishi	CT2965	Euro 8F Chassis	PSU similar to Euro 10						
Mitsubishi	CT29A4ST	Euro 12 Chassis							
Mitsubishi	CT29A6ST	Euro 12 Chassis							
Mitsubishi	CT29AT5								
Mitsubishi	CT29B2STX	Euro 11 Chassis							
Mitsubishi	CT29B3ST	B3							
Mitsubishi	CT29B4ST	B4							
Mitsubishi	CT29BV1(BD)	EE3W							
Mitsubishi	CT32BW1B	W1							
Mitsubishi	CT32CW1BD	EW1							
Mitsubishi	CT33B3ST	B3							
Mitsubishi	CT33C1STX(TX)								
Mitsubishi	CT37C1STX(TX)								
Mitsubishi	CT37C2STX	E9							
Murphy	3510T	Goodmans FST51TT							
Murphy	CTV 3510	Murphy CTV 3540T							
Murphy	CTV3500	Cathay/Osaki P22G	Phase PH20567				Susumu FX14S/FX1400R		
Murphy	CTV3540T	Goodmans FST51TT							
Murphy	M14R01	Fidelity ZX4000	Fidelity CTV1404R						
Murphy	M1500	Fidelity ZX4000							
Murphy	M22S01	Fidelity ZX4200							
Murphy	M22S01	Fidelity ZX4200							
Murphy	M22T01	Fidelity ZX4000							
Murphy	MC6124	Bush BC6004							
Naiko	N1088	Goodmans Compact-110							
Naiko	N2810DVD	PT92 +DVD	2003/2004 Safeways £299						
Naiko	N2811W	PT92							
Naiko	N2818W	PT92							
Naiko	N2850W	PT92	2003/2004						
Naiko	N2866	PT90A +DVD							
Naiko	N2897	F16							
Naiko	N3211W	PT92							
Naiko	N3280W	PT90	2003/2004						
Narita	DVTV2	TV+DVD Profilo PT90C chassis							
NEC	PF32W01	Daewoo SC132 chassis	=Daewoo model DSC3261H						
NEI	1288	Mono							
NEI	1451R/TX	Indiana 100 Chassis	Bush						
NEI	1461R	Indiana 100 Chassis	Bush						
NEI	1481R	Indiana 100 Chassis	Similar to NEI2031						
NEI	1482	Indiana 100 Chassis	Bush						
NEI	14FRE								
NEI	14SRE		Sunkyoung						
NEI	1551TX	Indiana 100 Chassis	Bush						
NEI	1581TX	Indiana 100 Chassis	Bush						
NEI	1601								
NEI	2031R/TX	Indiana 100 Chassis							
NEI	2041R	Indiana 200 Chassis	Bush						
NEI	2047(TX)	Indiana 200 Chassis							
NEI	2051R/TX	Indiana 200 Chassis	Bush						
NEI	2052R	Indiana 200 Chassis	Bush						
NEI	2131R	Indiana 100 Chassis	Bush						
NEI	2147(TX)	Indiana 200 Chassis							
NEI	2151R/TX	Indiana 200 Chassis	Bush						
NEI	2152R	Indiana 200 Chassis							
NEI	2181R	Indiana 200 Chassis	Bush						
NEI	2591FTXN	CE25							
NEI	2891FTXN	CE25							
NEI	5544	11AK03 Chassis							
NEI	ART701	Evelux E5 (use remote to bring out of stby)	Evelux = Elektronika Velenje in Slovenia						
NEI	C25F1FXN	CE25							
NEI	C28F1FXN	CE25							
NEI	CTV61	Indiana 100 Chassis							
NEI	E14D1X	Evelux E5							
NEI	E14TX	Evelux E5							
NEI	E20C1X	Evelux E5							
NEI	E2591TFXN	CE25							
NEI	E25G1TFXN	Evelux E5							
NEI	E28G1TFXN	Evelux E5							
NEI	NE3743TX	11AK08							
NEI	NE5147	11AK03 Chassis							
NEI	NE5155NT	11AK10							

NEI	NE5159NT	11AK10							
NEI	NE5159TX	11AK10							
NEI	NE5555	11AK10							
NEI	NE5559TX	11AK10							
Network	1210	Similar to NE11288	Mono						
Network	1286		Mono						
Network	1401	Bush T24	Toshiba X53						
Network	1402	Goldstar							
Network	1414	Grundig GSC-100							
Network	1430	Goldstar							
Network	1451R	Indiana 100 Chassis	NEI						
Network	1461R	Indiana 100 Chassis	NEI						
Network	1481R	Indiana 100 Chassis	NEI						
Network	1482R	Indiana 200 Chassis	NEI						
Network	1551TX	Indiana 100 Chassis	NEI						
Network	1581TX	Indiana 100 Chassis	NEI						
Network	2020	Grundig GSC-100							
Network	2031R	Indiana 100 Chassis							
Network	2031TX	Indiana 100 Chassis							
Network	2041R	Indiana 200 Chassis							
Network	2051R	Indiana 200 Chassis							
Network	2052R	Indiana 200 Chassis							
Network	2081	Indiana 200 Chassis							
Network	21311X	Indiana 200 Chassis							
Network	2151R	Indiana 200 Chassis							
Network	2152R	Indiana 200 Chassis							
Network	2181	Indiana 200 Chassis							
Network	2571	CE25							
Network	2591	CE25							
Network	2871	CE25							
Network	2891	CE25							
Network	3000172	Goldstar							
Network	NW1414	Grundig GSC-100							
Network	NW2020	Grundig GSC-100							
Nikkai	2155	Indiana 100 Chassis							
Nikkai	2156T	Indiana 100 Chassis							
Nikkai	Baby 10	Osaki P10R							
Nikkai	Baby 10	Samsung C1210R / Boots CTV10R	Akura Tourer CX10					Genexia CTV1001	
Nikkai	K3743TX	11AK08							
Nikkai	K5155NT	11AK10							
Nikkai	K5159NT	11AK10							
Nikkai	NT20	Sentra STX600	Susumu FX20						
Nikkai	TLG0101	Sentra STX600	Solarvox CML14RC						
Nikkai	TLG0909	Solarvox CML14							
Nikkai	TLG100	Solarvox 142TT	Osume CTV1486T						
Nikkai	TLG101	Hinari TVA1							
Nikkai	TLG120TX	Indiana 100 Chassis							
Nikkai	TLG1407T	Indiana 100 Chassis							
Nikkai	TLG1409								
Nikkai	TLG1432								
Nikkai	TLG1433								
Nikkai	TLG1447	Indiana 200 Chassis							
Nikkai	TLG1447T	Indiana 200 Chassis							
Nikkai	TLG1447TC	Indiana 100 Chassis							
Nikkai	TLG14R	Alba CTV14R							
Nikkai	TLG151T	Indiana 100 Chassis							
Nikkai	TLG200								
Nikkai	TLG2000	Indiana 100 or 200 Chassis							
Nikkai	TLG201	Indiana 100 Chassis							
Nikkai	TLG20TX	Indiana 200 Chassis							
Nikkai	TLG2121	Goodmans CTV2R							
Nikkai	TLG2122	Goodmans CTV2T							
Nikkai	TLG2149	Indiana 200 Chassis							
Nikkai	TLG2151TX	Indiana 200 Chassis							
Nikkai	TLG2155	Indiana 100							
Nikkai	TLG2156	Indiana 100							
Nikkai	TLG2195								
Nikkai	TLG2501	NEI CE25							
Nikkai	TLG2801	NEI CE25							
Nikkai	TLG511	Indiana 100 Chassis							
Nikkai	TLG51TX	Indiana 200 Chassis							
Nikkai	TLG88/89	Fidelity C14M07	Harwood HTV9014R					Hinari CT11	
Nikkai	TLG88/89	Osume 1484R	Soundwave CTV1401R					Solarvox 140	
Nikkai	TLG99	Dansai TA11401	Osume CTV1484R					Fidelity C14M08	
Nikkai	TLG99	Tashiko 14F841	Goodmans C140					Solarvox 141	
Nikkai	TV1407T	Indiana 100 Chassis	Bush						
Nokia	1425HS	EUROMONO 2							
Nokia	1430HS	EUROMONO 1/2							
Nokia	1530UK HS	EUROMONO 2							
Nokia	1630HS	EUROMONO 1 OR 2							
Nokia	1725HS	EUROMONO 2							
Nokia	1730HS	EUROMONO 1 OR 2							
Nokia	1741HS	HOTEL PLUS	tuning - for RCN612 press MUTE,VISION,1servis- MUTE,RED,TV (or STOP)						
Nokia	2125HS	EUROMONO 2							
Nokia	2141HS	HOTEL PLUS	tuning - for RCN612 press MUTE,VISION,TV; for RCN624 press MUTE,VISION,STOP.						
Nokia	3721(T)	Mono Plus 2 (MP2)							
Nokia	3723	Luxor 4723							
Nokia	3724UKFX	MonoPlus							
Nokia	3743	Luxor 4743							
Nokia	3755UK	MONOPLUS 90							
Nokia	3783	Luxor 4783							
Nokia	5121(T)	Mono Plus 2 (MP2)							
Nokia	5155	MONOPLUS 90							
Nokia	5521(T)	Mono Plus 2 (MP2)							
Nokia	5556 UK SFN	Monoplus 110							
Nokia	5575 UK SFN	STEREO PLUS							
Nokia	6355 NICAM	STEREO PLUS							
Nokia	6356 UK SFN	Monoplus 110							
Nokia	6364UKSFN	Eurostereo 2							
Nokia	7155UK SFN	STEREO PLUS							
Nokia	7156 UK SFN	Monoplus 110							
Nokia	7165 UK SFN	STEREO PLUS							
Nokia	7204MAC	EURODIGI 16:9							
Nokia	7291-T	Nokia/Salora/Luxor MZ-chassis							
Nokia	7294UK	Eurodigi 16:9 II	1993					PSU IC LF0112	
Nokia	8284MAC	EURODIGI 16:9							
Nokia	8284SAT	EURODIGI 16:9							
Nokia	8291-T	Nokia/Salora/Luxor MZ-chassis							
Nokia	8294SAT	EURODIGI 16:9							
Nokia	8294UK	Eurodigi 16:9 II	1993					PSU IC LF0112	
Nokia	CT3711	SANYO							
Nokia	CT3724	MONOPLUS							
Nokia	CT4030UK	CORE2							
Nokia	CT5111UK	CORE2							
Nokia	CT5124	MONOPLUS 90DEG							
Nokia	Digivision 6381	Nokia digital chassis B-E2							
Nokia	Digivision 6381 N UK	Nokia digital chassis B-E2							
Nokia	Digivision 7171	Nokia digital chassis B-E2							
Nokia	Digivision 7182	Nokia digital chassis B-E2							
Nokia	Digivision 8281	Nokia digital chassis B-E2							
Nokia	FP72B2	=SFN7296							
Nokia	FP82B2	=SFN8296							
Nokia	FS91E1	FS chassis							
Nokia	FX3724UK	MonoPlus							
Nokia	FX3725	MONOPLUS							
Nokia	FX4030UK	CORE2							
Nokia	FX4530UK	CORE2							
Nokia	FX5530UK	CORE2							
Nokia	FX5532	EUROMONO 2							
Nokia	FX6332	EUROMONO							
Nokia	MP51A1	MONOPLUS							
Nokia	SFN3755	MONOPLUS							
Nokia	SFN5155	MONOPLUS							
Nokia	SFN5166	MONOPLUS							
Nokia	SFN5554	STEREO PLUS							
Nokia	SFN5573	Eurostereo 2 B-F							
Nokia	SFN6374	Eurostereo 2 B-F							
Nokia	SFN6386	FEATURE STEREO (FS Chassis)							
Nokia	SFN7173	Eurostereo 2 B-F							

Nokia	SFN7174	Eurostereo 2 B-F							
Nokia	SFN7186	FEATURE STEREO (FS Chassis)							
Nokia	SFN7296	FEATURE STEREO PLUS							
Nokia	SFN8296	FEATURE STEREO PLUS							
Nokia	SP55A1.5554	STEREO PLUS							
Nokia	SP63D1.6355UK	STEREO PLUS							
Nokia	SP71D1	STEREO PLUS							
Nokia	SP71L1	STEREO PLUS	Akai CT2867						
Nokia	ST51A1	MONOPLUS							
Nokia	ST51D2	MONOPLUS							
Nordmende	1434PI	F10							
Nordmende	1444	F10							
Nordmende	2112	F10							
Nordmende	2513A	F8							
Nordmende	3434	F10							
Nordmende	3601		Ferguson 3787						
Nordmende	3602	F8							
Nordmende	3604	F14							
Nordmende	4230	FV I	Ferguson 3787						
Nordmende	4231		Ferguson 3787						
Nordmende	5038	F15/16							
Nordmende	5205	F15/16							
Nordmende	5432	F11							
Nordmende	6559	F15							
Nordmende	7000	F15							
Nordmende	778535A	F5 TT							
Nordmende	8180		Ferguson 3787						
Nordmende	9572D	F5 TT							
Nordmende	982512H	F10							
Nordmende	982514H	F10							
Nordmende	982515H	F10							
Nordmende	F11B	Ferguson ICC3							
Nordmende	F15	Ferguson ICC5	Telefunken 617						
Nordmende	F16	Ferguson ICC5	Telefunken 517						
Nordmende	F17/F18	Ferguson ICC5	Telefunken 518/618/B/A						
Nordmende	F19	Ferguson IKC2							
Nordmende	F19/F20	Ferguson IKC2	Telefunken 418/A						
Nordmende	F20	Ferguson IKC2							
Nordmende	F22	Ferguson TX80	Telefunken 318A						
Nordmende	F23	ICC8-S	Telefunken 418						
Nordmende	F23-11	ICC7-S	Telefunken 418B-ST						
Nordmende	F24	ICC8-M	Telefunken 418C						
Nordmende	F24-11	ICC7-M	Telefunken 418B						
Nordmende	Futura 55	chassis F18							
Oceanic	B294SAT	Eurodigi 16.9							
Okishi	N2818W	PT92							
Onimax	2818	TV9.3 Multi (Schneider)	Micro IC901 ST92R195B0/EPF	LOPTx 1372.0031, =HR8409					
Onwa	K9228	Akai CT2862UNT							
Orion	14AT	Matsui 1481B							
Orion	14DR	Matsui 1440	Saisho CT142R						
Orion	14DS	Matsui 1420	Saisho CT141						
Orion	14DT	Matsui 1480A	Saisho CT149X						
Orion	14LR	Matsui 1466							
Orion	14PR	Amstrad CTV1409	Saisho CT14R	Triumph CTV8208					
Orion	14PS	Amstrad CTV1401	Matsui 1410	Saisho CT1400					
Orion	16BR	Matsui 1640	Saisho CT162R						
Orion	18PS	Matsui 1810	Saisho CT1800						
Orion	20L S	Logik 690	Saisho CT204						
Orion	20L T	Logik 698	Saisho CT208						
Orion	286KB	4300	PCB marked B-4101						
Orion	28ZKM TV28F44	4400							
Orion	28ZKN TV28F44	4400							
Orion	3850	Bush 4400 chassis							
Orion	C1500	combi Orion chassis	PSU PCB VPA150A, main PCB VMA230A	Micro OEC0107					
Orion	CTV144	Saisho CX14R	Triumph CTV8212						
Orion	CTV164	Saisho CX16R	Triumph CTV8312						
Orion	T28F44	4400							
Orion	TV134TX	Matsui 1408T		Remote 07660BQ160					
Orion	TV2844W	4400 chassis							
Orion	TV400TX	chassis CTT-H AA							
Orion	TV4400NTX	4400 chassis							
Orion	TV450TX (TV450R)	CTN AA chassis							
Orion	TV700BR	CTN AA chassis							
Orion	TV700SLTX	CTN BB chassis							
Orion	TV800TX	CTN AA chassis							
Osaki	3214S	Orion 14A chassis							
Osaki	CI5013T	Samsung CI5052XT							
Osaki	CTV14	Jackson Mk2	Triumph CTV8209						
Osaki	P10	Nikkai Baby 10 etc							
Osaki	P140	Philips GR1-AX	Philips 14GR1021						
Osaki	P142	Akura CX4							
Osaki	P145	Philips GR1-AX							
Osaki	P20G	Murphy CTV3500							
Osaki	P20H	Hinari CT4							
Osaki	P60G	Hitachi NP8CQ							
Osume	CTV1474R	Bush Z214							
Osume	CTV1484R	Solarvox 141	Nikkai TLG99	Harwood HTV9014R					
Osume	CTV1486T	Nikkai TLG100T							
Pacific	PDTV14-100	Orion chassis	Micro 195C6PC00ECF011A (OECF011A)						
Pacific	PTV2701T	Schneider chassis TV9							
Pacific	PTV3604	CTS AA	Micro SAA5541PS/M5/0330						
Pacific	PTV3605	Beko T2 8	PCB marked G80.190-02	LOPTx 003071094 (058.413-TR5), equiv. FBT41041					
Pacific	PTV3606	Orion chassis	PCB marked TMB557A						
Pacific	PTV5102	CTS AA		serv.: select prog 75, press OSD key (+) on R/C and MENU on TV together for 10 sec, green S will appear in lower left c					
Pacific	PTV7001T	E9 chassis (Evelux, made in Slovenia)	Micro SDA5255-B001						
Pacific	PTV7002	E9 chassis (Evelux, made in Slovenia)							
Pacific	PTV7003	E9 chassis (Evelux, made in Slovenia)	Micro SDA5255-B002						
Panasonic	1665	Z1							
Panasonic	21V2	Alpha 4							
Panasonic	25A3	Euro 1							
Panasonic	25X1DP	Alpha 4							
Panasonic	28X1	Alpha 4H							
Panasonic	28X1DP	Alpha 4							
Panasonic	CT20S	U4 Chassis							
Panasonic	CT22S	U4W Chassis							
Panasonic	TC1302	M6							
Panasonic	TC1303	M6							
Panasonic	TC1404	M11							
Panasonic	TC1405	M11							
Panasonic	TC1406	M11							
Panasonic	TC1407	M12							
Panasonic	TC1408	M12							
Panasonic	TC1460	Z1							
Panasonic	TC1465	Z1							
Panasonic	TC1470	Z1							
Panasonic	TC1475	Z1							
Panasonic	TC1480	Z3							
Panasonic	TC1485T	Z3	1990						
Panasonic	TC1483R	Z375 (DAEWOO CP375)							
Panasonic	TC14B4R(B)	Z185 (Daewoo CP185)							
Panasonic	TC14JR1	Z7							
Panasonic	TC14K1R	Z7							
Panasonic	TC14L3R	MX1A							
Panasonic	TC14S1M	Z5							
Panasonic	TC14S1R/B	Z5							
Panasonic	TC14S1R/BH	Z5							
Panasonic	TC14S2R	Z5							
Panasonic	TC14S3R(W)	Z7							
Panasonic	TC14S3RC	Z7	nonUK Pal B/G						
Panasonic	TC14S4RL	Z7		remote TNQ8E0460					
Panasonic	TC15M1	Z4							
Panasonic	TC15M1M	Z4							
Panasonic	TC15M1R	Z4							
Panasonic	TC15M1T	Z4							
Panasonic	TC15M2	Z4							
Panasonic	TC15M2R	Z4		remote TNQ8E0448					
Panasonic	TC15MIR	Z1							
Panasonic	TC1601	M11							
Panasonic	TC1602	M11							

Panasonic	TC1631	U4							
Panasonic	TC1632	U4							
Panasonic	TC1633	U4							
Panasonic	TC1635	U4							
Panasonic	TC1637	U4							
Panasonic	TC1641	U4							
Panasonic	TC1651	U5							
Panasonic	TC1665	Z1							
Panasonic	TC1675	Z1							
Panasonic	TC1752	U5							
Panasonic	TC1785	Z3							
Panasonic	TC1786	Z3							
Panasonic	TC1802	M11							
Panasonic	TC1802U	M7							
Panasonic	TC1803	M7							
Panasonic	TC1807	M9							
Panasonic	TC1808	M11							
Panasonic	TC1810	M11							
Panasonic	TC1830	M12							
Panasonic	TC1832	M12							
Panasonic	TC200	M11							
Panasonic	TC2000	U3							
Panasonic	TC2002	U1							
Panasonic	TC2006	M7							
Panasonic	TC201	M9	M11						
Panasonic	TC2011	U3W							
Panasonic	TC202	M11							
Panasonic	TC202	PIX-M9							
Panasonic	TC2020	M11							
Panasonic	TC2024	U3W							
Panasonic	TC202G	PIX-M9							
Panasonic	TC2030	M12							
Panasonic	TC2031	U4W							
Panasonic	TC2033	U4							
Panasonic	TC2035	M11							
Panasonic	TC204	M9							
Panasonic	TC2043	U4W							
Panasonic	TC2051	U5							
Panasonic	TC2055	M11							
Panasonic	TC2056	M11							
Panasonic	TC2061	U5							
Panasonic	TC2076	M11							
Panasonic	TC208	U3							
Panasonic	TC2086	M11							
Panasonic	TC210	M11							
Panasonic	TC211	M12							
Panasonic	TC2110	U5N							
Panasonic	TC2112	U5							
Panasonic	TC212	M11							
Panasonic	TC214	M11							
Panasonic	TC215	M12							
Panasonic	TC216	M11							
Panasonic	TC2160	U5N							
Panasonic	TC217	M11							
Panasonic	TC2175	Z1							
Panasonic	TC218	M11							
Panasonic	TC2185	Z3							
Panasonic	TC2195	Z3T							
Panasonic	TC21K1R	Z7							
Panasonic	TC21L3R	MX1A							
Panasonic	TC21M	Z4							
Panasonic	TC21M1R	Z4							
Panasonic	TC21M2R	Z4							
Panasonic	TC21R	ALPHA2							
Panasonic	TC21R1	ALPHA2							
Panasonic	TC21S1	Z5							
Panasonic	TC21S3	Z7							
Panasonic	TC21S4RL	Z7							
Panasonic	TC220	M11							
Panasonic	TC2201	U1	PIU-S1C						
Panasonic	TC2202	U1							
Panasonic	TC2203	U1							
Panasonic	TC2204	U1							
Panasonic	TC2205	U2							
Panasonic	TC2206	U1/U4							
Panasonic	TC2207	U2							
Panasonic	TC2208	U2							
Panasonic	TC2209	U3							
Panasonic	TC221	U3							
Panasonic	TC2210NS	M11							
Panasonic	TC2210SP	M8							
Panasonic	TC2210VR	M12							
Panasonic	TC2211	U3W							
Panasonic	TC2213	U3W							
Panasonic	TC2216	U3W							
Panasonic	TC222	M11							
Panasonic	TC2220	M11							
Panasonic	TC2221	U3							
Panasonic	TC2223	U3							
Panasonic	TC2225	U3							
Panasonic	TC2226	U3							
Panasonic	TC2229	U3							
Panasonic	TC223	M12							
Panasonic	TC2231	M7							
Panasonic	TC2232	U4W							
Panasonic	TC2233	U4W							
Panasonic	TC2234	U4							
Panasonic	TC2235	M11							
Panasonic	TC2235UR	U4							
Panasonic	TC2239	U4							
Panasonic	TC224	M11							
Panasonic	TC2240	U4							
Panasonic	TC2243	U4							
Panasonic	TC225	U3							
Panasonic	TC2251	M8							
Panasonic	TC2253	U5							
Panasonic	TC2255	M11							
Panasonic	TC2256	M11							
Panasonic	TC2263	U5							
Panasonic	TC2271	M8							
Panasonic	TC2276	M11							
Panasonic	TC2283	U2 / U3							
Panasonic	TC2291	U2							
Panasonic	TC2292	U2							
Panasonic	TC2293	U2							
Panasonic	TC230	M12							
Panasonic	TC232	M12							
Panasonic	TC233	M12							
Panasonic	TC234	M12							
Panasonic	TC235	M12							
Panasonic	TC2461	U5							
Panasonic	TC2475	ALPHA1W							
Panasonic	TC24R1	ALPHA2							
Panasonic	TC26	M11							
Panasonic	TC2600	M8							
Panasonic	TC2603	M11							
Panasonic	TC261	M8							
Panasonic	TC2610	M11							
Panasonic	TC262	M7	PIUS1						
Panasonic	TC2620	M11							
Panasonic	TC2622	U3W							
Panasonic	TC2629	U3							
Panasonic	TC262G	M11							
Panasonic	TC262GA	PIUS1							
Panasonic	TC262SPM	M9							
Panasonic	TC2630	M12							
Panasonic	TC2633	U4							
Panasonic	TC2634	U4							
Panasonic	TC2635	M11							

Panasonic	TC2636	U4							
Panasonic	TC2637	U4							
Panasonic	TC2640	U4							
Panasonic	TC2641	U4W							
Panasonic	TC2650	M8							
Panasonic	TC2651	M8							
Panasonic	TC2656	M11							
Panasonic	TC265SPM	M9							
Panasonic	TC2665	M11							
Panasonic	TC2671	M8							
Panasonic	TC2675	M11							
Panasonic	TC2676	M11							
Panasonic	TC2680	U2							
Panasonic	TC2681	U2							
Panasonic	TC2683	U3							
Panasonic	TC2684	U3							
Panasonic	TC2686	M11							
Panasonic	TC2690	U3							
Panasonic	TC271	M8							
Panasonic	TC272	M8							
Panasonic	TC273P	M7							
Panasonic	TC273S	M9							
Panasonic	TC273SP	M7							
Panasonic	TC273SPM	M9							
Panasonic	TC273W	M12							
Panasonic	TC274	M7							
Panasonic	TC275	PIX-M8	M11						
Panasonic	TC275G	PIX-M8							
Panasonic	TC290	M7							
Panasonic	TC292	M9							
Panasonic	TC293	M7							
Panasonic	TC294	M11							
Panasonic	TC295	M9							
Panasonic	TC296	M11							
Panasonic	TC297	M9							
Panasonic	TC298	M11							
Panasonic	TC300SP	M6							
Panasonic	TC333	PIX-M6							
Panasonic	TC333G	PIX-M6							
Panasonic	TC361	M7							
Panasonic	TC371	PBX-M7A2							
Panasonic	TC381	PIX-M6A							
Panasonic	TC381G	M6							
Panasonic	TC381U	M6							
Panasonic	TC400	M11							
Panasonic	TC410	M11							
Panasonic	TC421	M11							
Panasonic	TC4230	M12							
Panasonic	TC430	M12H							
Panasonic	TC430G	M12H							
Panasonic	TC431	M12C							
Panasonic	TC431GR	M12C							
Panasonic	TC450	M12H							
Panasonic	TC450G	M12H							
Panasonic	TC4688	M12							
Panasonic	TC471	M11							
Panasonic	TC471NP	M7							
Panasonic	TC471SP	M7							
Panasonic	TC471SPM	M9							
Panasonic	TC481	M6							
Panasonic	TC482	M11							
Panasonic	TC482S	M6							
Panasonic	TC482SP	M6							
Panasonic	TC4830	M12							
Panasonic	TC48G								
Panasonic	TC492	PIX-M11							
Panasonic	TC492G	PIX-M11							
Panasonic	TC493	M11							
Panasonic	TC610	M11							
Panasonic	TC610SPM	M9							
Panasonic	TC681MN	M12							
Panasonic	TC681MRS	M12							
Panasonic	TC682	PIX-M11							
Panasonic	TC682GR	PIX-M11							
Panasonic	TC683	M11							
Panasonic	TC684	M11							
Panasonic	TC685	M11							
Panasonic	TC687	M12							
Panasonic	TC688	M12							
Panasonic	TC800	X8							
Panasonic	TC810	M11							
Panasonic	TC811	M11							
Panasonic	TC815	M11							
Panasonic	TC816	M11							
Panasonic	TC817	M11							
Panasonic	TC820	M11							
Panasonic	TC830	M12							
Panasonic	TC831	M12							
Panasonic	TC871	M8							
Panasonic	TC872	M8							
Panasonic	TC873	M8							
Panasonic	TC874	M7							
Panasonic	TC874SPM	M9							
Panasonic	TC890SPM	M9							
Panasonic	TC890W	M12							
Panasonic	TC9200	U1							
Panasonic	TCAL20	M11							
Panasonic	TCAL26	M11							
Panasonic	TCV1	M11							
Panasonic	TX1	ALPHA1							
Panasonic	TX1485	ALPHA1							
Panasonic	TX1483T	Z375 (Daewoo CP375)							
Panasonic	TX1484T	Z185 (Daewoo CP185), 2003 around £110	Service Mode: Select channel 99, set sharpness to minimum, hold set's DOWN key and press MUTE on remote at the same time. Use the up/down keys to select the						
Panasonic	TX14GV1	Z421 (Daewoo CP420, K-Mecha deck)							
Panasonic	TX14GV2	Z082PF (Daewoo CP082), deck K30	PSU I801 STRF6653						
Panasonic	TX14JT1	Z7							
Panasonic	TX14K1T	Z7							
Panasonic	TX14K2T	Z7							
Panasonic	TX14S1R	Z5							
Panasonic	TX14S1T/B(or BH)	Z5				remote TNQ8E0461			
Panasonic	TX14S2T	Z5				remote TNQ8E0461-1			
Panasonic	TX14S3T(W)	Z7				remote EUR511300			
Panasonic	TX14S3TC	Z7	nonUK Pal B/G						
Panasonic	TX14S4TL	Z7				remote EUR511300			
Panasonic	TX15AT1	ZM3L (Orion chassis)	remote EUR511300			PCB marked TMB538A			
Panasonic	TX15LT2	LH1 chassis (LCD TV)	2001						
Panasonic	TX15LV1	LH5 chassis (LCD TV + DVD player)	2002						
Panasonic	TX15M	Z4							
Panasonic	TX15M1R	ALPHA1							
Panasonic	TX15M1T	Z4							
Panasonic	TX15M2T	Z4				TNQ8E0448			
Panasonic	TX1631	U4W							
Panasonic	TX1632	U4							
Panasonic	TX1641	U4							
Panasonic	TX1642	U4							
Panasonic	TX1752	U5							
Panasonic	TX1786	Z3T							
Panasonic	TX2	ALPHA1							
Panasonic	TX2024	U3W							
Panasonic	TX2034	U4							
Panasonic	TX2112	U5N							
Panasonic	TX211AD2	EURO2							
Panasonic	TX2162	U5							
Panasonic	TX2172	ALPHA1							
Panasonic	TX2175	Z1							
Panasonic	TX2178	ALPHA1							
Panasonic	TX2195	Z3T							
Panasonic	TX21AD2	ALPHA1							
Panasonic	TX21AD2DP	EURO2L							

Panasonic	TX21AP1	Z8T		remote EUR511300					
Panasonic	TX21AT1	Z8T	2002	remote EUR511300					
Panasonic	TX21AV1	Z082PF (Daewoo CP082, K30 Deck)		remote EUR51941					
Panasonic	TX21CK1	Z8							
Panasonic	TX21GV1	Z421V (Daewoo CP420, K-Mecha Deck)							
Panasonic	TX21JT1	Z7							
Panasonic	TX21JT2	ZM3L (Orion chassis)	2003, remote EUR511300	PCB marked TMB553A, Micro	LOPTr Q401 2SD2499	PSU Q511 2SK2647			
Panasonic	TX21K1T	Z7							
Panasonic	TX21K2T	Z7							
Panasonic	TX21M1T	Z4							
Panasonic	TX21M2T	Z4		remote TNQ8E0448					
Panasonic	TX21MD1	EURO2L							
Panasonic	TX21MD3	EURO2M							
Panasonic	TX21MD4	EURO4		remote EUR511200					
Panasonic	TX21MK1	EURO4		remote EUR511200					
Panasonic	TX21S1T	Z5		remote TNQ8E0461					
Panasonic	TX21S3	Z7							
Panasonic	TX21S4TL	Z7		remote EUR511300					
Panasonic	TX21T	ALPHA2							
Panasonic	TX21T1	ALPHA2							
Panasonic	TX21V1	ALPHA2							
Panasonic	TX21V2	ALPHA4							
Panasonic	TX21V2BC	ALPHA1							
Panasonic	TX2200	U4							
Panasonic	TX2230	U4							
Panasonic	TX2231	U4							
Panasonic	TX2234	U4W							
Panasonic	TX2244	U4W							
Panasonic	TX2284	U3W							
Panasonic	TX2450	U5W							
Panasonic	TX2464	U5							
Panasonic	TX2470	ALPHA1W							
Panasonic	TX2472	ALPHA1X							
Panasonic	TX2480	ALPHA1							
Panasonic	TX2482	ALPHA1							
Panasonic	TX2488	ALPHA1							
Panasonic	TX2492	ALPHA1W							
Panasonic	TX24A1	ALPHA2							
Panasonic	TX24A1C	ALPHA1							
Panasonic	TX24DX1	EURO4		remote EUR511210					
Panasonic	TX24PS1	EURO10							
Panasonic	TX24T1	ALPHA2W							
Panasonic	TX24W1	ALPHA2W							
Panasonic	TX251XDP	ALPHA1							
Panasonic	TX25A2	ALPHA3							
Panasonic	TX25A2X	ALPHA3							
Panasonic	TX25A3	EURO1							
Panasonic	TX25AD1	EURO2S							
Panasonic	TX25AD2	EURO2S							
Panasonic	TX25AD70F/P	EURO3H							
Panasonic	TX25BM1	ALPHA2							
Panasonic	TX25CK1	Z8							
Panasonic	TX25G1	ALPHA2							
Panasonic	TX25LD4DP	EURO4		remote EUR511200					
Panasonic	TX25LDM4F	EURO4	Multistandard PAL/SECAM B/G,D/K,I	remote EUR511200					
Panasonic	TX25MD1	EURO2L							
Panasonic	TX25MD3	EURO2M							
Panasonic	TX25MD4	EURO4		remote EUR511200					
Panasonic	TX25MK1	EURO4	1999						
Panasonic	TX25T2	ALPHA2							
Panasonic	TX25W2	ALPHA3							
Panasonic	TX25W2A	ALPHA3							
Panasonic	TX25W3	EURO1							
Panasonic	TX25X1	ALPHA4							
Panasonic	TX25X1DP	ALPHA4							
Panasonic	TX25XD1E	EURO2S							
Panasonic	TX25XD4	EURO4		remote EUR511200					
Panasonic	TX25XD90	EURO5		remote EUR511211					
Panasonic	TX25XDP3	EURO2M							
Panasonic	TX2636	U4W							
Panasonic	TX2646	U4W							
Panasonic	TX2656	U5W							
Panasonic	TX26LXD1	LH18 Chassis (LCD TV)	2004	remote EUR7635010					
Panasonic	TX28A1	ALPHA2W							
Panasonic	TX28A1C	ALPHA1							
Panasonic	TX28A2	ALPHA3							
Panasonic	TX28A2X	ALPHA3							
Panasonic	TX28A3	EURO1							
Panasonic	TX28CK1	Z8							
Panasonic	TX28DK1	EURO4		remote EUR511210					
Panasonic	TX28DK2	EURO4		remote EUR511210					
Panasonic	TX28DT2	EURO4D	Pal-I	remote EUR511230					
Panasonic	TX28DT2/E	EURO4D	Pal-I	remote EUR511230					
Panasonic	TX28DT30	EURO8DH (built-in digital receiver)							
Panasonic	TX28DT4	EURO10D (built-in digital receiver)	2003 around £510	remote EUR511243					
Panasonic	TX28DTS3	EURO4DS (built-in digital receiver)							
Panasonic	TX28EX2000	EURO4	Multistandard PAL/SECAM B/G,D/K,I	remote EUR511200					
Panasonic	TX28G1	ALPHA2							
Panasonic	TX28L D1	EURO2							
Panasonic	TX28L D4DP	EURO4		remote EUR511200					
Panasonic	TX28LDM4F	EURO4	Multistandard PAL/SECAM B/G,D/K,I	remote EUR511200					
Panasonic	TX28MD3	EURO2M							
Panasonic	TX28MD4	EURO4		remote EUR511200					
Panasonic	TX28MK1	EURO4		remote EUR511200					
Panasonic	TX28PB50	EURO7		remote EUR511224					
Panasonic	TX28PG40	EURO7		remote EUR511224					
Panasonic	TX28PG45	EURO7		remote EUR511212A					
Panasonic	TX28PK1	EURO4		remote EUR511210					
Panasonic	TX28PK10	EURO5L		remote EUR511211					
Panasonic	TX28PK2	EURO4		remote EUR511210					
Panasonic	TX28PK25	EURO4H 100Hz		remote EUR511211					
Panasonic	TX28PK3L	EURO4		remote EUR511210					
Panasonic	TX28PL1	EURO4		remote EUR511210					
Panasonic	TX28PL10	EURO4H 100Hz	around £660	remote EUR511211					
Panasonic	TX28PL4	EURO4		remote EUR511210					
Panasonic	TX28PS1	EURO10	2003 around £450	remote EUR511320					
Panasonic	TX28PS12		2003 around £510						
Panasonic	TX28PS5	EURO10							
Panasonic	TX28W1	ALPHA2W							
Panasonic	TX28W2	ALPHA3							
Panasonic	TX28W3	EURO1							
Panasonic	TX28X1	ALPHA4							
Panasonic	TX28X1DP	ALPHA4							
Panasonic	TX28XD1E	EURO2S							
Panasonic	TX28XD3	EURO2M							
Panasonic	TX28XD4	EURO4		remote EUR511200					
Panasonic	TX28XD90	EURO5		remote EUR511211					
Panasonic	TX28XDP3	EURO2M							
Panasonic	TX29A3	EURO1							
Panasonic	TX29AD1	EURO2S							
Panasonic	TX29AD10C(F)	E2100	nonUK						
Panasonic	TX29AD1DP	EURO2S							
Panasonic	TX29AD2	EURO2S							
Panasonic	TX29AD20C	E2100	nonUK						
Panasonic	TX29AD30C	E2100	nonUK						
Panasonic	TX29AD70	EURO3H							
Panasonic	TX29AK1	EURO4		remote EUR511200					
Panasonic	TX29AK10P	EURO5		remote EUR511211					
Panasonic	TX32DH40	EURO8DH (built-in digital receiver)							
Panasonic	TX32DK1	EURO4		remote EUR511210					
Panasonic	TX32DK2	EURO4		remote EUR511210					
Panasonic	TX32DT2	EURO4D		remote EUR511230					
Panasonic	TX32DT30	EURO8DH (built-in digital receiver)							
Panasonic	TX32DT4	EURO10D (built-in digital receiver)		remote EUR511243					
Panasonic	TX32DTS3	EURO4DS (built-in digital receiver)							
Panasonic	TX32LXD1	LH18 Chassis (LCD TV)	2004	remote EUR7635010					
Panasonic	TX32PB50(N)	EURO7		remote EUR511224					
Panasonic	TX32PD30	GP1 , 100Hz							
Panasonic	TX32PF10	EURO5		remote EUR511220					

Panasonic	TX32PG30	EURO7		remote EUR511212A					
Panasonic	TX32PG50	EURO7		remote EUR511224					
Panasonic	TX32PH40	EURO7P	2002	remote EUR511224					
Panasonic	TX32PK1	EURO4		remote EUR511210					
Panasonic	TX32PK2	EURO4		remote EUR511210					
Panasonic	TX32PK20	EURO5		remote EUR511211					
Panasonic	TX32PK25	EURO4H 100Hz		remote EUR511211					
Panasonic	TX32PK3	EURO4		remote EUR511210					
Panasonic	TX32PL1	EURO4		remote EUR511210					
Panasonic	TX32PL10	EURO4H 100Hz	around £900	remote EUR511211					
Panasonic	TX32PL4	EURO4		remote EUR511210					
Panasonic	TX32PS1	EURO10	2003	remote EUR511320					
Panasonic	TX32PS5	EURO10							
Panasonic	TX3300	U4							
Panasonic	TX3370GR	ALPHA1							
Panasonic	TX33A1	ALPHA2W							
Panasonic	TX33A1G	ALPHA2							
Panasonic	TX33A2	ALPHA3							
Panasonic	TX33AK10	EURO5		remote EUR511211					
Panasonic	TX36DT35	EURO8	2002	remote EUR511241					
Panasonic	TX36PB50(N)	EURO7		remote EUR511224					
Panasonic	TX36PD30	GP1 , 100Hz							
Panasonic	TX36PF10	EURO5		remote EUR511220					
Panasonic	TX36PG50	EURO7		remote EUR511224					
Panasonic	TX36PL30	EURO7		remote EUR511212A					
Panasonic	TX37A2	ALPHA3							
Panasonic	TX37A2G	ALPHA3							
Panasonic	TX47PT1 (projector)	EURO5VP		remote EUR511220					
Panasonic	TX47PT10 (projector)	EURO7VP							
Panasonic	TX5500	U5							
Panasonic	TXC21	U4							
Panasonic	TXC22	U5							
Panasonic	TXC71	ALPHA1W							
Panasonic	TXC74	ALPHA1W							
Panasonic	TXC78	ALPHA1W							
Panasonic	TXC84	ALPHA2							
Panasonic	TXC88	ALPHA2							
Panasonic	TXG10	AC1 Multisystem							
Panasonic	TXW28D1F	E2100	nonUK						
Panasonic	TXW28D2	EURO3HW							
Panasonic	TXW28D5F/P	EURO5							
Panasonic	TXW28R3	EURO3W							
Panasonic	TXW28R4(DP)	EURO4		remote EUR511210					
Panasonic	TXW32D2	EURO3HW							
Panasonic	TXW32D3DP/L	EURO3HW							
Panasonic	TXW32D4DP	EURO5		remote EUR511211					
Panasonic	TXW32D5F/P	EURO5							
Panasonic	TXW32R4(DP)	EURO4		remote EUR511210					
Panasonic	TXW36D3DP/L	EURO3HWS							
Panasonic	TYSU1	ALPHA1							
Panasonic	TYSU2	ALPHA1							
Panasonic	TYSU3	ALPHA1							
Perdio	CT2005	Indiana 100	Bush						
Perdio	P1408	Indiana 100	Bush						
Perdio	P1480	Indiana 100	Bush						
Perdio	P2004	Indiana 100	Bush						
Perdio	P2005	Indiana 100	Bush						
Perdio	P2101	Indiana 100	Bush						
Perdio	P2102	Indiana 100	Bush						
Phase	PH20567	Murphy CTV3500							
Philips	797	K12							
Philips	912	TX							
Philips	928	KT3							
Philips	934	KT3							
Philips	10CX1120	Pye 25KX1201							
Philips	1201	K30							
Philips	1205	K30							
Philips	1234	K30							
Philips	1250	K30							
Philips	12B611	T8	1976						
Philips	12B710	TX	1982						
Philips	12B711	TX	1982						
Philips	12B912	TX	1982						
Philips	12B915	TX	1982						
Philips	12TX1501	TX1	1982						
Philips	12TX2301	TX2	1982						
Philips	12TX2460	TX2	1982						
Philips	12TX2501	TX2	1982						
Philips	12TX2502	TX2	1982						
Philips	12TX3201	TX3	1984						
Philips	12TX3303	TX3	1984						
Philips	12TX3501	TX3	1984						
Philips	12TX3502	TX3	1984						
Philips	14B614	T8	1976						
Philips	14C825	KT2	1977						
Philips	14C925	KT3	1979						
Philips	14CE1200	CP90	1988						
Philips	14CE1201	CP90	1987						
Philips	14CE1210	CP90							
Philips	14CE1500	CP90	1988						
Philips	14CF1014	CF1	1985						
Philips	14CF1114	CF1	1985						
Philips	14CN2201	NC3-CR	1988						
Philips	14CN3001	NC3	1987						
Philips	14CT2006	CTX-S	1982						
Philips	14CT2007	CTX-E	1984						
Philips	14CT2201	CTX-E							
Philips	14CT2206	CTX-E	1983						
Philips	14CT3005	KT3	1980						
Philips	14CT3205	KT3	1980						
Philips	14CT3605	KT3	1984						
Philips	14CT3606	KT3							
Philips	14CT3607	KT3							
Philips	14CT4206	KT4 SYSTEM 4	1983						
Philips	14GR1021	GR1-AX	1989						
Philips	14GR1212	GR1-AX							
Philips	14GR1220	GR1-AX	1990						
Philips	14GR1221	GR1-AX	1990						
Philips	14GR1227/05B	GR1-AX	1992						
Philips	14GR2520	G90AE	1989						
Philips	14PT1121A	GR1-AX	1993						
Philips	14PT11332/05	L6.1AA	1996						
Philips	14PT11342	L6.1	1996-2000						
Philips	14PT11356/05	L01.2E AA	2002						
Philips	14PT1135A	ANUBIS A	1994						
Philips	14PT1135B	AA5	1995						
Philips	14PT11532	L6.1	1996-1998						
Philips	14PT11553/05	L6.1	1998						
Philips	14PT11555/05	L01.2E AA	2002, 2004 £80	RCLE011					
Philips	14PT1155A	ANUBIS A	1993						
Philips	14PT11559	AA5	1995						
Philips	14PT1156A	ANUBIS A	1994						
Philips	14PT1156B	AA5-AB	1994-1996						
Philips	14PT2002/05	L01.2E	2002						
Philips	14PT2665/05	L9.2E AA	2000-2001						
Philips	14PT2666/05	L01.2E	2001	RCLE014					
Philips	14PT3685/05	L9.3E	2000-2001						
Philips	14PT6107/05D	TDVD1.1E	2002						
Philips	14PV110	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV111/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14PV112/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14PV120/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV125/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV135/07	Funai MK12 deck	2004	similar 14PV135 14PV235 14PV385					
Philips	14PV182/05	MONO98 chassis							
Philips	14PV202	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV203/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14PV210	Delta 99, Turbo drive deck	1999						
Philips	14PV220	Epsilon 2001 , Turbo drive deck	2001						

Philips	14PV225/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV227	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV235/07	Funai MK12 deck	2004	similar 14PV135 14PV235 14PV385					
Philips	14PV284/05(S)	MONO98 chassis							
Philips	14PV320	Delta 99, Turbo drive deck	1999						
Philips	14PV325	Delta 99, Turbo drive deck	1999						
Philips	14PV327	Delta 99, Turbo drive deck	1999						
Philips	14PV340	Delta 99, Turbo drive deck	1999						
Philips	14PV345	Delta 99, Turbo drive deck	1999						
Philips	14PV350	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV354	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV358	Epsilon 2001 , Turbo drive deck	2001						
Philips	14PV360/07	Funai MK11 deck		similar 14PV360 14PV365					
Philips	14PV365/07	Funai MK11 deck		similar 14PV360 14PV365					
Philips	14PV374/07	Funai MK12 deck	2003						
Philips	14PV375/07	Funai MK12 deck	2003						
Philips	14PV385/07	Funai MK12 deck	2004	similar 14PV135 14PV235 14PV385					
Philips	14PV415/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14PV422/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV425/07	Funai MK12 deck	2003	similar 14PV120 14PV125 14PV225 14PV422 14PV425					
Philips	14PV460/07	Funai MK11 deck	2002	similar 14PV111 14PV112 14PV203 14PV415 14PV460					
Philips	14TVCR24	COMBI							
Philips	14TX1504	TX-14	1982						
Philips	14TX2504	TX2	1982						
Philips	14TX3504	TX3	1984						
Philips	14TX3540	TX3							
Philips	15AA3332	ANUBIS A	1991						
Philips	15CE1010	CP90	1987						
Philips	15CE1210	CP90	1987						
Philips	15CE1510	CP90	1987						
Philips	15CE1518	CP90	1988						
Philips	15CT2309	CTX-E	1985						
Philips	15GR2330	G90AE	1988						
Philips	15GR2331	G90AE	1991						
Philips	15GR2530	G90AE	1989						
Philips	16C927	KT3	1979						
Philips	16C928	KT3	1979						
Philips	16CT2016	CTX-E	1982						
Philips	16CT2216	CTX-E	1983						
Philips	16CT3015	KT3	1980						
Philips	16CT3215	KT3	1980						
Philips	16CT3715	KT3	1981						
Philips	16CT4418	KT4 SYSTEM 4	1983						
Philips	16CT4616	KT4 SYSTEM 4	1983						
Philips	16CT4718	KT4 SYSTEM 4	1983						
Philips	17B920/15X	E2	1983						
Philips	17CE1230	CP90	1987						
Philips	17CE1530	CP90	1987						
Philips	17CE1538	CP90	1988						
Philips	17CE1630	CP90	1987						
Philips	17CT2319	CTX-E	1985						
Philips	17CT2619	CTX-E	1985						
Philips	17GR2340	G90AE	1989						
Philips	17GR2341	G90AE	1991						
Philips	17GR2540	G90AE	1989						
Philips	17HT1340	ANUBIS B	1993						
Philips	17HT1640	ANUBIS B	1993						
Philips	17HT1549	ANUBIS B	1993						
Philips	17HT3252	A7H.1	1998						
Philips	17HT3302	A7H.1	1998						
Philips	17PT1563/05	L7.2E AA	1998						
Philips	17PT1565	L9.2E	2000						
Philips	17PT1568	AA5-AB	1995						
Philips	17PT166A	ANUBIS A AC	1994						
Philips	20C933	KT3	1979						
Philips	20C934	KT3	1980						
Philips	20CT2026	CTX-E	1983						
Philips	20CT2035	CTX-E	1985						
Philips	20CT2036	CTX-E	1982						
Philips	20CT2235	CTX-E	1986						
Philips	20CT2236	CTX-E	1984						
Philips	20CT2635	CTX-E	1986						
Philips	20CT2636	CTX-E	1985						
Philips	20CT3027	KT3	1984						
Philips	20CT3227	KT3	1981						
Philips	20CT3723	KT3	1984						
Philips	20CT3726	KT3	1982						
Philips	20CT4428	KT4 SYSTEM 4	1983						
Philips	20CT4626	KT4 SYSTEM 4	1983						
Philips	20CT4636	KT4 SYSTEM 4	1984						
Philips	20CT4728	KT4 SYSTEM 4	1983						
Philips	20PT1552	L6.1	1996						
Philips	20PV184/05	MONO98 chassis							
Philips	20PV220	Delta 99, Turbo drive deck	1999						
Philips	20PV230	Epsilon 2001 , Turbo drive deck	2001						
Philips	21AA3350	ANUBIS A	1991						
Philips	21AA3356	ANUBIS A	1992/1993						
Philips	21AA3557	ANUBIS A	1992/1993						
Philips	21A93556	ANUBIS B	1992						
Philips	21CE1051	CP90	1987						
Philips	21CE1059	CP90	1987						
Philips	21CE1250	CP90	1987						
Philips	21CE1251	CP90	1987						
Philips	21CE1259	CP90	1987						
Philips	21CE1550	CP90	1987						
Philips	21CE1551	CP90	1987						
Philips	21CE1557	CP90	1988						
Philips	21CE1558	CP90	1988						
Philips	21CE1559	CP90	1987						
Philips	21CE2340	2A	1986						
Philips	21CE2640	2A	1986						
Philips	21CE4550	2B	1986						
Philips	21CE4559	2B	1987						
Philips	21CE5554	2B	1988						
Philips	21CE7550	3A	1987						
Philips	21CE7650	3A	1987						
Philips	21CT4829	KT4 SYSTEM 4	1985						
Philips	21GR1251	GR1-AX	1990						
Philips	21GR2150	G90AE	1989						
Philips	21GR2350	G90AE	1989						
Philips	21GR2550	G90AE	1989						
Philips	21GR2552	G90AE	1989						
Philips	21GR2554	G90AE	1991						
Philips	21GR2752	G90B	1989						
Philips	21GR9752	G90B	1991						
Philips	21HT1350	ANUBIS B	1995						
Philips	21HT1550	ANUBIS B	1993						
Philips	21HT1559	ANUBIS B	1993						
Philips	21HT5403/05Z	L9H.2E AA	2000						
Philips	21PT1385	AA5-AB	1995						
Philips	21PT1532	L6.1AA	1996						
Philips	21PT1653/05	L6.2 AA	1998						
Philips	21PT165A	ANUBIS A AC	1993-1994						
Philips	21PT165B	AA5-AB	1996						
Philips	21PT1663/05	L7.2E AA	1998						
Philips	21PT1664	L9.2E	2000						
Philips	21PT166B	AA5-AB	1995-1997						
Philips	21PT2665/05	L9.2E AA	2000						
Philips	21PT4416/05	L01.2E	2002						
Philips	21PT4424/05	L7.2E AA	1998						
Philips	21PT442B/05	MD1.1E	1995-1996						
Philips	21PT442B/05B	MD1.2E	1997						
Philips	21PT4456	L9.2	2000						
Philips	21PT4457/05	L01.2E	2001						
Philips	21PT4475	L9.2E	2000-2001						
Philips	21PT4494	L6.3	1998						
Philips	21PT522A/05	GR2.2	1993						
Philips	21PT522B/05/(25)	GR2.4	1994-1995						
Philips	21PT5321/05	GR2.4	1995						

Philips	21PT5322/05	MD1.2E	1996						
Philips	21PT5324/05R	A8.0E	1998						
Philips	21PT532A/05	GR2.2	1993						
Philips	21PT532B/05/(25)	GR2.4	1994-1995						
Philips	21PT5407/05	L01.1E	2001, Multistandard B/G, D/K, I						
Philips	21PT5457/05	L01.2E AA	2002, Multistandard B/G, D/K, I						
Philips	21PT5505/05	L9.1E AB	2000-2001						
Philips	21PT5507/05	L01.1E AB	2002						
Philips	21PT5606/05	L01.1E AB	2002						
Philips	21PT6807/05	L01.1E AB	2002						
Philips	21PV210	Delta 99, Turbo drive deck	1999						
Philips	21PV288/05	MONO98 chassis							
Philips	21PV320	Delta 99, Turbo drive deck	1999						
Philips	21PV340	Epsilon 2001, Turbo drive deck	2001						
Philips	21PV375/07	Funai MK12 deck	2003						
Philips	21PV385/07	Funai MK12 deck	2004						
Philips	21PV548	Epsilon 2001, Turbo drive deck	2001						
Philips	21PV620/05	STEREO98 chassis							
Philips	21PV688/05	STEREO98 chassis							
Philips	21PV715/07	Delta 2000 chassis	2000						
Philips	21PV908 (combi)	Delta 2000 chassis	2000						
Philips	21ST11730	GR2.1	1991						
Philips	21ST2730	GR2.2	1992						
Philips	21ST2731	GR2.2	1992						
Philips	2206	CTX							
Philips	2216	CTX							
Philips	2226	CTX							
Philips	22AV3500	CP90							
Philips	22CE2060	2A							
Philips	22CE2061	2A	1986						
Philips	22CE2065	2A	1986						
Philips	22CE2261	2A	1986						
Philips	22CE2267	2A	1986						
Philips	22CE2561	2A	1986						
Philips	22CE2565	2A	1986						
Philips	22CE2567	2A	1986						
Philips	22CS1002	K30	1980						
Philips	22CS1201	K30	1980						
Philips	22CS1205	K30							
Philips	22CS1234	K30	1982						
Philips	22CS3040	K35	1983						
Philips	22CS3245	K35	1982						
Philips	22CS3745	K35	1983						
Philips	22CS3761	K35	1982						
Philips	22CS3850	K35	1982						
Philips	22CS3880	K35							
Philips	22CS4360	K40 SYSTEM 4	1983						
Philips	22CS4860	K40 SYSTEM 4	1984						
Philips	22CS4861	K40 SYSTEM 4	1985						
Philips	22CS5240	K40 SYSTEM 4	1984						
Philips	22CS5350	K40 SYSTEM 4	1984						
Philips	22CS5735	K40 SYSTEM 4	1985						
Philips	22CS5740	K40 SYSTEM 4	1984						
Philips	22CS5744	K40 SYSTEM 4	1984						
Philips	22CS5748	K40 SYSTEM 4	1985						
Philips	22CS5750	K40 SYSTEM 4	1984						
Philips	22CS5751	K40 SYSTEM 4	1985						
Philips	22CT2226	CTX-E							
Philips	23BC2001	TC2	1982						
Philips	24CE2370	2A	1986						
Philips	24CE2670	2A	1986						
Philips	24CE3270	CP110	1987						
Philips	24CE3271	CP110	1987						
Philips	24CE3570	CP110	1987						
Philips	24CE3578	CP110	1988						
Philips	24CE3588	CP110	1998						
Philips	24CE4570	2B	1986						
Philips	24CE4579	2B	1987						
Philips	24CE7570	3A	1987						
Philips	24PW6005	A10E	2000-2001						
Philips	24PW6006/05	L01.1E	2001-2002 around £285						
Philips	24PW6322	MD1.2E	1997						
Philips	24PW6324/05R	A8.0E	1999						
Philips	24PW6407	L01.1E	2002-2003 around £375						
Philips	25CE5574	2B	1988						
Philips	25CE6270	CP110	1989						
Philips	25CE6570	CP110	1989						
Philips	25GR5560	G110	1989						
Philips	25GR5762	G110	1990						
Philips	25GR5763	G110	1990						
Philips	25GR5764	G110	1990						
Philips	25GR6771	G111-S	1990						
Philips	25GR9762	G110	1989						
Philips	25GR9763	G110	1990						
Philips	25GR9768	G110	1990						
Philips	25HT5403/05Z	L9H.2E AA	2001						
Philips	25ML8300	FL1.7	1992						
Philips	25ML8500	FL1.6	1992						
Philips	25MN1550/05	GR2.1	1991						
Philips	25MN1550/25	GR2.2	1992						
Philips	25PT4101/05	AA5-AB	1995-1996						
Philips	25PT4103/05	L6.2AA	1997-1998						
Philips	25PT410A	GR2.1	1993						
Philips	25PT4423	L6.2	1997-1998						
Philips	25PT4456/25	L9.1E	2000						
Philips	25PT4457/05	L01.1E AA	2001-2002	RCLE014					
Philips	25PT4475	L9.1E	2000						
Philips	25PT4494/05	L6.3	1998						
Philips	25PT4501	MD1.1E	1995-1996						
Philips	25PT4521	MD1.1E	1995						
Philips	25PT4523	MD1.2E	1996-1997						
Philips	25PT482A/05	GR2.2 AA	1993-1994						
Philips	25PT5324/05R	A8.0E	1998						
Philips	25PT532A/05	GR2.2	1993						
Philips	25PT532B/05	GR2.4	1994						
Philips	25PT6322/05	MD1.2E	1997						
Philips	25PT632A/05	GR2.4	1995						
Philips	25PV720	Delta 99, Turbo drive deck	1999						
Philips	25ST1724	GR2.1	1991						
Philips	25ST1760/25	GR2.1	1991						
Philips	25ST1761/25	GR2.1	1991						
Philips	25ST2760	GR2.2	1992						
Philips	25ST2761	GR2.2	1992						
Philips	26C797	K12	1979						
Philips	26CE2080	2A	1985						
Philips	26CE2081	2A	1986						
Philips	26CE2281	2A	1986						
Philips	26CE2581	2A	1986						
Philips	26CP2601	K12	1980						
Philips	26CS1009	K30	1980						
Philips	26CS1205	K30	1981						
Philips	26CS1250	K30	1982						
Philips	26CS3070	K35	1983						
Philips	26CS3275	K35	1982						
Philips	26CS3775	K35	1983						
Philips	26CS3880	K35	1982						
Philips	26CS3890	K35	1983						
Philips	26CS3895	K35	1983						
Philips	26CS4880	K40 SYSTEM 4	1983						
Philips	26CS4895	K40 SYSTEM 4	1984						
Philips	26CS5770	K40 SYSTEM 4	1984						
Philips	26CS5774	K40 SYSTEM 4	1984						
Philips	26CS5793	K40 SYSTEM 4	1985						
Philips	27CE2390	2A	1986						
Philips	27CE2690	2A	1986						
Philips	27CE3290	CP110	1987						
Philips	27CE3590	CP110	1987						
Philips	27CE3598	CP110	1988						
Philips	27CE4695	2B	1987						

[illegible]

Philips	37KV1240	GR1-AX	1990							
Philips	37KV1242	GR1-AX	1990							
Philips	37KV2225	G90B	1990							
Philips	37TR210	Epsilon 2001 , Turbo drive deck	2001							
Philips	37TR215	Delta 99, Turbo drive deck	1999							
Philips	37TVB50	Delta 99, Turbo drive deck	1999							
Philips	37TVB60	Epsilon 2001 , Turbo drive deck	2001							
Philips	3850	K35								
Philips	3880	K35								
Philips	3890	K35								
Philips	3895	K35								
Philips	38KV2325	G90AE	1989							
Philips	41GR8840	G110-PTV	1989							
Philips	41GR8841	G110-PTV	1989, PROJECTION							
Philips	4206	KT4								
Philips	42CT2142	CTX-E								
Philips	4360	K40								
Philips	43KV2425	G90AE	1989							
Philips	4418	KT4								
Philips	4526	KT4								
Philips	4616	KT4								
Philips	46ML0985	FL1.PTV	1992							
Philips	46PP912A/05	FL1.PTV	1993							
Philips	4718	KT4								
Philips	4728	KT4								
Philips	4860	K40								
Philips	4880	K40								
Philips	51BE2080	E2	1983							
Philips	51BL7205	L7	1982							
Philips	51BL7215	L7	1982							
Philips	51TR225	Delta 99, Turbo drive deck	1999							
Philips	51TR300	Epsilon 2001 , Turbo drive deck	2001							
Philips	51TVB60	Delta 99, Turbo drive deck	1999							
Philips	51TVB70	Epsilon 2001 , Turbo drive deck	2001							
Philips	52KE2406	2A	1986							
Philips	52KV1528	GR1-AX	1990							
Philips	52KV2523	G90AE	1989							
Philips	52KV2525	G90AE	1989							
Philips	52KV2529	G90AE	1991							
Philips	52ZY3535	ANUBIS B AA	1992							
Philips	52ZZ3523/25G	ANUBIS A AB	1991							
Philips	56KE2600	2A	1985							
Philips	56KE2610	2A	1986							
Philips	56KS5487	K40 SYSTEM 4	1985							
Philips	59KE3702	CP110	1987							
Philips	60CP2605	K12Z	1983							
Philips	61BL7245	L7	1982							
Philips	63KV9637	G110	1989							
Philips	6620	KT4								
Philips	6720	K40								
Philips	6820	K40								
Philips	68KE7827	3A	1988							
Philips	9TC2000	TC2	1982							
Philips	9TC2100	TC2	1982							
Philips	CTV105	CP90								
Philips	CTV111	CP90								
Philips	CTV114	CP110								
Philips	CTV117	CP110								
Philips	CTV121	CP90								
Philips	D14GY1	NC3-CR								
Philips	D14KP3	CP90								
Philips	D14KP4	NC3-CR								
Philips	D36EP1	CP90								
Philips	D36FY5	CP90								
Philips	D36GP5	CP90								
Philips	D36GP6	G90AE								
Philips	D41FP2	CP90								
Philips	D51EP2	CP90								
Philips	D51EP4	CP90								
Philips	D51EP5	CP90								
Philips	D51FP3	CP90								
Philips	D51FP4	CP90								
Philips	D51FP5	CP90								
Philips	D51FP6	CP90								
Philips	D51GP2	G90AE	1989							
Philips	D51GP5	G90AE	1989							
Philips	D51GY4	G90AE	1989							
Philips	D51HY2	G90AE								
Philips	D51JP4	G90AE								
Philips	D51KP6	CP90								
Philips	D59EP2	2B								
Philips	D59EP3	CP110								
Philips	D59EP6	CP110								
Philips	D59EPC	CP110								
Philips	D59FP2	CP110								
Philips	D59FP3	CP110								
Philips	D59FP4	CP110								
Philips	D59FP5	CP110								
Philips	D59FP6	CP110								
Philips	D59FY5	CP110								
Philips	D59GP4	CP110								
Philips	D59HY5	CP110								
Philips	D59JP4	CP110								
Philips	D59JP6	GR2.1								
Philips	D66EP4	CP110								
Philips	D66EP5	CP110								
Philips	D66EP6	CP110								
Philips	D66FY5	CP110								
Philips	G20657	G11								
Philips	G20C560	G8								
Philips	G20C655	G11								
Philips	G22C566	G11								
Philips	G22C567	G11								
Philips	G22C569	G11								
Philips	G22C655	G11								
Philips	G22C657	G11								
Philips	G22C660	G11								
Philips	G22C661	G11								
Philips	G22C662	G11								
Philips	G22C663	G11								
Philips	G22C664	G11								
Philips	G22C665	G11								
Philips	G22C666	G11								
Philips	G22C667	G11								
Philips	G22C700	G11								
Philips	G22C701	G11								
Philips	G22C702	G11								
Philips	G22C703	G11								
Philips	G22C705	G11								
Philips	G22C706	G11								
Philips	G22C707	G11								
Philips	G22C708	G11								
Philips	G26C672	G11								
Philips	G26C674	G11								
Philips	GR2330	G90AE								
Philips	KE3715	CP110								
Philips	KT2040	CTX-E								
Philips	KT2366	CTX-E								
Philips	KT4146	KT4								
Philips	KV2523	G90AE								
Philips	STC2100	TC2								
Philips	TX3303	TX3								
Philips	V6600	KT3	1984							
Philips	V6620	KT4 SYSTEM 4	1983							
Philips	V6621	KT4 SYSTEM 4	1985							
Philips	V6651	KT4 SYSTEM 4	1985							
Philips	V6720	K40 SYSTEM 4	1983							
Philips	V6721	K40 SYSTEM 4	1985							
Philips	V6820	K40 SYSTEM 4	1983							

Philips	V6821	K40 SYSTEM 4	1985						
Philips	V6851	K40 SYSTEM 4	1985						
Philips	V7001	K40							
Philips	VP120	KT4							
Pilot	CTV735	THORN 9500							
Pilot	P735	THORN 9500							
Pilot	P798A	Ferguson TX9							
Pilot	P8039	Ferguson TX9							
Pioneer	AV28	ITT Core							
Pioneer	SD21AVI	Nokia Compact D-E							
Pioneer	SD25AVI	Nokia Compact D-E							
Pioneer	SD28AVI	Nokia Compact D-E							
Pioneer	SV2103	2A/2B?							
Pioneer	SV2503	2B							
Pioneer	SV2803	2B							
Portland	GB14F5	CP420 (Daewoo, K-Mecha Deck)							
Portland	P14F5	CP420 (Daewoo, K-Mecha Deck)							
PowerPoint	CTN BB	Orion CTN BB chassis							
Proline	1405R	PC180 (Seleco-Formenti)							
Proline	1415T 1415R	TX807 (Ferguson)							
Proline	1420R 1420T	Tatung F chassis							
Proline	1460R 1460T	Tatung K chassis							
Proline	1485T	Daewoo chassis							
Proline	1490T	Formenti PC230 chassis (PCB marked FPC230)	2001-2002						
Proline	20N1	Daewoo CP385							
Proline	28N1	F19							
Proline	28N1T	FPC2001 (aka TWIST)							
Proline	360TT	Tatung 170							
Proline	418B	TX807 (Ferguson)							
Proline	5100RC	Tatung 170							
Proline	5900TT	Tatung 180							
Proline	F205T	Formenti PC230 chassis							
Proline	K1405		2003 £70 from Comet, 2004 £60						
Proline	NV2400	Tatung 180							
Proline	NV2700	Tatung 180							
Proline	TVC140		PCB marked KNP991P081-1, LOPTx 6174	Serv mode: STBY, MUTE, 3, 7, 2, STBY.					
Proline	TVD1425	TV+DVD	2004, £130						
Proline	TVD1430	TV+DVD	2004, £120						
Proline	W28D1	CP885	2002, around £250						
Protec	7295	11AK12							
Protec	7296NT	11AK12-9							
Pye	1022	K30							
Pye	1042	K30							
Pye	1062	K30							
Pye	1826	K12							
Pye	2013	TX2							
Pye	2056	K12Z							
Pye	2060	CTX							
Pye	2062	CTX							
Pye	2162	CTX							
Pye	2260	CTX							
Pye	3030	NC3							
Pye	3052	KT3							
Pye	3062	KT3							
Pye	3152	KT3							
Pye	3157	KT3							
Pye	3237	KT3							
Pye	3267	KT3							
Pye	3457	K30							
Pye	3508	K35							
Pye	3757	K30							
Pye	3808	K35							
Pye	3908	K35							
Pye	4146	KT4							
Pye	4184	KT4							
Pye	4187	KT4							
Pye	4266	KT4							
Pye	4284	KT4							
Pye	4287	KT4							
Pye	4309	KT4							
Pye	4508	K40							
Pye	4509	K40							
Pye	4808	K40							
Pye	25CX1201	Phillips 10CX1120							
Pye	27KE1112	CP90	1988						
Pye	27KE1115	CP90	1988						
Pye	31BX2013	TX2	1982						
Pye	31BX2016	TX2	1982						
Pye	31BX2125	TX3							
Pye	31BX3025	TX3	1984						
Pye	31BX3033	TX3	1984						
Pye	31BX3046	TX3							
Pye	31BX3112	TX3	1984						
Pye	31BX3115	TX3	1984						
Pye	35BX1045	TX-14"	1982						
Pye	35BX2045	TX2	1982						
Pye	35BX3045	TX3	1984						
Pye	37K7225	KT3	1979						
Pye	37KE1022	CP90	1987						
Pye	37KE1025	CP90	1989						
Pye	37KF1140	CF1	1986						
Pye	37KN2010	NC3CR	1988						
Pye	37KN2012	NC3CR	1988						
Pye	37KN3030	NC3	1987						
Pye	37KT2040	CTX-E	1984						
Pye	37KT2042	CTX-E	1984						
Pye	37KT2060	KT3							
Pye	37KT2062	KT3							
Pye	37KT3052	KT3	1980						
Pye	37KT3062	KT3	1981						
Pye	37KT7225	KT3							
Pye	37KV1232	GR1-AX	1989						
Pye	37KV1240	GR1-AX	1990						
Pye	37KV1242	GR1-AX	1990						
Pye	37KV2225	G90B	1990						
Pye	38KE1102	CP90	1987						
Pye	38KE1185	CP90	1988						
Pye	38KT2093	CTX-E	1986						
Pye	38KV2325	G90AE	1989						
Pye	41KT3152	KT3							
Pye	42KT227	KT3	1979						
Pye	42KT228	KT3	1979						
Pye	42KT2140	CTX-E	1984						
Pye	42KT2142	CTX-E	1984						
Pye	42KT2160	CTX-E	1982						
Pye	42KT2162	CTX-E	1983						
Pye	42KT3150	KT3	1979						
Pye	42KT3152	KT3	1980						
Pye	42KT3157	KT3	1981						
Pye	42KT4146	KT4 SYSTEM 4	1984						
Pye	42KT4166	KT4 SYSTEM 4	1984						
Pye	42KT4184	KT4 SYSTEM 4	1983						
Pye	42KT4187	KT4 SYSTEM 4	1983						
Pye	42KT5184	KT4 SYSTEM 4	1984						
Pye	42KT7227	KT3							
Pye	42KT7228	KT3							
Pye	43KE1312	CP90	1987						
Pye	43KE1315	CP90	1987						
Pye	43KE1385	CP90	1988						
Pye	43KE2196	CTX-E							
Pye	43KE2425	G90AE							
Pye	43KT2198	CTX-E							
Pye	43KV2429	G90-AE							
Pye	44T7220	E2	1983						
Pye	51BE2080	E2	1983						
Pye	51BL7205	L7	1982						
Pye	51BL7215	L7	1982						
Pye	51K7324	KT3	1984						
Pye	51K7326	KT3	1984						

[illegible]

[illegible]

[illegible]

Samsung	WS28V53N	KS3A(P) Rev.4 50Hz (marked WS28V53NS8)	2002, manual 3KS3A-SEH-0714						
Samsung	WS28V53V	KS3A(P) Rev.5 50Hz (marked WS28V53VS8)	2003, manual AA82-00710A						
Samsung	WS28W5VN	KS3A(P)							
Samsung	WS28W63N	KS3A(P) Rev.2 (marked WS28W63NS8XXEU)	2001, manual 3KS3A-SEH32W6-04						
Samsung	WS28W64N	KS3A(P) Rev.2 (marked WS28W64NS8XXEU)	2001, manual 3KS3A-SEH32W6-04						
Samsung	WS28W6HA	SCT53A							
Samsung	WS28W6VN	KS3A(P) Rev.2 (marked WS28W6VNG8XXEU)	2000, 3KS3A(P)-W2401						
Samsung	WS28W6WG	KS3A(P)							
Samsung	WS28W73NS	KS3A(P) Rev.2	2001						
Samsung	WS28W8V	KS3A(P) Rev.5 (marked WS28W8VNE8)	2003, manual AA82-00710B						
Samsung	WS28Z46VS	K55A Rev.1 (marked WS28Z46VSGXXEU)	2003, manual AA82-01136A						
Samsung	WS28Z46VS	KS3A(P) Rev.5 (marked WS28Z46VSGXXEU)	2002, manual3KS3A_50-SEH-32V5						
Samsung	WS32M64V	KS3A							
Samsung	WS32V54N	KS3A(P) Rev.4 50Hz							
Samsung	WS32W64NS8(VS8)	KS3A(P) Rev.2	2001, manual 3KS3A-SEH32W6-04						
Samsung	WS32W6HA	SCT53A							
Samsung	WS32W6VNG	KS3A(P) Rev.2 (marked WS32W6VNG8XXEC)	2000, manual 3KS3A(P)-W2401						
Samsung	WS32W8VD	KS3A(P)							
Samsung	WS32W8VH	KS3A(P)							
Samsung	WZ28W6VD	KS3A(P)							
Samsung	WZ32W6VN	KS3A(P)							
Sanyo	12T232	12" Mono							
Sanyo	14CT1	Combi, Orion chassis, deck OVD-5A	PCB TM7379B, video VM7127C	Micro OEC6044D					
Sanyo	14M1	EC2-B14							
Sanyo	14MT1	EC3-A							
Sanyo	14MT2	EC3-A							
Sanyo	21DN1	EB4-A	1998 (see C21EF45NB)						
Sanyo	21DN2	EB4-A	1997 (see C21ES57NB)						
Sanyo	21M1	EC3-A21	(see C21EF90B)						
Sanyo	21MT1	EC3-A21	(see C21EF95B)						
Sanyo	21MT2	EC5-A21	1999 (see C21ES35B)						
Sanyo	21MT4	EC8							
Sanyo	21XP1	EB4-A	(see C21ES55NB)						
Sanyo	25BN1	EB4-A	1997 (see C25EG65NB)						
Sanyo	25DN1	EB4-A	1998 (see C25EG65NB)						
Sanyo	25DN2	EB4-A	1997/2000 (see C25EP57NB)						
Sanyo	25MT1	EC3-A	see C25EG95B						
Sanyo	25MT2	EC5-A	see C25EG98B						
Sanyo	25XP1	EB4-A	see C25EP55NB						
Sanyo	25XP2	EB4-A (MKII)							
Sanyo	28DN1	EB4-A	1998 (see C28EH65NB)						
Sanyo	28MT2	EC5-A	1997 (see C28EH75B)						
Sanyo	28XP1	EB4-A	see C28ER55NB						
Sanyo	28XP2	EB4-A (MKII)							
Sanyo	C14EA80B-00	EC2-A	=CB1443						
Sanyo	C14EA85B-00(01)	EC3-A	=CB1456						
Sanyo	C14EA90B-00(01.03.04)	EC2-B14	=14M1						
Sanyo	C14EA95B-00(01)	EC3-A	=14MT1						
Sanyo	C14EA97B-00	EC5-A	1997 (=14MT2)						
Sanyo	C14EA97B-04	EC5-A	1999 (=14MT2)						
Sanyo	C21EF25NB-00	EB2-A	=CB5149						
Sanyo	C21EF35NB-00(01)	EB2-A	=CB5159						
Sanyo	C21EF45NB-01(02.03)	EB4-A21	1998 (=21DN1)						
Sanyo	C21EF45NBA-05	EB4-A21	1997 (=21BN1)						
Sanyo	C21EF50B-00	EC3-A	=CB5153						
Sanyo	C21EF55B-00	EC1-B21	=CB5146						
Sanyo	C21EF57B-00(01)	EC3-A21	=CB5156						
Sanyo	C21EF90B-02	EC3-A21	=21M1						
Sanyo	C21EF95B-01(02)	EC3-A21	=21MT1						
Sanyo	C21ES35B	EC5-A21	1999 (=21MT2)	remote JXTJ					
Sanyo	C21ES55NB-01	EB4-A21	=21XP1						
Sanyo	C21ES57NB-01	EB4-A21	1997 (=21DN2)						
Sanyo	C25EG25NB-00	EB2-A25	=CB5949						
Sanyo	C25EG35NB-00	EB2-A25	=CB5959						
Sanyo	C25EG65NB-00(01)	EB4-A25	1998 (=25DN1)						
Sanyo	C25EG65NBA-03(04.05.06)	EB4-A25	1997 (=25BN1)						
Sanyo	C25EG75NB-00(01)	EB2-A	=CB5967						
Sanyo	C25EG77NB-01	EB4-A	=CB5967MKII						
Sanyo	C25EG85NB	EB2-A							
Sanyo	C25EG90B-00(02)	EC3-A25	=CB5953						
Sanyo	C25EG95B-00(02.03.04)	EC3-A25	=CB5956	remote JXTC					
Sanyo	C25EG98B-01	EC5-A25	1997 (=25MT2)						
Sanyo	C25EG98B-03	EC5-A25	1999 (=25MT2)						
Sanyo	C25EP55NB-01	EB4-A25	=25XP1						
Sanyo	C25EP57NB-00	EB4-A	1997 (=25DN2)						
Sanyo	C25EP57NB-01	EB4-A	2000 (=25DN2)						
Sanyo	C28EH25NB-00	EB3-A	=CB6649						
Sanyo	C28EH27NB-00	EB3-A	=CB6659						
Sanyo	C28EH65NB-00(01)	EB4-A28	1998 (=28DN1)						
Sanyo	C28EH75B-01	EC5-A28	1997 (=28MT2)						
Sanyo	C28EH85NB-02	EB2-A	=CB6657						
Sanyo	C28ER55NB-00(01)	EB4-A28	=28XP1						
Sanyo	C28ER57NB-00	EB4-A28	=28DN2						
Sanyo	C28WK1B-00	A8-B							
Sanyo	C28WN1B-00	WB2-B	1997						
Sanyo	C28WP1B	WB2-A							
Sanyo	C28WP3B	WB2-A							
Sanyo	CB1443	EC2-A	=C14EA80B						
Sanyo	CB1456	EC3-A	=C14EA85B						
Sanyo	CB5146	EC1-B21	=C21EF65B						
Sanyo	CB5149	EB2-A21	=C21EF28NB						
Sanyo	CB5153	EC3-A21	=C21EF50B						
Sanyo	CB5156	EC3-A21	=C21EF57B						
Sanyo	CB5159	EB2-A	=C21EF35NB						
Sanyo	CB5949	EB2-A	=C25EG25NB						
Sanyo	CB5953	EC3-A25	=C25EG90B						
Sanyo	CB5966	EC3-A25	=C25EG95B	remote JXTC					
Sanyo	CB5967	EB2-A	=C25EG75NB						
Sanyo	CB5967MKII	EB4-A	=C25EG77NB						
Sanyo	CB5969	EB2-A	=C25EG35NB						
Sanyo	CB6649	EB3-A	=C28EH25NB						
Sanyo	CB6657	EB2-A	=C28EH85NB						
Sanyo	CB6659	EB3-A	=C28EH27NB						
Sanyo	CBP1748	E2-G21							
Sanyo	CBP2145	E2-B21							
Sanyo	CBP2146	E2-E21							
Sanyo	CBP2147	E2-G21							
Sanyo	CBP2148	E2-G21							
Sanyo	CBP2151	E4-A21							
Sanyo	CBP2152	E4-A21							
Sanyo	CBP2162	E4-A21							
Sanyo	CBP2168	EC1-B							
Sanyo	CBP2180	A5-A21	1991						
Sanyo	CBP2180A	A5-A21							
Sanyo	CBP2551	E4-A25							
Sanyo	CBP2552	E4-A25							
Sanyo	CBP2565	E3-A25							
Sanyo	CBP2566	E3-A25							
Sanyo	CBP2572	ED1-25							
Sanyo	CBP2573	ED1-25							
Sanyo	CBP2576	ED0-25							
Sanyo	CBP2576A	EB1-25							
Sanyo	CBP2580	EB1-25							
Sanyo	CBP2865	E3-A28							
Sanyo	CBP2866	E3-A28							
Sanyo	CBP2872	ED1-28							
Sanyo	CBP2873	ED1-28							
Sanyo	CBP2876	ED0-28	(EB1A ??)						
Sanyo	CBP3000	80P-G14							
Sanyo	CBP3001	A1-A14	BPL 9009						
Sanyo	CBP3011	A1-A14							
Sanyo	CBP3012	A3-A14/A28							
Sanyo	CBP3018	A3-A14							
Sanyo	CBP3024	A3-A14							
Sanyo	CBP7110	80P-D22							
Sanyo	CBT2558	E3							
Sanyo	CBT2576	ED0							
Sanyo	CBT2846	E2							
Sanyo	CBT2876	ED0							

Sanyo	CE14A2-GB	EC7-A	2001							
Sanyo	CE14AT2-GB	EC7-A	2001 (=14AT2)							
Sanyo	CE14AT3-GB	EC7-C	2003, £75	remote 0600123608						
Sanyo	CE14M2B-03	EC5-A	1998	remote JXYA						
Sanyo	CE14M2B-04	EC5-A	1999							
Sanyo	CE14M3B-00	EC5-A	2000							
Sanyo	CE14M4B-00	EC8-A	2001							
Sanyo	CE14M4SLB-00	EC8-A	2001							
Sanyo	CE14MT2SLB-03	EC5-A	1999	remote JXYC						
Sanyo	CE14MT3B-00	EC5-A	2000							
Sanyo	CE14MT4B-00	EC8-A	2001	remote JXMKE						
Sanyo	CE14MT4MB-00	EC8-A	2001							
Sanyo	CE14MT4SLB-00	EC8-A	2001	remote JXMKE						
Sanyo	CE17AT3-GB	EC7-B	2002							
Sanyo	CE21DG1B-04	EB4-A	1998							
Sanyo	CE21DN1	EB4-A								
Sanyo	CE21DN2	EB4-A								
Sanyo	CE21DN4B-01(02)	EB4-A	1999							
Sanyo	CE21DN5B-00(01,03)	EB6-A	2000							
Sanyo	CE21DN5B-04	EB6-A	2001							
Sanyo	CE21DN5B-05	EB6-A	2002							
Sanyo	CE21DN6B-00	EB6-A	2001							
Sanyo	CE21DN6B-01	EB6-D	2001							
Sanyo	CE21DN6MDB-00	EB6-B	2001							
Sanyo	CE21DN7B-00	EB6-D	2002							
Sanyo	CE21DN8B-00	EB7-B	2003							
Sanyo	CE21DN8B-00(01)	EB6-A	2004							
Sanyo	CE21EF5B	EC1-B	=CB5146							
Sanyo	CE21MT3B-00	EC5-A	2000							
Sanyo	CE21MT4AB-00	EC8-A	2001	remote JXMKE						
Sanyo	CE21MT4B-00	EC8-A	2001	remote JXMKE						
Sanyo	CE21MT4HB-00	EC8-A	2001	remote JXMKE						
Sanyo	CE21MT4HB-01	EC8-A	2002							
Sanyo	CE21MT4HRB-00	EC8-A	2002							
Sanyo	CE21MT4MB-00	EC8-A	2001							
Sanyo	CE24FWN5B-00	EB8-A	2004							
Sanyo	CE24FWN5BKB-00	EB8-A	2004							
Sanyo	CE24WN4B-00(01)	EB6-A	2000							
Sanyo	CE24WN5B-00(01)	EB6-A	2001							
Sanyo	CE24WN5B-03(04,05)	EB7-A	2002							
Sanyo	CE24WN6B-00	EB7-A	2003							
Sanyo	CE24WN7B-01	EB8-A	2004							
Sanyo	CE25BM1B-00	EC5-A	2000	remote JXMKE						
Sanyo	CE25BM2B-00	EC5-A	2001	remote JXMKE						
Sanyo	CE25BN2B-00(01)	EB4-A	2000							
Sanyo	CE25DN1B	EB4-A								
Sanyo	CE25DN2B-03	EB4-A								
Sanyo	CE25DN3B-01(03,04,07,12)	EB4-A (MKII)	1998							
Sanyo	CE25DN5B-00(01,02,03,04)	EB6-A	2000							
Sanyo	CE25DN6B-00	EB6-A	2001							
Sanyo	CE25DN6B-01	EB6-D	2001							
Sanyo	CE25DN6MDB-00	EB6-B	2001							
Sanyo	CE25DN7B-00(01)	EB6-D	2002							
Sanyo	CE25DN8B-00	EB7-B	2003							
Sanyo	CE25DN9B-00	EB7-B	2004							
Sanyo	CE25DN9B-01	EB8-A	2004							
Sanyo	CE25MT3B-00	EC5-A	2000							
Sanyo	CE25MT3B-01	EC5-A	2001							
Sanyo	CE25MT3B-02(03)	EC5-A	2002							
Sanyo	CE25MT4B-00	EC8-C	2003	remote JXMTA						
Sanyo	CE25MT4MB-00	EC8-C	2003							
Sanyo	CE25XP2B-00(01)	EB4-A (MKII)	1998/1999							
Sanyo	CE27LD3B-00	UB4-B LCD TV	2004							
Sanyo	CE28BN2B-00(02)	EB4-A	2000							
Sanyo	CE28BN2B-01	EB4-A	2001							
Sanyo	CE28DFN1B-00	WB5-D	2002							
Sanyo	CE28DFN2B-00	EB7-D	2003							
Sanyo	CE28DN1B	EB4-A								
Sanyo	CE28DN4B-01(02)	EB4-A (MKII)	1999							
Sanyo	CE28DN5B-00(01,02,03)	EB6-A	2000							
Sanyo	CE28DN6B-00	EB6-A	2001							
Sanyo	CE28DN6B-01	EB6-D	2001							
Sanyo	CE28DN7B-00(01)	EB6-D	2002							
Sanyo	CE28DN8B-00(01)	EB7-B	2003							
Sanyo	CE28DN9B-00(01)	EB8-A	2004							
Sanyo	CE28DWN1B-00	EB7-D	2004							
Sanyo	CE28FWH4B-00	WB6-A	2003	remote JXMTA						
Sanyo	CE28FWN1B-00	WB5-B	2000							
Sanyo	CE28FWN2B-00	WB5-B	2001							
Sanyo	CE28FWN2B-01	EB6-C								
Sanyo	CE28FWN3B-00(01)	EB6-C	2002							
Sanyo	CE28FWN3B-02(03)	EB7-A	2002							
Sanyo	CE28FWN4B-00(01)	EB7-A	2003							
Sanyo	CE28FWN4BKB-00	EB7-A	2003							
Sanyo	CE28FWN5B-00	EB7-A	2004							
Sanyo	CE28FWN5B-01	EB8-A	2004							
Sanyo	CE28FWN5BKB-00	EB8-A	2004							
Sanyo	CE28FWP2B-00	WB5-B	2001	remote JXMFE						
Sanyo	CE28MT3B-00	EC5-A	2000							
Sanyo	CE28MT4B-00	EC8-C	2003	remote JXMTA						
Sanyo	CE28WN3B-01	EB5-W	1999							
Sanyo	CE28WN4B-00(01)	EB6-A	2000							
Sanyo	CE28WN4B-04	EB6-A	2001							
Sanyo	CE28WN4JB-00	EB7-A	2003							
Sanyo	CE28WN5B-00(01,02,03)	EB6-A	2001-2002							
Sanyo	CE28WN5B-04(05,06)	EB7-A	2002							
Sanyo	CE28WN6B-00(01)	EB7-A	2003							
Sanyo	CE28WN7B-00	EB7-A	2004							
Sanyo	CE28WN7B-01	EB8-A	2004							
Sanyo	CE28WP1B	WB2-A		remote SXMR						
Sanyo	CE28WP2B-00	WB2-A		remote SXMR						
Sanyo	CE28WP3B-01(02)	WB2-A	1999							
Sanyo	CE28WP4B-00(01,02,03,04)	EB6-A	2000							
Sanyo	CE28WP5B-00(01,02,03)	EB6-A	2001-2002							
Sanyo	CE28XP2B-01	EB4-A (MKII)	1998							
Sanyo	CE28XP2B-04	EB4-A	1999							
Sanyo	CE30LD3B-00	UB4-B LCD TV	2004							
Sanyo	CE32DFN1B-00	WB5-D	2002	remote JXMSA						
Sanyo	CE32DFN2B-00	EB7-D	2003							
Sanyo	CE32DFN2BKB-00	EB7-D	2003							
Sanyo	CE32FWH4B-00(01)	WB6-A	2003/2004	remote JXMTA						
Sanyo	CE32FWN2B-00	WB5-B	2001							
Sanyo	CE32FWN2B-01	EB6-A	2002							
Sanyo	CE32FWN3B-00	WB5-B	2002	remote JXMTA						
Sanyo	CE32FWN3B-01	EB6-C	2002							
Sanyo	CE32FWN3B-02(03)	EB7-A	2002							
Sanyo	CE32FWN4B-00(01)	EB7-A	2003							
Sanyo	CE32FWN4BKB-00	EB7-A	2003							
Sanyo	CE32FWN5B-00	EB8-A	2004							
Sanyo	CE32FWN5BKB-00	EB8-A	2004							
Sanyo	CE32FWP2B-00	WB5-B	2001							
Sanyo	CE32WN2B-00	WB2-B	1998	remote SXMR						
Sanyo	CE32WN3B-01	EB5-W	1999							
Sanyo	CE32WN4B-00(01,02,03)	EB6-A	2000							
Sanyo	CE32WN4B-04	EB6-A	2001							
Sanyo	CE32WN4JB-00(01)	EB7-A	2003							
Sanyo	CE32WN5B-00(01)	EB6-A	2001							
Sanyo	CE32WN5B-02(03)	EB6-A	2002							
Sanyo	CE32WN5B-04(05,06)	EB7-A	2002							
Sanyo	CE32WN6B-00(01)	EB7-A	2002							
Sanyo	CE32WN7B-00	EB7-A	2004							
Sanyo	CE32WN7B-01	EB8-A	2004							
Sanyo	CE32WP2B-00	WB2-A		remote SXMR						
Sanyo	CE32WP3B-00(01)	WB2-A	1999/2000							
Sanyo	CE32WP4B-00(01,02,03)	EB6-A	2000							
Sanyo	CE32WP5B-00(01,02,03)	EB6-A	2001-2002							
Sanyo	CMX2100	83S-C21								
Sanyo	CPB2552	E4-A25								

Sanyo	CPB2558	E3							
Sanyo	CTP3101	B5C-31021							
Sanyo	CTP3104	79P-BBZ							
Sanyo	CTP3105	79P							
Sanyo	CTP3106	80P-B14							
Sanyo	CTP3131	80P-B14							
Sanyo	CTP3132	80P-B14							
Sanyo	CTP3134	83P-D14							
Sanyo	CTP3141	83P-C14	Tashiko 14D961						
Sanyo	CTP3144	E2-A14	Tashiko 14D962						
Sanyo	CTP3246	80P							
Sanyo	CTP4100	79P							
Sanyo	CTP4132	80P-G16							
Sanyo	CTP4144	E2-A16							
Sanyo	CTP6112	B5A-61120							
Sanyo	CTP6113	B5A-61130							
Sanyo	CTP6124	80P-A20							
Sanyo	CTP6130	80P-D20							
Sanyo	CTP6131	80P-D20							
Sanyo	CTP6132	80P-D20							
Sanyo	CTP6133	80P-D20							
Sanyo	CTP6134	83P-D20							
Sanyo	CTP6135	83P-D20							
Sanyo	CTP6143	E2-B20							
Sanyo	CTP6144	E2-B20							
Sanyo	CTP6229	80P							
Sanyo	CTP7130	80P-F22							
Sanyo	CTP7131	80P-F22							
Sanyo	CTP7132	80P-F22							
Sanyo	CTP7133	80P-F22							
Sanyo	CTP7135	80P-F22							
Saville	XMP25	Goldstar P58A							
Schneider	70222	TV9.1	Multistandard Pal/SECAM I, B/G, D/K						
Schneider	Scenario 215	11AK19E-3							
Schneider	Scenario 216	11AK19E-3							
Schneider	Scinema 2817LUK	TV9.3 Multi	2000, Philips "Made in Germany" CRT	LOPTx 1372.0031 (FBT40715, HR8409)					
Schneider	STV1401	11AK20M							
Schneider	STV1402T	CTN AA							
Schneider	STV1405T	CTN BB							
Schneider	STV2003T	CTN BB							
Schneider	STV2007T	CTS AA	2001, serv.mode see Pacific PTV5102	LOPTx 40337-54, LOPTr BUT11AF					
Schneider	STV2801T	TV9							
Schneider	STV2802T	TV9.1							
Schneider	STV2804T	Beko 14.2							
Schneider	STV360	11AK20							
Schneider	STV365	11AK20							
Schneider	STV510	11AK19E-3							
Schneider	STV515	11AK19E-3							
Schneider	STV5187.1	11AK19E-3							
Schneider	STV5197.1	11AK19E-3							
Schneider	STV550	11AK19E-3							
Schneider	STV5501 ("STV5501")	11AK19-8A	1999-	AK19 prod.code: 10000360					
Schneider	STV552	11AK19E-3							
Schneider	SVTV1451	Orion chassis	PCB marked VMA230A, PSU VPA150A	Micro OEC0107B, option codes EEPROM 0B4h (0B4->0B4h)					
SEG	CT1402A(UK)	11AK36	2002-2003	prod.code: 10015412					
SEG	CT1402S(UK)	11AK36	2002-2003	prod.code: 10015414					
SEG	CT2102a UK	11AK30	2002-2003	prod.code: 10014287					
SEG	CT2102UK	11AK30	2002-2003	prod.code: 10014288					
SEG	CT2103A	11AK30							
SEG	CT2801UK	11AK19P5	micro SDA5555-A041						
SEG	CT2820a	11AK28-7							
SEG	CT17800	11AK19E-3							
SEG	CT7951GB	11AK19P							
Sentra	GX9200	Nikkai TLG0101							
Sentra	STX600	Nikkai NT20	Susumo FX20						
Sharp	15JF25H	GA1E	2002						
Sharp	15JF26H	GA1E	2002						
Sharp	21HS50H	GA1E	2001						
Sharp	21HT15H	GA1E	2001						
Sharp	21KF80H	GA1E	2003						
Sharp	21LF90H	11AK44 (Vestel)	2004						
Sharp	28HW53H	DA50W	2001						
Sharp	28JF73H	GA20	2002/2003						
Sharp	28JF74H	GA20	2002/2003						
Sharp	28JW73H	GA20 100Hz	2002, around £330, Pal I						
Sharp	28JW74H	GA20	2002/2003						
Sharp	28JW76E	GA200 100Hz	2002/2003, Multisystem Pal/SECAM B/G, D/K	ERRMCG1073BMSA					
Sharp	28KF84H	GA200 100Hz	2003						
Sharp	28LF92H	11AK45 (Vestel)	2004, £300						
Sharp	28LW92H	11AK45 (Vestel)	2004						
Sharp	32HW53H	DA50W							
Sharp	32HW57E	DA100W 100Hz	2001, Multisystem Pal/Secam I, B/G, D/K						
Sharp	32JF73H	GA20	2002/2003						
Sharp	32JF74H	GA20	2002/2003						
Sharp	32JF77H	GA200 100Hz	2003						
Sharp	32JW73H	GA20 100Hz	2002, Pal I						
Sharp	32JW74H	GA20	2002/2003						
Sharp	32JW76E	GA200 100Hz	2002/2003, Multisystem Pal/SECAM B/G, D/K, I						
Sharp	32KF84H	GA200 100Hz	2003						
Sharp	32LF92H	11AK45 (Vestel)	2004						
Sharp	32LW92H	11AK45 (Vestel)	2004						
Sharp	37AM12H	5BSA							
Sharp	37AM23H	5BSA							
Sharp	37AT25H	5BSA							
Sharp	37DM23H	CA1							
Sharp	37DT25H	CA1							
Sharp	37EM33H	CA1							
Sharp	37ES33H	CA1							
Sharp	37ET35H	CA1							
Sharp	37FM11H	CA1							
Sharp	37FT15H	CA1							
Sharp	37GQ20H	Squad	2000						
Sharp	37GT25H	GA1	2000/2001						
Sharp	37GT27H	SQUAD-T	2002						
Sharp	37VT12H	VP3							
Sharp	37VT24H	VP5							
Sharp	37VT26H	VP8	1999						
Sharp	51AT15H	5BSA							
Sharp	51CS03H	CS							
Sharp	51CS05H	CS							
Sharp	51DS02H	CA10							
Sharp	51DS03H	CA10							
Sharp	51DS05H	CA10							
Sharp	51DT25H	CA1							
Sharp	51FS51H	CA10							
Sharp	51GT25H	GA1	2000						
Sharp	56FW53H	DA100 50Hz chassis (aka DA50W)	1999/2000						
Sharp	59CS03H	CS							
Sharp	59CS05H	CS							
Sharp	59CS08H	CS							
Sharp	59DS03H	CA10							
Sharp	59DS05H	CA10							
Sharp	59ES03H	CA10							
Sharp	59ES05H	CA10							
Sharp	59ESD7H	DA100							
Sharp	66AS05H	4BSC							
Sharp	66AS06H	BCTV-A							
Sharp	66CS03H	CS							
Sharp	66CS05H	CS							
Sharp	66CS08H	CS							
Sharp	66DS03H	CA10							
Sharp	66DS05H	CA10							
Sharp	66DW18H	CW100	1999						
Sharp	66ES03H	CA10							
Sharp	66ES05H	CA10							
Sharp	66ESD7H	DA100							
Sharp	66FW53H	DA100 50Hz chassis (aka DA50W)	1999/2000						
Sharp	66FW54H	DA100 50Hz	1999/2000						
Sharp	66GF63H	DA50W	2000						

Sharp	66GF64H	DA50W	2000						
Sharp	66GS62H	GA10 50Hz	2001						
Sharp	70FW53E	DA50W 50Hz	2002						
Sharp	70GS64S	DA100 (nonUK model)							
Sharp	76DW18H	CW100	1999						
Sharp	76EF19H	DA100W , 100Hz ,not Dolby, only NICAM	1999						
Sharp	76EF20H	DA100W , 100Hz, Dolby sound	1999						
Sharp	76FW53H	DA100 50Hz chassis (aka DA50W)	1999/2000						
Sharp	76FW54H	DA100 50Hz	1999/2000						
Sharp	76GF63H	DA50W							
Sharp	76GF64H	DA50W	2000						
Sharp	81GF66E	DA100W							
Sharp	C1407	no chassis type							
Sharp	C1410HW	4PS							
Sharp	C1411H	4PSR1							
Sharp	C1412								
Sharp	C1415	no chassis type							
Sharp	C1420H	7PS							
Sharp	C1421H	7PSR1							
Sharp	C1430	8PS							
Sharp	C1431H	8PSR							
Sharp	C1480	TAP-812							
Sharp	C1491	Rediffusion Mk5							
Sharp	C1493								
Sharp	C1495								
Sharp	C1871								
Sharp	C1891								
Sharp	C2002								
Sharp	C2072								
Sharp	C2092								
Sharp	C2095								
Sharp	C3703H	7PS							
Sharp	C3703HBK	7PS							
Sharp	C3704	8PS							
Sharp	C3705	4PSR1							
Sharp	C3705H	4PS							
Sharp	C3706H	14B							
Sharp	C3709	7PS							
Sharp	C3710H	8PSR							
Sharp	C3720H	14A							
Sharp	C3730H	14B							
Sharp	CV2121H	7PSR1							
Sharp	CV2123H	7PSR1							
Sharp	CV2131	8PSR							
Sharp	CV2133H	8PSR							
Sharp	CV3707	5P-SR1							
Sharp	CV3707H	5PS							
Sharp	CV3709H	7PS							
Sharp	CV3730								
Sharp	CV3745	14B							
Sharp	CV4833	14B							
Sharp	CV5407	5PS							
Sharp	DV1512	Euro DS1							
Sharp	DV1600	no chassis type							
Sharp	DV1620								
Sharp	DV2120	4PSR2							
Sharp	DV2121	4PS							
Sharp	DV3750H	S3B							
Sharp	DV3751H	S3B							
Sharp	DV3760H	4BSA							
Sharp	DV3761H	4BSC							
Sharp	DV3770H	4BSA							
Sharp	DV4205	4PS							
Sharp	DV5101H	EURO-DS							
Sharp	DV5103H	EURO-DS							
Sharp	DV5105H	DECO-4							
Sharp	DV5107H	DECO-5							
Sharp	DV51083H	D3000							
Sharp	DV5131H	S3B							
Sharp	DV5132H	DECO-5							
Sharp	DV5135H	DECO-5							
Sharp	DV5150H	S3B							
Sharp	DV5161H	4BSA							
Sharp	DV5165H	4BSB							
Sharp	DV5180H	4BSB							
Sharp	DV5903H	D3000							
Sharp	DV59083H	D3000							
Sharp	DV5932H	BCTV-A							
Sharp	DV5935H	BCTV-A							
Sharp	DV5937H	BCTV-A							
Sharp	DV5940H	4BSC							
Sharp	DV6603H	D3000							
Sharp	DV66083H	D3000							
Sharp	DV6632H	4BSC							
Sharp	DV6635H	BCTV-A							
Sharp	DV6640H	4BSC							
Sharp	SV2199	8PLS							
Sharp	SV257	NC-7							
Sharp	SV2588	8PLS							
Sharp	SV2588H	8PLS							
Sharp	SV2589	8PLS							
Sharp	SV2589H	8PLS							
Sharp	SV287	NC-7							
Sharp	SV2888	8PLS							
Sharp	SV2888H7	8PLS							
Sharp	SV2889	8PLS							
Sharp	SV3320	8PLP1							
Sharp	VT3700	VP1	TV/VCR						
Sharp	VT3705	VP1	TV/VCR						
Skantic	3781	180							
Skantic	5111	BC							
Skantic	5114	BC							
Skantic	5601	BC							
Skantic	5608	BC							
Skantic	6711	BC							
Skantic	6718	BC							
Skantic	18051919	B2							
Solarvox	142TT								
Solarvox	14R19	CVC1110/12							
Solarvox	14S09	CVC1110/12							
Solarvox	14S19	ITT PICO S/2							
Solarvox	16R19	ITT PICO S/2	CVC1110/12						
Solarvox	20R09	ITT MINI 2 ST2/2							
Solarvox	20S09	ITT CVC1175							
Solarvox	20S19	ITT PICO S/2							
Solarvox	20T09	ITT CVC1200/1							
Solarvox	20T19	ITT MINI2							
Solarvox	22R09	ITT CVC1215							
Solarvox	22S09	ITT CVC1200/1	CVC1210/15						
Solarvox	22S19	ITT COMPACT 80/R							
Solarvox	22T09	ITT CVC1215							
Solarvox	22T09TX	ITT CVC1210							
Solarvox	26R09	ITT CVC1212/17							
Solarvox	26SR09	ITT CVC1212/17							
Solarvox	26ST09	ITT CVC1212/17							
Solarvox	26T09	ITT CVC1212/17							
Solarvox	CML14	Hinari CT4 / 5	Nikkai TLG0909						
Solarvox	CML14RC	Nikkai TLG0101							
Sony	CKV2760		TV/MONITOR						
Sony	FDL390		1991						
Sony	KD28DL10U	FE2D, 50Hz, Dolby Surround	2003, RM933,£430						
Sony	KD28DL11U	FE2D	2004, RM949						
Sony	KD28DX200U	AE6D	2004, RM933						
Sony	KD28DX40U	FE2D	2001, RM933, around £540						
Sony	KD28DX50U	FE2D	2003, RM933						
Sony	KD28DX51U	FE2D	2004, RM949						
Sony	KD32DX100U	AE6D	2001, RM933						
Sony	KD32DX150U	AE6D	2003, RM933						
Sony	KD32DX200U	AE6D	2004, RM933						


Sony	KD32DX40U	FE2D	2002, RM933						
Sony	KD32DX50U	FE2D	2003, RM933						
Sony	KD32DX51U	FE2D	2004, RM949						
Sony	KD32NS100B	AE6D	2001, nonUK, RM935						
Sony	KD32NX100U	AE6D	2001, RM935						
Sony	KD32NX200U	AE6D	2002, RM939						
Sony	KD36NX200U	AE6D	2002, RM939						
Sony	KD51DS1U	RE2D	2000, RM892						
Sony	KDEP42MRX1D	MRX1 (LCD TV)	2004, RMY1013						
Sony	KDEP50MRX1D	MRX1 (LCD TV)	2004, RMY1013						
Sony	KDEP61MRX1D	MRX1 (LCD TV)	2004, RMY1013						
Sony	KDLL32MRX1D	MRX1 (LCD TV)	2004, RMY1013						
Sony	KDLL42MRX1D	MRX1 (LCD TV)	2004, RMY1013						
Sony	KF42SX200U	LE3A (LCD TV, Multistandard B/G, D/K, I, L)	2003, RM905						
Sony	KF42SX300U	LE4A	2004, RM906						
Sony	KF50SX100U	LE3	2000, RM903						
Sony	KF50SX200U	LE3A (LCD TV, Multistandard B/G, D/K, I, L)	2002, RM905						
Sony	KF50SX300U	LE4A	2003, RM906						
Sony	KF60SX300U	LE4A	2003, RM906						
Sony	KL37W1U	LE1	1996, RM838						
Sony	KL37W2U	LE1	1998, RM838						
Sony	KL40WA1U	LE2 (LCD Projector)	1997, RM862						
Sony	KL50W1U	LE1	1996, RM838						
Sony	KL50W2U	LE1	1997, RM838						
Sony	KLTV15SR1	AS1 (LCD TV, Multi-standard)	2002, RM932						
Sony	KLTV15SR2	?? (LCD TV, Multi standard)	2003, RMY1101						
Sony	KLTV17HR1	AS1 (LCD TV, Multi-standard)	2002, RM932						
Sony	KLTV23HR2	?? (LCD TV, Multi standard)	2003, RMY1103						
Sony	KLTV30MR1	?? (LCD TV, Multi standard)	2003, RM972						
Sony	KP41DS1U	RE2D (based on BE3D)	1999, RM892						
Sony	KP41S3U	RE1	1996, RM831						
Sony	KP41S4U	RE2 (based on BE3D)	1998, RM862						
Sony	KP41S5U	RE2	1999, RM862						
Sony	KP44DX2	AE6X	2003, RM948						
Sony	KP44PS2	RE3W	2001, RM903						
Sony	KP44PX2U	AE6X	2002, RM938						
Sony	KP44PX3U	AE6Y	2004, RM945						
Sony	KP46S4U	RX1E	1997, RM831						
Sony	KP48PS1	RE3	2000, RM892						
Sony	KP53PS1	RE3	2000, RM892						
Sony	KP53S4U	RX1E	1997, RM831						
Sony	KP61PS1	RE3	2000, RM892						
Sony	KPS4112	AP1E	1995, RM831						
Sony	KT-X1420UB	SCC-603-A							
Sony	KV1201UB	SCC23A-A							
Sony	KV1310		1974						
Sony	KV1320		1972						
Sony	KV1330		1974						
Sony	KV1340		1975						
Sony	KV1352E	P-2E							
Sony	KV1400		1978						
Sony	KV1412UB	XE3	1984, RM636						
Sony	KV1430UB	XE3	1983						
Sony	KV1434M3	GP1A (nonUK, brought from abroad)	RM687B						
Sony	KV1440UB	XE5	1985						
Sony	KV1442UB	XE5	1986, RM651						
Sony	KV1460UB	GP1	1987						
Sony	KV1462UB	GP1	1987, RM655						
Sony	KV14CT1U	BX1	2003, RMW100						
Sony	KV14FV1U	BC5	2000, RMC815	around £350					
Sony	KV14LM1U	FE2	2000, RM889						
Sony	KV14LT1U	FE2	2000, RM887						
Sony	KV14M1U	BE4	1996, RM836						
Sony	KV14T1U	BE4	1996, RM836						
Sony	KV14V4U	TE1	1996, RMC802						
Sony	KV14V5U	BC4	1997, RMC811						
Sony	KV14V6U	BC4	1997, RMC811						
Sony	KV1612UB	XE3	1979, RM604B	SCC-251A					
Sony	KV16WS1U	BE5	1996, RM836						
Sony	KV16WT1U	BE4	1995, RM836						
Sony	KV16XMTU	GP2	1987, RM654						
Sony	KV1800		1972						
Sony	KV1810		1973						
Sony	KV1820	SCC-132B-B	ALSO SCC-155A-A	MADE1976					
Sony	KV1822UB	SCC-146C-B	1978						
Sony	KV1882UB	XE3	1984, RM636	SCC-521C-A					
Sony	KV19XMTU	GP2	1987, RM654						
Sony	KV19XMU	GP2	1987, RM652						
Sony	KV2000UB		1975						
Sony	KV2000UB-II/1820	SCC-132A-A & B	ALSO SCC-99A-A	1977					
Sony	KV2020		1979						
Sony	KV2022		1979, RM604B						
Sony	KV2029								
Sony	KV2040		1981						
Sony	KV2052U	PE2	1982, RM621						
Sony	KV2056UB	PE2	1982, RM615						
Sony	KV2060	XE3	1983						
Sony	KV2062	XE3	1983, RM632						
Sony	KV2066	XE3	1983, RM632						
Sony	KV2075								
Sony	KV2090	XE4	1985						
Sony	KV2092	XE4	1985, RM641						
Sony	KV2096UB	XE4	1985, RM641						
Sony	KV20WS1U	BE5	1997, RM836						
Sony	KV211XMTU	AE1	1989, RM670						
Sony	KV211XMU	AE1	1989, RM671						
Sony	KV2121U	AE1							
Sony	KV2153MT								
Sony	KV2170U	BE4A							
Sony	KV2171U	BE4A							
Sony	KV21CL10U	BX1, 50Hz	2003, RMW100, £215						
Sony	KV21CT1U	BX1, 50Hz	2003, RMW100, £170						
Sony	KV21FT1U	FE2	2000, RM887						
Sony	KV21FV1U	BC5	2000, RMC815	around £450					
Sony	KV21FX20	FE1A	nonUK						
Sony	KV21FX30	FE2	nonUK						
Sony	KV21LS30U	FE2	2000, RM887						
Sony	KV21LT1U	FE2	2000, RM887						
Sony	KV21M1U	BE4A	1996, RM836						
Sony	KV21M3U	BE4A	1997, RM836						
Sony	KV21M5	FE1	1998, nonUK						
Sony	KV21T1U	BE4A	1996, RM836						
Sony	KV21T3U	BE4A	1997, RM836						
Sony	KV21V4U	TE1	1996, RMC802						
Sony	KV21V5U	BC4	1997, RMC811						
Sony	KV21V6U	BC4	1997, RMC811						
Sony	KV21X1U	BE5	1996, RM836						
Sony	KV21X4U	BE5	1997, RM836						
Sony	KV21X5U	FE1	1998, RM863						
Sony	KV21XMTU	AE1	1987, RM670						
Sony	KV21XMU	AE1	1987, RM671						
Sony	KV21XRTU	SX	1986, RM661						
Sony	KV21XRU	SX	1986, RM661						
Sony	KV2200		1978						
Sony	KV2201	YE2	1981						
Sony	KV2202		1978						
Sony	KV2204UB	SCC-244A-A	1979, RM604B						
Sony	KV2206		1980						
Sony	KV2207		1980						
Sony	KV2212UB	YE2	1982, RM615						
Sony	KV2212UBII	YE2	1984, RM632						
Sony	KV2215UB	YE2	1985, RM632						
Sony	KV2216UB	YE2	1982, RM615						
Sony	KV2216UBII	YE2	1984, RM632						
Sony	KV2217UB	YE2	1985, RM632						
Sony	KV2252UB	PE3 (chassis depends on year)	1983, RM632						
Sony	KV2252UB	RX (chassis depends on year)	1985, RM632						
Sony	KV2256UB	PE3 (chassis depends on year)	1983, RM632						
Sony	KV2256UB	RX (chassis depends on year)	1985, RM632						


Sony	KVB2512U	AE2	1993, RM830						
Sony	KVB2513	AE2							
Sony	KVB2515	AE2							
Sony	KVB252	AE2B							
Sony	KVB2912U	AE2	1993, RM830						
Sony	KVB2913	AE2							
Sony	KVB2915	AE2							
Sony	KVB292	AE2B							
Sony	KVC2121	AE1C							
Sony	KVC2122	AE1C	1991, RM816						
Sony	KVC2123	AE1C							
Sony	KVC2163	AE1C							
Sony	KVC2521	AE1B							
Sony	KVC2522	AE1C	1991, RM816						
Sony	KVC2523	AE1B							
Sony	KVC2531	AE1B							
Sony	KVC2533	AE1B							
Sony	KVC2561	AE1C							
Sony	KVC2563	AE1C							
Sony	KVC2573	AE1C							
Sony	KVC27	AE1							
Sony	KVC2721	AE1							
Sony	KVC2911	AE1							
Sony	KVC2921	AE1B							
Sony	KVC2923	AE1B							
Sony	KVC2931	AE1B							
Sony	KVC2933	AE1B							
Sony	KVC2961	AE1C							
Sony	KVC2963	AE1C							
Sony	KVC2963	AE1C							
Sony	KVC2973	AE1C							
Sony	KVD2511	AE1A							
Sony	KVD2512	AE1A	1990, RM689						
Sony	KVD2911	AE1A							
Sony	KVD2912	AE1A	1990, RM689						
Sony	KVD2921	AE1A							
Sony	KVD3411	DE1							
Sony	KVD3412	DE1	1989, RM685						
Sony	KVD3431	DE2							
Sony	KVD3432	DE2	1991, RM811						
Sony	KVD3433	DE2							
Sony	KVDX21	AE1							
Sony	KVDX2112	AE1	1989, RM670						
Sony	KVDX21TU	AE1	1989, RM670						
Sony	KVDX271TU	AE1	1989, RM670						
Sony	KVDX27T	AE1							
Sony	KVDX27TU	AE1	1989, RM670						
Sony	KVE2511	AE1A							
Sony	KVE2512U	AE1A	1990, RM689						
Sony	KVE2521	AE1C							
Sony	KVE2522	AE1C	1991, RM817						
Sony	KVE2523	AE1C							
Sony	KVE2532	AE2	1992, RM830						
Sony	KVE254	AE2A							
Sony	KVE2542	AE2A	1993, RM831						
Sony	KVE2543	AE-2A							
Sony	KVE255	AE2B							
Sony	KVE2911	AE1A							
Sony	KVE2912U	AE1A	1990, RM689						
Sony	KVE2921	AE1C							
Sony	KVE2922U	AE1C	1991, RM817						
Sony	KVE2923	AE1C							
Sony	KVE2925	AE1C	1991, RM813						
Sony	KVE2932	AE2	1992, RM830						
Sony	KVE2933	AE2A							
Sony	KVE294	AE2A							
Sony	KVE2942U	AE2A	1993, RM831						
Sony	KVE2943	AE2A							
Sony	KVE295	AE2B							
Sony	KVE296	AE2F							
Sony	KVE2963	AE2A							
Sony	KVE3433	AE2							
Sony	KVFX2921	CE1							
Sony	KVFX2923	CE1							
Sony	KVFX29TU	FX	1989, RM682						
Sony	KVG2515U	AE2B	1994, RM831, TV/SAT RX						
Sony	KVG2915U	AE2B	1994, RM831, TV/SAT RX						
Sony	KVH1510	BE1							
Sony	KVH1513	BE1							
Sony	KVH2513	AE1C							
Sony	KVM1100	EE1A							
Sony	KVM1120	EE1A	1993, RM828						
Sony	KVM1400U	BE2A	1993, RM841						
Sony	KVM1401U	BE2A	1993, RM841						
Sony	KVM1410U	BE2A	1992, RM694						
Sony	KVM1411U	BE2A	1992, RM694						
Sony	KVM1420U	BE2A	1991, RM694						
Sony	KVM1421U	BE2A	1991, RM694						
Sony	KVM1430	BE2A							
Sony	KVM1431	BE2A							
Sony	KVM1440U	BE4	1995, RM836						
Sony	KVM1441U	BE4	1995, RM836						
Sony	KVM14M1U	BE4							
Sony	KVM14TU	BE1	1989, RM657						
Sony	KVM14U	BE1	1989, RM658						
Sony	KVM1620U	BE2A	1991, RM694						
Sony	KVM1621U	BE2A	1991, RM694						
Sony	KVM16TU	BE1	1989, RM657						
Sony	KVM16U	BE1	1989, RM658						
Sony	KVM1920	BE2A							
Sony	KVM1921U	BE2A	1992, RM694						
Sony	KVM19TU	BE1	1989, RM657						
Sony	KVM2100D	BE2A							
Sony	KVM2101U	BE2A	1993, RM841						
Sony	KVM2120U	BE1	1990, RM670						
Sony	KVM2121U	BE1							
Sony	KVM2130	BE1	1991, RM670						
Sony	KVM2131	BE1	1991, RM670						
Sony	KVM2140U	BE2A	1991, RM820						
Sony	KVM2141U	BE2A	1991, RM820						
Sony	KVM2150U	BE2A	1992, RM826						
Sony	KVM2151	BE2A	1992, RM826						
Sony	KVM2170U	BE4A	1995, RM836						
Sony	KVM2171U	BE4A	1995, RM836						
Sony	KVM21TU	AE1							
Sony	KVM21U	AE1	1989, RM670						
Sony	KVM21XMU	AE-1							
Sony	KVM2511	AE1	1989, RM670						
Sony	KVM2521	AE1C	1991, RM816						
Sony	KVM2531	AE1C	1992, RM816						
Sony	KVM2541	BE3B	1994, RM833						
Sony	KVP14U	BE1	1989						
Sony	KVS2911	AE1							
Sony	KVS2912	AE2	1992, RM832						
Sony	KVS2922	AE2A	1993, RM842						
Sony	KVS2942	AE2F	1994, RM831						
Sony	KVS2943	AE2F							
Sony	KVS2952U	AE3 100Hz	1995, RM831						
Sony	KVS3411	AE2							
Sony	KVS3412U	AE2	1993, RM832						
Sony	KVS3412U	AE2A	1994, RM842						
Sony	KVS3413E	AE2							
Sony	KVS3432U	AE2B	1994, RM831						
Sony	KVV1410	BC2	1994, RM846						
Sony	KVV1430	TE1	1995, RMY863						
Sony	KVV281	AE2F							
Sony	KVV2812U	AE2F 100Hz	1994, RM842						
Sony	KVV3212U	AE2F 100Hz	1995, RM842						
Sony	KVX21	AE1							

Sony	KVX2102U	BE3B	1994, RM833						
Sony	KVX2121U	AE1	1989, RM670						
Sony	KVX2129	AE1	1990, RM670						
Sony	KVX2131	AE1C							
Sony	KVX2132U	AE1B	1990, RM689, NICAM						
Sony	KVX2133	AE1B							
Sony	KVX2142	AE1C	1991, RM816						
Sony	KVX2152	AE1C	1992, RM816						
Sony	KVX2153	AE1C							
Sony	KVX2162U	AE2	1993, RM830						
Sony	KVX2163	AE1C							
Sony	KVX217	AE2B							
Sony	KVX2172	AE2B	1994, RM831						
Sony	KVX2173	AE2B							
Sony	KVX2182U	BE3B	1995, RM833						
Sony	KVX21TU	AE1	1988, RM670						
Sony	KVX2502	BE3B	1994, RM833						
Sony	KVX2503	BE3B							
Sony	KVX2521	AE1	1989, RM670						
Sony	KVX2529U	AE1	1990, RM670						
Sony	KVX2531	AE1C							
Sony	KVX2532	AE1B	1990, RM689						
Sony	KVX2533	AE1B							
Sony	KVX2542	AE1C	1991, RM831						
Sony	KVX2545	AE1C	1991, RM824						
Sony	KVX2552	AE1C	1992, RM816						
Sony	KVX2553	AE1C							
Sony	KVX2560	AE2							
Sony	KVX2561	AE2							
Sony	KVX2562U	AE2	1993, RM830						
Sony	KVX2563	AE2							
Sony	KVX257	AE2B							
Sony	KVX2572	AE2B	1994, RM831						
Sony	KVX2573	AE2B							
Sony	KVX2582U	BE3B	1995, RM833						
Sony	KVX25TU	AE1	1988, RM670						
Sony	KVX2902	BE3B	1994, RM833, A board	part number A-1632-199-A					
Sony	KVX2903	BE3B							
Sony	KVX2910	AE1							
Sony	KVX2931	AE1C							
Sony	KVX2932	AE1B	1990, RM689						
Sony	KVX2933	AE1B							
Sony	KVX2942	AE1C	1991, RM816						
Sony	KVX2952	AE1C	1992, RM816						
Sony	KVX2962	AE2	1993, RM830						
Sony	KVX2963	AE2							
Sony	KVX297	AE2B							
Sony	KVX2972	AE2B	1994, RM831						
Sony	KVX2973	AE2B							
Sony	KVX2982U	BE3B	1995, RM833, A board 1-655-470-11	part number A-1632-275-A					
Sony	KX14CP1		1985						
Sony	KX20PS1	HF	1982						
Sony	KX27PS1	HF	1982						
Sony	KZ32TS1	??	2002, RM932						
Sony	KZ32TS2	??	2003, RM932						
Sony	KZ42TS1	??	2002, RM932						
Sony	KZ42TS2	??	2003, RM932						
Sony	PVM-1440OM	SCC-C57A-A							
Sony	PVM-1442OM	SCC-C56A-A							
Sony	PVM-1444OM	SCC-C55A-A							
Sony	TV9-90UB	D/S MONO							
Susumu	FX1400R	Murphy CTV3500							
Susumu	FX14S	Murphy CTV3500							
Susumu	FX20	Nikkai NT20	Sentra STX600						
Susumu	GT20	Hinari CT5							
Tandy	CTV1402	Decca 140							
Tandy	CTV1601	Decca 160							
Tandy	CTV2102	Decca 160							
Tashiko	12D971	Samsung VT306K							
Tashiko	14D961	Sanyo CTP3141							
Tashiko	14D962	Sanyo E2	Sanyo CTP3144						
Tashiko	14D971	Samsung CI338F							
Tashiko	14E881	Nikkai TLG0101							
Tashiko	14F891	Decca 160	Tatung VN1671						
Tashiko	16E891	Decca 160	Tatung DP8655						
Tashiko	20E911	Jackson 20R	Matsui CTV2055						
Tashiko	20E912	Jackson 20R	Matsui CTV2055						
Tashiko	20F862	ITT Pico S/3							
Tashiko	45E881	Nikkai TLG010							
Tashiko	51E941	Finlandia/Salora/Granada	C51EZ4						
Tashiko	51E942	Finlandia/Salora/Granada	C51EZ4						
Tatung	D14DT90S	TV/DVD PT90 chassis	2003	remote 631020001381					
Tatung	D14DT91S	TV/DVD PT90 chassis							
Tatung	D14RFG5	F Series							
Tatung	D14RFG6	F Series							
Tatung	D14RFG7	F Series							
Tatung	D14RKD5	K Series (chassis KAT00-W, Cabinet 14CX4)	2002, nonTEXT	chassis marked 200-100-TV2K					
Tatung	D14RKD5	K Series (chassis KAT00-W, Cabinet 14CX7)	2002, nonTEXT	chassis marked 200-100-TV2K					
Tatung	D14RKG7LS	K Series (TV3K chassis)							
Tatung	D14TFG5	F Series							
Tatung	D14TFG6	F Series							
Tatung	D14TKD5	K Series (chassis KAT00-I, Cabinet 14CX4)	2002, TEXT	chassis marked 200-100-TV2K					
Tatung	D14TKG5	K Series (chassis KAT00-I, Cabinet 14CX7)	2002, TEXT	chassis marked 200-100-TV2K					
Tatung	D14TKG6LS	K Series (TV3K chassis)							
Tatung	D14TT92S	PT92							
Tatung	D20NDE5	D4N Series							
Tatung	D20RFG5	F Series							
Tatung	D20RKD5	K Series (chassis KBT00-W, Cabinet 20CX7)	2002, nonTEXT	chassis marked 200-100-TV2K					
Tatung	D20TFG6	F Series							
Tatung	D20TKG5	K Series (chassis KBT00-I, Cabinet 20CX7)	2002, TEXT	chassis marked 200-100-TV2K					
Tatung	D21NDE5	D4N Series							
Tatung	D21NF91S	PT90							
Tatung	D21NT90S	PT90							
Tatung	D21NT92S	PT92							
Tatung	D21RDF6	D Series (D4N Series)							
Tatung	D21TFG5	F Series							
Tatung	D21TFG6	F Series							
Tatung	D21TKG5LS	K Series							
Tatung	D25N440	4400 chassis							
Tatung	D28DGH5S	G Series							
Tatung	D28N440 (28BKD)	4400 chassis							
Tatung	D28N441	4400							
Tatung	D28NGH5S	G Series							
Tatung	D28NT92S	PT92							
Tatung	D28W441 (28ZKR)	4400 chassis		LOPTx S065621350 1372.0030 (Wills Grove LT-838 £14.95), equiv HR8624, FBT40824					
Tatung	D28WHH5S	H Series (H3N)							
Tatung	D28WHH6S	H Series							
Tatung	D28W792S	PT92							
Tatung	D32W441S	4400 chassis							
Tatung	D32W792S	PT92							
Tatung	DP8655	160	Decca	Tashiko 16E891					
Tatung	DVC763	Orion chassis	PCB marked TM9450A, video VM9162D	Micro OEC0078C, option codes EEPROM address 100H					
Tatung	DVC764	Orion chassis		Micro OEC0096B					
Tatung	DVT466S	Orion chassis		Micro OEC0107B, option codes EEPROM address 0B4h (0B4->0B4h)					
Tatung	RR5188	170Q	Decca						
Tatung	T14DT90S	TV/DVD PT90 chassis							
Tatung	T14DT91S	TV/DVD PT90 chassis	2003	remote 631020001381					
Tatung	T14RF70	F Series							
Tatung	T14RF71	F Series							
Tatung	T14RK40	K Series (chassis KAT00-W, Cabinet 14CX4)	2002, nonTEXT	chassis marked 200-100-TV2K					
Tatung	T14RK70	K Series (chassis KAT00-W, Cabinet 14CX7)	2002, nonTEXT	chassis marked 200-100-TV2K					
Tatung	T14TD40	D Series							
Tatung	T14TF70	F Series							
Tatung	T14TF71	F Series							
Tatung	T14TK40	K Series (chassis KAT00-I, Cabinet 14CX4)	2002, TEXT	chassis marked 200-100-TV2K					
Tatung	T14TK70	K Series (chassis KAT00-I, Cabinet 14CX7)	2002, TEXT	chassis marked 200-100-TV2K					
Tatung	T20TD50	D Series							
Tatung	T20TF70	F Series							
Tatung	T20TK70	K Series (KBT00-I, Cabinet 20CX7)	2002, TEXT	chassis marked 200-100-TV2K					

Tatung	T21N421	Orion chassis				
Tatung	T21NT90S	PT90				
Tatung	T21NT92S	PT92	2002			
Tatung	T21TF70	F Series				
Tatung	T21TK70	K Series (chassis KCT00-I, Cabinet 21CX7)	2002, TEXT			
Tatung	T21TT92S	PT92				
Tatung	T24WF255S	2550 chassis	2003, realflat CRT			
Tatung	T25N250S	2500 chassis				
Tatung	T25N255S	2550 chassis	2003			
Tatung	T25N440	4400 chassis				
Tatung	T25NE61	E1 SERIES				
Tatung	T25T395	3960 chassis	remote			
Tatung	T28DG80S	G series				
Tatung	T28DG82S	G Series	2003			
Tatung	T28N440	4400 chassis				
Tatung	T28NE51	E SERIES				
Tatung	T28NG80S	G series				
Tatung	T28NT92S	PT92	2003			
Tatung	T28W440	4400 chassis				
Tatung	T28W441S	4400 chassis				
Tatung	T28W730	7300 chassis				
Tatung	T28WF255S	2550 chassis	2003, realflat CRT			
Tatung	T28WG82S	G Series (G5N)				
Tatung	T28WH81S	H Series (H3N)				
Tatung	T28WH82S	H Series (H3N)	2003			
Tatung	T28WT91S	PT90P-I	2004			
Tatung	T32W250S	2500 chassis				
Tatung	T32W255S	2500 chassis	2003			
Tatung	T32W440 (32KBD)	4400 chassis				
Tatung	T32W441S	4400 chassis				
Tatung	T32WF255S	2550 chassis	2003, realflat CRT			
Tatung	TN1201	120/130	Decca			
Tatung	TN1401	140	Decca			
Tatung	TN1441	140	Decca			
Tatung	TN1601A	160	Decca			
Tatung	TN1616	160	Decca			
Tatung	TN1621	160	Decca			
Tatung	TN8402	140	Decca			
Tatung	TN8422	145A	Decca			
Tatung	TN8432	145	Decca			
Tatung	TN8904	190	Decca			
Tatung	TN9201	120/130	Decca			
Tatung	TNC50	C SERIES				
Tatung	TNC52	C SERIES				
Tatung	TO8632	165	Decca			
Tatung	TO8682	165	Decca			
Tatung	TP1207	120/130	Decca			
Tatung	TP1403	10	Decca			
Tatung	TP1603/A	160	Decca			
Tatung	TP1623	160	Decca			
Tatung	TP8404	140	Decca			
Tatung	TP8424	145A	Decca			
Tatung	TP8434	145	Decca			
Tatung	TP9207	120/130	Decca			
Tatung	TP9424	145A	Decca			
Tatung	TP9434	145	Decca			
Tatung	TT1202	120/130	Decca			
Tatung	TT1405	140	Decca			
Tatung	TT1409	140	Decca			
Tatung	TT1605	160	Decca			
Tatung	TT1607	160	Decca			
Tatung	TT1625	160	Decca			
Tatung	TT1627	160	Decca			
Tatung	TT1905	190	Decca			
Tatung	TT8406	140	Decca			
Tatung	TT8409	140	Decca			
Tatung	TT8416	145A	Decca			
Tatung	TT8426	145A	Decca			
Tatung	TT8436	145	Decca			
Tatung	TT8906	190/195	Decca			
Tatung	TT9202	120/130	Decca			
Tatung	TT9205	120/130	Decca			
Tatung	TT9206	120/130	Decca			
Tatung	TT9406	140	Decca			
Tatung	TT9409	140	Decca			
Tatung	TT9416	145A	Decca			
Tatung	TT9426	145A	Decca			
Tatung	TT9436	145	Decca			
Tatung	TU3D53	D SERIES				
Tatung	TU8620M	165	Decca			
Tatung	TU8638	165	Decca			
Tatung	TU9711	170	Decca			
Tatung	TUN0A51	A SERIES (A3N)				
Tatung	TUV2C52	C SERIES				

[illegible]








CRT LG W66QBD240X11		
---------------------	--	--


[illegible]


[illegible]

























[illegible]















[illegible]


interchangeable.
when you move to the next item using Pr+/-.


together for >3 sec.


points on the keyboard control unit for a short period, switch the unit off and disconnect it from the mains.


when you move to the next item using Pr+/-.

















[illegible]

[illegible]








[illegible]





[illegible]



























































[illegible]

[illegible]